

******* CAL. 90S5 MOV'T PARTS LIST *******

ORIGINAL PARTS, MADE IN JAPAN

PART NAME	90S5
BALANCE BRIDGE	710-204
BALANCE WITH HAIRSPRING REGULATED	039-991
BARREL AND TRAIN WHEEL BRIDGE	701-H01
BARREL COMPLETE	001-992
BREAKELEVER FOR SECOND HAND	269-402
CANNON PINION WITH DRIVING WHEEL	028-A16
CENTER WHEEL & PINION	012-A20
CENTER WHEEL BRIDGE	702-201
CLAMP CASING	082-060
CLICK	060-551
CLICK SPRING	903-A15
CLUTCH WHEEL	064-991
CROWN WHEEL	058-501
DATE INDICATOR MAINTAINING PLATE / HOUR WHEEL SP	176-A06
DIAL WASHER	078-120
ESCAPE WHEEL AND PINION	032-991
FORTH WHEEL AND PINION	023-A21
HOUR WHEEL	075-A51
INTERMEDIATE REDUCTION WHEEL AND PINION	088-254
INTERMEDIATE REDUCTION WHEEL AND PINION(2)	088-252
INTERMEDIATE REDUCTION WHEEL AND PINION(3)	088-253
INTERMEDIATE REDUCTION WHEEL AND PINION(4)	138-251
JEWEL PALLET FORK AND STAFF	035-701
LOWER CAP JEWEL MOUNTED	094-040
MINUTE WHEEL AND PINION	072-998
OPERATING LEVER	257-152
OSCILLATING WEIGHT	119-A36
PALLET BRIDGE	708-091
RATCHET SLIDING WHEEL 1	087-B08
RATCHET SLIDING WHEEL(2)	087-A74
RATCHET WHEEL	059-802
REDUCTION WHEEL AND PINION 1 SPRING-CLIP	115-101
REVERSING WHEEL	141-251
SCREW FOR BALANCE BRIDGE	923-998
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE(×7)	923-998
SCREW FOR CLAMP CASING(×2)	924-752
SCREW FOR CLICK	922-820
SCREW FOR CLICK SPRING	922-820
SCREW FOR DAIL(×2)	929-808
SCREW FOR HOUR WHEEL SPRING(×5)	930-701
SCREW FOR MINUTE TRAIN COVER(×2)	923-630
SCREW FOR OSCILLATING WEIGHT(×3)	923-999
SCREW FOR PALLET BRIDGE(×2)	922-820
SCREW FOR STUD	927-020
SCREW FOR TRAIN WHEEL GUARD(MANUAL- WINDING)(×3)	930-701
SCREW FOR TRAIN WHEEL GUARD(AUTOMATIC)(×2)	930-701
SETTING LEVER	067-995
SETTING LEVER PIN	906-A12
SETTING LEVER SPRING	077-998
SETTING STEM	065-A05
SETTING WHEEL	076-751
SPACER FOR DIAL	212-A47
SPIRAL SPRING WITH JEWEL(×2)	098-090
THIRD WHEEL AND PINION	017-A01
TRAIN WHEEL GUARD(MANUAL- WINDING)	117-361
TRAIN WHEEL GUARD(AUTOMATIC)	117-354
UPPER CAP JEWEL MOUNTED	094-010
WINDING PINION	063-351
YOKE	071-999