

******* CAL.9110/20/22/30/32 MOV'T PARTS LIST *******

ORIGINAL PARTS, MADE IN JAPAN

PART NAME	9110	9120	9122	9130	9132
BALANCE BRIDGE	710-204	710-204	710-204	710-204	710-204
BALANCE WITH HAIRSPRING REGULATED	039-993	039-993	039-993	039-993	039-993
BARREL AND TRAIN WHEEL BRIDGE	701-J09	701-J09	701-J09	701-J09	701-J09
BARREL COMPLETE	001-995	001-995	001-995	001-995	001-995
BARREL LOWER WHEEL	901-A56	-	-	901-A56	901-A56
BREAKELEVER FOR SECOND HAND	269-402	269-402	269-402	269-402	269-402
CANNON PINION WITH DRIVING WHEEL	028-A22	028-A22	028-A22	028-A22	028-A22
CALENDAR CORRECTOR FINGER	106-860	106-860	106-860	106-860	106-860
CALENDAR CORRECTOR WHEEL	213-616	213-616	213-616	213-616	213-616
CALENDAR CORRECTOR WHEEL SPRING	903-A18	903-A18	903-A18	903-A18	903-A18
CALENDAR PLATFORM	713-160	713-160	713-160	713-160	713-160
CENTER WHEEL BRIDGE	702-201	702-201	702-201	702-201	702-201
CENTER WHEEL & PINION	012-A20	012-A20	012-A20	012-A20	012-A20
CLICK	060-551	060-551	060-551	060-551	060-551
CLICK SPRING	903-A15	903-A15	903-A15	903-A15	903-A15
CLUTCH WHEEL	064-991	064-991	064-991	064-991	064-991
CROWN WHEEL	058-501	058-501	058-501	058-501	058-501
DATE DIAL	108-N4XX	108-K9XX	108-K9XX	108-N4XX	108-N4XX
DATE JUMPER	109-875	109-875	109-875	109-875	109-875
24HOUR DRIVING WHEEL	100-818	100-818	-	-	100-818
24HOUR WHEEL	103-A13	103-A13	103-A13	103-A13	103-A13
DATE DIAL GUARD	293-A18	293-A18	293-A18	293-A18	293-A18
DAY CORRECTOR LEVER	116-993	116-993	116-993	-	-
DAY WHEEL	200-156	200-156	200-156	-	-
DAY JUMPER	209-251	209-251	209-251	-	-
DIAL WASHER 1	078-120	078-120	078-120	078-120	078-120
DIAL WASHER 2	078-660	-	-	078-660	078-660
ESCAPE WHEEL AND PINION	032-991	032-991	032-991	032-991	032-991
FOURTH WHEEL AND PINION	023-A27	023-A27	023-A27	023-A27	023-A27
HOURLY WHEEL	075-A63	075-A63	075-A63	075-A63	075-A63
INTERMEDIATE DATE WHEEL(1)	087-A93	087-A93	087-A93	087-A93	087-A93
INTERMEDIATE DATE WHEEL(2)	087-A94	087-A94	087-A94	087-A94	087-A94
INTERMEDIATE DATE CORRECTING WHEEL	087-A72	087-A72	087-A72	087-A72	087-A72
INTERMEDIATE POWER RESERVE WHEEL(1)	087-A95	-	-	087-A95	087-A95
INTERMEDIATE POWER RESERVE WHEEL(2)	087-A96	-	-	087-A96	087-A96
INTERMEDIATE POWER RESERVE WHEEL(3)	087-A97	-	-	087-A97	087-A97
INTERMEDIATE POWER RESERVE WHEEL(4)	087-B01	087-B01	087-B01	087-B01	087-B01
INTERMEDIATE REDUCTION WHEEL AND PINION 1	088-254	088-254	088-254	088-254	088-254
INTERMEDIATE REDUCTION WHEEL AND PINION 2	088-252	088-252	088-252	088-252	088-252
INTERMEDIATE REDUCTION WHEEL AND PINION 3	088-253	088-253	088-253	088-253	088-253
INTERMEDIATE REDUCTION WHEEL AND PINION 4	138-251	138-251	138-251	138-251	138-251
INTERMEDIATE REDUCTION WHEEL AND PINION 1 SPRING-CLIP	115-101	115-101	115-101	115-101	115-101
JEWELLED PALLET FORK AND STAFF	035-702	035-702	035-702	035-702	035-702
CAP JEWEL MOUNTED (1)	094-040	094-040	094-040	094-040	094-040
LOWER PLATE FOR BARREL COMPLETE	719-058	719-058	719-058	719-058	719-058
LOWER PLATE FOR CALENDAR	719-065	719-056	719-056	719-065	719-065
MINUTE WHEEL AND PINION	072-999	072-999	072-999	072-999	072-999
MONTH CORRECTOR LEVER	-	265-202	265-202	-	-
MONTH CORRECTOR SPRING	-	903-A19	903-A19	-	-
MONTH JUMPER	-	109-874	109-874	-	-
MONTH WHEEL	-	294-807	294-807	-	-
MONTH DRIVING WHEEL	-	103-A12	103-A12	-	-
OPERATING LEVER	257-152	257-152	257-152	257-152	257-152
OSCILLATING WEIGHT	119-A57	119-A58	119-A68	119-A59	119-A60
PALLET BRIDGE	708-091	708-091	708-091	708-091	708-091
POWER RESERVE WHEEL	189-163	-	-	189-163	189-163
RATCHET SLIDING WHEEL 1	087-B08	087-B08	087-B08	087-B08	087-B08
RATCHET SLIDING WHEEL 2	087-A74	087-A74	087-A74	087-A74	087-A74
RATCHET WHEEL	059-802	059-802	059-802	059-802	059-802
REVERSING WHEEL	141-251	141-251	141-251	141-251	141-251
SCREW FOR BALANCE BRIDGE	923-998	923-998	923-998	923-998	923-998
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE (x5)	923-998	923-998	923-998	923-998	923-998
SCREW FOR CALENDAR PLATFORM	929-700	929-700	929-700	929-700	929-700
SCREW FOR CENTER WHEEL BRIDGE	923-998	923-998	923-998	923-998	923-998
SCREW FOR CLICK	922-820	922-820	922-820	922-820	922-820
SCREW FOR CLICK SPRING	922-820	922-820	922-820	922-820	922-820
SCREW FOR DATE DIAL GUARD	929-700	929-700	929-700	929-700	929-700
SCREW FOR DATE DIAL GUARD (x4)	930-702	930-702	930-702	930-702	930-702
SCREW FOR LOWER PLATE FOR BARREL COMPLETE (x2)	922-940	922-940	922-940	922-940	922-940
SCREW FOR LOWER PLATE FOR CALENDAR (x2)	923-998	923-998	923-998	923-998	923-998
SCREW FOR OSCILLATING WEIGHT (x3)	923-999	923-999	923-999	923-999	923-999
SCREW FOR PALLET BRIDGE (x2)	922-820	922-820	922-820	922-820	922-820
SCREW FOR SETTING LEVER JUMPER (x2)	923-630	923-630	923-630	923-630	923-630
SCREW FOR STUD	927-020	927-020	927-020	927-020	927-020

SCREW FOR TRAIN WHEEL GUARD(MANUAL- WINDING)(x3)	930-701	930-701	930-701	930-701	930-701
SCREW FOR TRAIN WHEEL GUARD(AUTOMATIC)(x 2)	930-701	930-701	930-701	930-701	930-701
SCREW FOR UPPER PLATE FOR CALENDER (x 4)	923-998	923-998	923-998	923-998	923-998
SETTING LEVER	067-995	067-995	067-995	067-995	067-995
SETTING LEVER SPRING	077-996	077-996	077-996	077-996	077-996
SETTING LEVER PIN	906-A12	906-A12	906-A12	906-A12	906-A12
SETTING STEM	065-A05	065-A05	065-A05	065-A05	065-A05
SETTING WHEEL	076-751	076-751	076-751	076-751	076-751
SPIRAL SPRING WITH JEWEL (1)	098-090	098-090	098-090	098-090	098-090
SPIRAL SPRING WITH JEWEL (2)	098-090	098-090	098-090	098-090	098-090
THIRD WHEEL AND PINION	017-A01	017-A01	017-A01	017-A01	017-A01
TRAIN WHEEL GUARD(MANUAL- WINDING)	117-361	117-361	117-361	117-361	117-361
TRAIN WHEEL GUARD(AUTOMATIC)	117-354	117-354	117-354	117-354	117-354
CAP JEWEL MOUNTED (2)	094-010	094-010	094-010	094-010	094-010
UPPER PLATE FOR CALENDER	703-112	703-114	703-114	703-112	703-112
WINDING PINION	063-351	063-351	063-351	063-351	063-351
YOKE	071-995	071-995	071-995	071-995	071-995
** LONGER SETTING STEM(24.0MM) **	065-A25	065-A25	065-A25	065-A25	065-A25