

***** CALL. 9T/U1X MOV'T PARTS LIST *****

ORIGINAL PARTS, MADE IN JAPAN

<u>PART NAME</u>	<u>9T13</u>	<u>9U13</u>	<u>9T15</u>	<u>9U15</u>
BATTERY	280-730	280-450	280-730	280-450
BATTERY CONNECTOR SPRING	231-368	231-373	231-368	231-373
BATTERY INSULATOR	230-220	230-220	230-220	230-220
CALENDAR CORRECTOR LEVER		116-112	116-112	116-112
CANNON PINION WITH DRIVING WHEEL	028-286	028-286	028-301	028-301
CLUTCH WHEEL	064-790	064-790	064-790	064-790
COIL UNIT	246-182	246-185	246-182	246-185
DATE DIAL	108-E50	108-E60	108-E50	108-E60
DATE DIAL DRIVING WHEEL	103-111	103-111	103-111	103-111
DATE JUMPER	109-500	109-650	109-500	109-650
DIAL GUARD RING	110-470	-	110-470	-
DIAL WASHER	078-040	078-040	078-040	078-040
ELECTRONIC CIRCUIT UNIT	279-B32	279-B32	279-B32	279-B32
FIFTH WHEEL AND PINION	084-700	084-700	084-700	084-700
FOURTH WHEEL AND PINION	023-326	023-326	023-328	023-328
GUARD FOR DATE DIAL	293-103	293-108	293-103	293-108
HOUR WHEEL	075-455	075-455	075-455	075-455
INTERMEDIATE WHEEL	087-162	087-162	087-162	087-162
MINUTE WHEEL AND PINION	072-121	072-121	072-121	072-121
ROTOR	285-175	285-175	285-175	285-175
SCREW (1)	923-112	923-112	923-112	923-112
SCREW (2)	930-640	930-640	930-640	930-640
SCREW FOR DATE DIAL GUARD ×3	929-510	929-510	929-510	929-510
SETTING LEVER	067-173	067-173	067-173	067-173
SETTING LEVER SPRING	077-136	077-136	077-136	077-136
SETTING STEM	065-495	065-495	065-495	065-495
SETTING WHEEL	076-640	076-640	076-640	076-640
SPACER FOR SETTING STEM	212-247	212-264	212-247	212-264
STATOR	190-152	190-172	190-152	190-172
THIRD WHEEL AND PINION	017-149	017-149	017-149	017-149
TRAIN WHEEL BRIDGE	701-C81	701-E45	701-C81	701-E45
YOKE	071-137	071-137	071-137	071-137