

***** CALL. GP00/01/30/10/11/50/03/52 MOV'T PARTS LIST *****

ORIGINAL PARTS, MADE IN JAPAN

<u>PART NAME</u>	<u>GP00</u>	<u>GP01</u>	<u>GP30</u>	<u>GP10</u>	<u>GP11</u>	<u>GP50</u>	<u>GP03</u>	<u>GP52</u>
BATTERY	280-3104	280-3104	280-3104	280-3104	280-3104	280-3104	280-3104	280-3104
BATTERY CLAMP	234-A87	234-A88	234-A89	234-B00	234-B01	234-B03	234-B06	234-B07
BATTERY CONNECTOR SPRING	231-373	231-373	231-373	231-373	231-373	231-373	231-373	231-373
CALENDAR PLATFORM	713-151	713-151	713-151	713-151	713-151	713-152	713-153	713-152
CANNON PINION WITH DRIVING WHEEL	028-995	028-995	028-995	028-997	028-997	028-998	028-995	028-998
CENTER WHEEL COCK	711-225	711-225	711-225	711-225	711-225	711-225	711-225	711-225
CLUTCH WHEEL	064-790	064-790	064-790	064-790	064-790	064-790	064-790	064-790
COIL UNIT	246-185	246-185	246-185	246-185	246-185	246-185	246-185	246-185
CORRECTOR INTERMEDIATE WHEEL FOR 24H(1)	087-998	087-998	----	----	----	087-998	087-998	087-998
CORRECTOR INTERMEDIATE WHEEL FOR 24H(2)	087-997	087-997	----	----	----	087-997	087-997	087-997
CORRECTOR INT. WHEEL FOR DATE	087-997	087-997	087-997	087-997	087-997	087-997	087-997	087-997
CORRECTOR INT. WHEEL(1)	087-994	087-994	087-994	087-994	087-994	087-994	087-994	087-994
CORRECTOR INT. WHEEL(2)	087-996	087-996	087-996	087-996	087-996	087-996	087-996	087-996
CORRECTOR WHEEL FOR 24H	213-602	213-602	----	----	----	213-602	213-602	213-602
CORRECTOR WHEEL FOR DATE	213-601	213-601	213-601	213-601	213-601	213-603	213-601	213-603
DATE DIAL DRIVING WHEEL	103-995	103-995	103-995	103-995	103-995	103-996	103-995	103-996
DATE DIAL MAINTAINING PLATE	293-994	293-994	293-994	293-994	293-994	293-996	293-994	293-996
DATE DIAL(1)	108-H9XX	108-J1XX	108-H9XX	108-H9XX	108-J1XX	----	108-J1XX	----
DATE DIAL(2)	108-J0XX	108-J2XX	108-J0XX	108-J0XX	108-J2XX	----	108-J2XX	----
DATE FINGER	106-852	106-852	106-852	106-852	106-852	----	106-852	----
DIAL GUARD RING	110-703	110-703	110-703	110-703	110-703	110-704	110-706	110-704
DIAL WASHER	078-040	078-040	078-040	078-040	078-040	078-040	078-040	078-040
ELECTRONIC CIRCUIT UNIT	279-G00	279-G00	279-G00	279-G00	279-G00	279-G00	279-G00	279-G00
FIFTH WHEEL AND PINION	084-953	084-953	084-953	084-955	084-955	084-953	084-953	084-953
FOURTH WHEEL AND PINION	023-996	023-996	023-996	023-998	023-998	023-999	023-996	023-999
HOLD SPRING FOR SECONDS WHEELS	----	----	----	078-450	078-450	----	----	----
HOUR WHEEL	075-998	075-998	075-998	075-998	075-998	075-A02	075-998	075-A02
INTERMEDIATE WHEEL FOR 24H(1)	208-054	208-054	----	----	----	208-054	208-054	208-054
INTERMEDIATE WHEEL FOR 24H(2)	087-999	087-999	----	----	----	087-999	087-999	087-999
INTERMEDIATE WHEEL FOR 24H(3)	087-995	087-995	----	----	----	087-995	087-995	087-995
INTERMEDIATE WHEEL FOR 24H(4)	----	----	----	----	----	----	087-A18	----
INTERMEDIATE WHEEL FOR 24H(2) CAM	253-201	253-201	----	----	----	253-201	253-201	253-201
INTERMEDIATE WHEEL FOR 24H(2) SPRING	903-994	903-994	----	----	----	903-994	903-994	903-994
INTERMEDIATE WHEEL FOR DATE(1)	----	----	----	----	----	087-A04	----	087-A04
INTERMEDIATE WHEEL FOR DATE(2)	----	----	----	----	----	087-A05	----	087-A05
INTERMEDIATE WHEEL FOR DATE(3)	----	----	----	----	----	087-A06	----	087-A06
INTERMEDIATE WHEEL FOR SECONDS(1)	----	----	----	087-195	087-195	----	----	----
INTERMEDIATE WHEEL FOR SECONDS(2)	----	----	----	087-195	087-195	----	----	----
JUMPER(1)	109-853	109-853	109-853	109-853	109-853	----	109-853	----
JUMPER(2)	109-854	109-854	109-854	109-854	109-854	----	109-854	----
DATE JUMPER	----	----	----	----	----	109-855	----	109-855
JUMPER WHEEL FOR 24H	208-053	208-053	----	----	----	208-053	208-053	208-053
JUMPER WHEEL FOR DATE	----	----	----	----	----	208-053	----	208-053
MINUTE WHEEL AND PINION	072-992	072-992	072-992	072-992	072-992	072-992	072-992	072-992
RING FOR DATE DIAL MAINTAINING PLATE	027-992	027-992	027-992	027-992	027-992	027-993	027-992	027-993
ROTOR	285-995	285-995	285-995	285-995	285-995	285-995	285-995	285-995
SCREW FOR TRAIN WHEEL BRIDGE	923-992	923-992	923-992	923-992	923-992	923-992	923-992	923-992
SCREW FOR BATTERY CLAMP(1)	923-992	923-992	923-992	923-992	923-992	923-992	923-992	923-992
SCREW FOR BATTERY CLAMP(2)	923-107	923-107	923-107	923-107	923-107	923-107	923-107	923-107
SCREW FOR DATE DIAL MAINTAINING PLATE	929-801	929-801	929-801	929-801	929-801	922-992	929-801	922-992
SECONDS WHEEL	----	----	----	025-993	025-993	----	----	----
SETTING LEVER	067-173	067-173	067-173	067-173	067-173	067-173	067-173	067-173
SETTING LEVER SPRING	077-993	077-993	077-993	077-993	077-993	077-993	077-993	077-993
SETTING STEM	065-992	065-992	065-992	065-992	065-992	065-992	065-992	065-992
SETTING WHEEL	076-640	076-640	076-640	076-640	076-640	076-640	076-640	076-640
SPACER FOR INSULATION	212-A04	212-A04	212-A04	212-A04	212-A04	212-A04	212-A04	212-A04
SPACER FOR SETTING STEM	212-A03	212-A03	212-A03	212-A03	212-A03	212-A03	212-A03	212-A03
SPACER FOR SECONDS WHEEL	----	----	----	----	----	212-A11	----	----
STATOR	190-172	190-172	190-172	190-172	190-172	190-172	190-172	190-172
THIRD WHEEL AND PINION	017-992	017-992	017-992	017-992	017-992	017-992	017-992	017-992
TRAIN WHEEL BRIDGE	701-G07	701-G07	701-G07	701-G07	701-G07	701-G07	701-G07	701-G07
WHEEL FOR 24H(1)	189-151	189-151	----	----	----	189-153	189-151	189-153
WHEEL FOR 24H(2)	----	----	----	----	----	----	189-155	189-156
YOKE	071-992	071-992	071-992	071-992	071-992	071-992	071-992	071-992
DATE DIAL WHEEL (GP50/52)	----	----	----	----	----	189-153	----	189-153