

[illegible]

Normal audio path is from "LOCAL AUDIO" source.
For remote input, UAD connects to phone line after prescribed number of rings.
Remote operator enters correct code to capture bi-directional audio path or perform switching.
System disconnects from phone line per selection (time, loop current interrupt or both).

** Only one set of Normally Open contacts are shown connected. Additional NO and NC contacts are available on the 3185D card.