


Installing Nikon View 5 under Macintosh

When you insert the Nikon View 5 CD into the CD-ROM drive under Mac OS 9.0, 9.1, or 9.2, the **Select Language** dialog box appears automatically. Under Mac OS X, click the **Nikon View 5** icon on the desktop, and then double-click the **Welcome** icon to display the dialog box. After you make settings in this dialog box, the **Install Center** window will be displayed.

Step 1 : Install the software

From the list in the **Software** tab, select the programs you want to install.




Software tab

Step 2 : Install the Plug-in

From the **Other software** tab, select **Cumulus Plug-in**.

You do not need to install this if you do not have Canto's Cumulus 5. This does not appear if your computer is running Mac OS X.



Other software tab

Click [here](#)  to proceed to the next step.




Mac OS X

- You will need to enter the Administrator password to install Nikon View 5 under Mac OS X.
- QuickTime 5.0.2 does not appear if your computer is running Mac OS X.


After you make settings in the **Select Language** dialog box, the **Install Center** window will be displayed automatically. The **Install Center** window has the **Software**, **Other software** and **Customer Support** tabs. Click **Quit** if you want to close the **Install Center** window and cancel installation.

Software



Displays a list of programs that can be installed. Select the check box next to each of the programs you want to install, and then click **Install**.

Other software




Cumulus Plug-in check box

Cumulus Plug-in does not appear if your computer is running Mac OS X.

Select this check box to install Nikon Cumulus Plug-in. You do not need to install this if you do not have Canto's Cumulus 5.

Customer Support




Click this button to view the Nikon technical support Web site for your area (your computer must be configured for connection to the Internet).

Click **Display README file** to display the README file. Be sure to read it before installation.

Click [here](#)  to proceed to the next step.

Step 1 : Select a language

From the pull-down menu, select the language to use in Nikon View 5.
After you select a language, click **Next**.




Click [here](#)  to proceed to the next step.

Step 2 : Select the programs

When installing Nikon View 5, you can also install the bundled programs.

I. Select the programs

From the **Software** tab, select the programs you want to install. If you choose to install multiple programs, the programs are installed in the order displayed in the **Software** tab.



PanoramaMaker check box

Select this check box to install Panorama Maker.

Nikon View 5 check box

Select this check box to install Nikon View 5.

FotoStation Easy check box

Select this check box to install FotoStation Easy.


QuickTime 5.0.2 check box

Select this check box to install Apple Computer's QuickTime 5.0.2. This does not appear if your computer is running Mac OS X.

Click [here](#)  to proceed to the next step.

2. Click Install

After you have selected the programs you want to install, click **Install** in the **Software** tab.



**Install
button**

Click [here](#)  to proceed to the next step.

Image Database Applications

Nikon View 5 supports the following image database program:

- FotoStation Easy: images registered in catalog
- iViewMediaPro (iView Multimedia): images registered in catalog

Step 3 : Install the software

When you have finished selecting the programs to install, start installation.

I. Installing Panorama Maker

If you selected **PanoramaMaker** in the **Software** tab, the installation of Panorama Maker begins. When the installer starts, follow the on-screen instructions to complete installation.

When installation finishes, the dialog box shown below will be displayed. Click **Quit** to proceed to the next step.



If you did not select **PanoramaMaker**, proceed to the next step.

Click [here](#)  to proceed to the next step.

2. Installing Nikon View 5


If you selected **Nikon View 5**, the installation of Nikon View 5 begins. If you did not select **Nikon View 5**, proceed to the next step.

2-1 :Accept the license agreement

When you start installation of Nikon View 5, the license agreement is displayed in the **License agreement** window. Read the agreement carefully, and click **Accept** to continue installation.


When you accept the agreement, the **ReadMe** window is displayed.

Take a few moments to view this file, which may contain important information that could not be included in this manual.



2-2 : Select the installation type

Select **Easy Install** from the pull-down menu in the top left corner of the **Nikon View 5 Installer** dialog box.



Click [here](#)  to proceed to the next step.



Existing Versions of Nikon View


If an older version of Nikon View 5 is installed on your computer, it must be uninstalled before installing Nikon View 5.

Nikon View 5 does not support connection of COOLPIX950, 910, 900, 800, or 700 digital cameras.

Nikon View 5 can however be used to view photographs taken with these cameras if the camera memory card is inserted into a digital camera that Nikon View 5 supports.


2-3: Confirm the install destination

The disk and folder to which Nikon View 5 will be installed are shown in the Install Location area.



2-4 : Start installation


To install Nikon View 5 to the selected location, click **Install** in the **Nikon View 5 Installer** dialog box. A progress meter will be displayed during installation.



2-5 : Complete the installation

A dialog box indicating that installation is complete is displayed.


Click **Quit**.



Click [here](#)  to proceed to the next step.

3. Installing FotoStation Easy

If you selected **FotoStation Easy** in the **Software** tab, the installation of FotoStation Easy begins. The dialog box shown below will be displayed. Click **Continue** and follow the on-screen instructions to complete installation.

Click [here](#)  for more information on FotoStation Easy after installation.



4. Installing Quick Time

If you selected **QuickTime 5.0.2** in the **Software** tab, the installation of QuickTime 5.0.2 begins. When the installer starts, follow the on-screen



instructions to complete installation.


Note you are not required to fill out the **Registration** dialog box. Click **Continue** to continue installation without entering registration information.

Click [here](#)  to proceed to the next step.

5. Quit the installer

When all the selected programs are installed, the dialog box shown below will be displayed.

Click **Restart** to exit the installer and restart your computer.



If the dialog box shown below is displayed, click **Restart** to restart your computer.




6. Install Nikon Cumulus Plug-in

Install Nikon Cumulus Plug-in if you are using Cumulus as your image database program.

Nikon Cumulus Plug-in allows Cumulus 5.0 to handle image information from Nikon digital cameras.


To install Nikon Cumulus Plug-in, select the **Cumulus Plug-in** check box in the **Other software** tab, and click **Install**.

When the installer starts, follow the on-screen instructions to complete installation. Click [here](#)  for settings after the installation.

7. Quit the installer

When the installation of Nikon Cumulus Plug-in finishes, the dialog box shown below will be displayed.

Click **Quit**.



Click [here](#)  to return to the *Nikon View 5 Reference Manual*

Mac OS X

The **Other software** tab does not appear if your computer is running Mac OS X.