


Install Software

Step 1 : Select the software you wish to use



Select the programs you want to install from the list in the **Software** tab. Click **Install**. If you have chosen more than one program, the programs are installed in the order of display.

PanoramaMaker

Select this check box to install PanoramaMaker.

Nikon View 5

Select this check box to install Nikon View 5.

FotoStation Easy

Select this check box to install FotoStation Easy.

QuickTime 5.0.2

Select this check box to install Apple Computer's QuickTime 5.0.2.


✓ Before installation

- You have turned off any virus-checking software that may be running.
- You have exited all other applications.


Step 2 : Install the selected software

2.1 — Install PanoramaMaker

The license agreement shown below will appear. Read the agreement carefully and click **Accept** if you wish to continue the installation.



When you accept the agreement the dialog below is displayed.




Click **Install**, and follow the on-screen instructions.

🔧 PanoramaMaker

You can use PanoramaMaker to combine separate images into a Panorama. This software is particularly useful if your COOLPIX camera has a Panorama Assist mode.



When the installation is complete, the dialog shown below appears. Click **OK**.




2.2 — Install Nikon View 5

The license agreement shown below appears, showing that you are now installing the selected software.

I — Accept the license agreement

When you start installation of Nikon View 5, the license agreement is displayed. Read the agreement carefully, and click **Accept** if you wish to continue installation.




When you accept the agreement, the **ReadMe** window is displayed.

Take a few moments to view this file, which may contain important information that could not be included in this manual.

Click **Continue**.



Installing Nikon View 5 under Mac OS X




When installing Nikon View under Mac OS X, the **Authenticate** dialog box will appear. Enter your administrator name and password.




2 — Choose a location for Nikon View 5

Select **Easy Install** from the pull-down menu in the top left corner of the **Nikon View 5 Installer** dialog box.



3 — Confirm the install destination

The disk and folder to which Nikon View 5 will be installed are shown in the **Install Location** area.



Existing versions of Nikon View


If an older version of Nikon View is installed on your computer, it must be uninstalled before installing Nikon View 5.

4 — Start installation

To install Nikon View 5 to the selected location, click **Install** in the **Nikon View 5 Installer** dialog box. A progress meter will be displayed during installation.



The dialog box shown below will appear when the installation of files is complete. Click **Yes** to create an alias, which will allow you to start Nikon View 5 directly from an icon on the desktop.



If multiple versions of Photoshop (version 5.0 or later) are installed

When more than one version of Photoshop (version 5.0 or later) is installed on your Macintosh, you will be asked to select the version to which you wish to install the plug-in from a list that will appear on screen.


For more information on NEF plug-in, click [here](#) .




5 — Complete the installation

The dialog box shown below will appear indicating that the installation is complete.


Click **Quit** to complete the installation of Nikon View 5.



If the dialog box shown below appears, click **Restart** to restart your computer.




Add to Dock (Mac OS X only)




When installing Nikon View 5 under Mac OS X, the dialog box shown left will appear asking if you want to add Nikon View 5 to the Dock. Click **Yes**. The Nikon View 5 icon will then appear in the Dock, allowing you to start the program by clicking the icon.

2.3 — Install FotoStation Easy

The splashscreen below appears, showing that you are now installing FotoStation Easy. Click **Continue** and follow the rest of the on-screen instructions to complete the installation.



The dialog box below will appear indicating that the installation is complete. Click **OK** to complete the installation.



2.4 — Installing QuickTime 5.0.2


The **Welcome to QuickTime** dialog box appears, showing that you are now installing QuickTime 5. Click **Continue**.



The QuickTime 5 license will appear. Read the license carefully. If you accept the terms of the license and wish to continue with the installation, click **Agree**.



The **Choose Installation Type** dialog box will be displayed. Select **Recommended** and click **Continue**.



The Registration dialog box will be displayed. Leave the entry fields blank and click **Continue**.



When the installation is complete the dialog box shown below will be displayed. Click **Restart** to end the installation and restart your computer. When your computer restarts, the QuickTime settings dialog box will be displayed. For information on QuickTime settings, refer to the instructions provided with the software.

