


[AD]

?


SCHEMATIC TERRORIST

?????????? ????}?? connections Panasonic



Pin	Name	Function	in / ou
1		GND	
2		TX AUDIO	
3		AUDIO GND	
4		HF ON (L=ON)	
5		AOP SENSE (DATA ADAPTOR SELECT)	
6		SERIAL UP (UART UP - 9600 bps)	
7		SERIAL DOWN (UART DOWN)	
8		CHARGE	
9		GND	
10		RX AUDIO	
11		RADIO MUTE (L=MUTE)	
12		HF SENSE (L=HF MODE)	
13		FLASH (L=WRITE ENABLE)	
14		IGNITION (H=ON)	
15		LOGIC PWR (H=HANDSET ON)	
16		PAON (POWER AMP. CONTROL SIGNAL)	

Panasonic Interface G450 G500 G520 G600 by Misiek





?????????? and a cable of connection Panasonic GD-70 GD-90



Pin	Name	Function	in / ou
1		GND	
2		PA_ON	
3		nLOGIC_PWR	
4		IGNITION	
5		VBAT	
6		NHF_SENSE	
7		NRADIO_MUTE	
8		RX_AUDIO	
9		NC	
10		EXT_POWER	
11		NON_HOOK	
12		SERIAL_OUT	
13		SERIAL_IN	
14		NADP_SENSE	
15		nHF_ON	
16		GND	
17		TX_AUDIO	
18		GND	



Panasonic GD35/52/92/93 serial interface



Phone - Keyboard is UP

GD52/92/93 connector

- 1 AGND
- 5 ACC
- 8 Tx
- 7 Rx
- 14 GND



??????? ?????????



Schematic

[\[AD\]](#)

