



NOTE:  
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC  
DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE  
REFER TO PARTS LIST.

NOTE:  
THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS  
DIAGRAM IS STOP MODE.

TO  
FRONT-B  
FP441

6	3V
5	AWT OUT
4	FLICK
3	AWT L2
2	D GND
1	AF/MF

TO  
FP4904

1

2

3

4