

➡:VIDEO SIGNAL


E

D

C

B

A



TO
CAMERA SUB
PS201

26	V3 RB
25	V4 RB
24	SIG B
23	A GND(B)
22	SUB B
21	15V
20	SIG R
19	A GND(RG)
18	A GND(RG)
17	SIG G
16	-8V
15	V3 G
14	V4 G
13	V1 G
12	V2 G
11	R
10	SUB G
9	H2 G
8	H1 G
7	H2 B
6	H1 B
5	H2 R
4	H1 R
3	SUB R
2	V1 RB
1	V2 RB

TO
PP101

NOTE:
DO NOT USE ANY PART NUMBER
SHOWN ON THIS SCHEMATIC
DIAGRAM FOR ORDERING.WHEN
YOU ORDER A PART,PLEASE
REFER TO PARTS LIST.

NOTE:
THE MEASUREMENT MODE OF
THE DC VOLTAGE ON THIS
DIAGRAM IS REC MODE.