


A

TO HOT SHOE
JS1001

SHOE GND	1
_____	2
_____	3
_____	4
SHOE DET	5
SHOE SCLK	6
SHOE SDATA	7
SHOE UNREG	8

CARD DOOR OPEN

S4051
K0L1BB000022TO
POWER

1	MMC DET
2	SHOE GND
3	SHOE GND
4	SHOE GND
5	SHOE DET
6	SHOE SCLK
7	SHOE SDATA
8	SHOE UNREG
9	SHOE UNREG
10	SHOE UNREG

TO
FP1004

NOTE:
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC
DIAGRAM FOR ORDERING. WHEN YOU ORDER A PART, PLEASE
REFER TO PARTS LIST.

1

2

3

4