

LanSafe III

Supported Operating Systems

February 12, 2003 / MX

Non-UNIX Operating Systems Supported by LanSafe III (LS3)

Operating System	Supported By	Operating System Requirements
IBM OS/2 v. 3.0 - 4.0	LS3 v. 4.14	Any OS/2 compatible with OS/2 v. 3.0 - 4.0
Novell NetWare 4.11, 5.0, 5.1, 6	LS3 v. 4.1	386/486/Pentium or compatible
Windows 2000	LS3 v. 4.16.x -	Pentium PC with network services installed
Windows 9x	LS3 v. 4.16.x -	386/486/Pentium PC
Windows Me	LS3 v. 4.16.x -	486/Pentium PC with network services installed
Windows NT 3.5x-4.0 (<i>Alpha</i>)	LS3 v. 4.15-4.16.x	Computer with Alpha processor
Windows NT 4.0 (<i>intel</i>)	LS3 v. 4.1x -	486/Pentium PC with network services installed
Windows XP	LS3 v. 4.16.3 -	Pentium PC with network services installed

Unix Operating Systems Supported by LanSafe III (LS3)

Operating System	Supported By	Operating System Requirements
AT&T Unix SV R4 v. 3.0, 4.4 (<i>Unisys</i>)	LS3 v. 4.1x	386/486/Pentium PC
Data General DG-UX R4.2MU01 or higher (<i>Intel</i>)	LS3 v. 4.1x -	Character based UI or GUI-X Window v.11R4 or higher
Compaq Tru64 v. 4.x, 5.x	LS3 v. 4.16 -	Alpha processor, character-based UI or CDE
Digital Unix v. 4.x (<i>Alpha</i>)	LS3 v. 4.1x	Alpha processor, character-based UI or CDE
HP-UX v. 10.10, 10.20, 11.00, 11.11	LS3 v. 4.1x	HP9000/xxx Series, character-based UI or Vue
IBM AIX v. 4.x, 5.1 (<i>RISC</i>)	LS3 v. 4.16.x -	IBM RS/6000, character-based UI or AIX-Windows
IBM AIX v. 4.x, 5.1 (<i>PowerPC</i>)	LS3 v. 4.16.x -	IBM PowerPC, character-based UI or AIX-Windows
Interactive Unix v. 3.0.1 – 3.2.2,3.7.2	LS3 v. 3.72	Character-based UI or Looking Glass
Linux Redhat v. 6.2, 7.x, 8 SuSE v. 8	LS3 v. 4.17.3a	Character-based UI or GUI-X Window
SCO Unix, OpenServer v. 5.x	LS3 v. 4.1x -	Character-based UI or GUI-X Window v.11R4 or higher
SGI IRIX v. 6.5 w/ MIPS	LS3 v. 4.16 -	Character-based UI or GUI-X Window
Solaris v. 2.x with SunOS v. 5.x, (<i>SPARC</i>)	LS3 v. 4.1x	Character-based UI or GUI-X Window v.11R4 or higher
Solaris v. 2.6 with SunOS v. 5.6, 7, 8 (<i>Intel</i>)	LS3 v. 4.17.1a	Character-based UI or GUI-X Window v.11R4 or higher
UnixWare v. 7.1	LS3 v. 4.1x -	Character-based UI or Destiny