

AD370/AD380
(G529/G582)

AD370/AD380 (G529/G582)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1.DUPLEX UNIT 1 (G529/G582)	2
2.DUPLEX UNIT 2 (G529/G582)	4
3.DUPLEX UNIT 3 (G529/G582)	6
PARTS INDEX	9

September ,30 ' 2000

1.DUPLEX UNIT 1 (G529/G582)




1.DUPLEX UNIT 1 (G529/G582)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A896 4760	Inner Cover Front	1
2	A896 4765	Decal Misfeed Removal	1
3	A896 1320	Cover Holder Rear	1
4	A896 1050	Holder	1
5	A896 1310	Cover Holder Front	1
6	A896 1330	Cover Holder Middle	1
7	A896 4800	Bracket Link	1
8	A896 4770	Inner Cover Rear	1
9	AA06 2306	Pressure Spring	3
10	AA08 0307	Bushing - M4	3
11	AF02 0464	Driven Transport Roller	3
12	A232 4653	Pressure Plate - Guide Plate	2
13	A896 4781	Decal Grip Upper	1
14	A896 4651	Exchange Powl	1
15	A896 4655	Guide Plate Driven	1
16	A896 4755	Decal Duplex Unit Upper	1
17	AA06 0709	Tension Spring	1
18	A896 4750	Cover Duplex Unit	1
19	A896 1120	Allen Key 2.5	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0804 6114	Hexagon Set Screw - M4x12.5	
102	0451 3006B	Tapping Screw - M3x6	
103	0720 0030E	Retaining Ring - M3	
104	0451 3008H	Tapping Screw - 3x8	
105	0804 6113	Hexagonal Set Screw - M3x8	

2.DUPLEX UNIT 2 (G529/G582)




2.DUPLEX UNIT 2 (G529/G582)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A896 4684	Grip Unlock	1
2	AA08 2074	Bushing - M8	2
3	A896 4647	Guide Plate Middle	1
4	A896 4782	Decal Grip Lower	1
5	AF02 0465	Reverse Roller	1
6	A232 4657	Inverter Roller	2
7	AA06 2306	Pressure Spring	2
8	AA08 0307	Bushing - M4	2
9	AF02 0464	Driven Transport Roller	1
10	A896 4620	Guide Plate Entrance	1
11	AA16 2046	Cushion - 347x10x5	1
12	AA06 2307	Tension Spring	1
13	AW01 0048	Photo Sensor - GP2A28N1	1
14	A896 4725	Bracket Entrance Sensor	1
15	A896 4686	Pawl Un Lock	1
16	AB01 4053	Gear - 30Z	1
17	A896 4717	Link DC Solenoid (G529)	1
17	G582 4717	Link DC Solenoid (G582)	1
18	A232 4665	DC Motor - 17W	1
19	A896 4675	Bracket Stepper Motor Reverse	1
20	AB01 7456	Gear - 20Z	1
21	AB01 7455	Gear - 21Z/35Z	1
22	AA04 3520	Timing Belt - S2M120	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0720 0060E	Retaining Ring - M6	
102	0802 5265	Tapping Screw - M3X6	
103	0313 0060B	Philips Pan Head Screw - M3x6	
104	0720 0030E	Retaining Ring - M3	
105	1105 0328	Harness Clamp - ES-0505	
106	1105 0229	Clamp	
107	0720 0040E	Retaining Ring - M4	

3.DUPLEX UNIT 3 (G529/G582)



3.DUPLEX UNIT 3 (G529/G582)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A896 4625	Side Plate Front	1
2	AA08 2075	Bushing - M6	2
3	AB03 0569	Pulley - 30T	2
4	AA04 3521	Timing Belt - S2M260	2
5	AF02 0466	Transport Roller	3
6	A896 4617	Cover Stay Lower Front	1
7	A896 4645	Guide Plate Duplex	1
8	AW50 0022	Push Switch	1
9	A896 4632	Side Plate Rear	1
10	AB01 1088	Gear - 30Z	1
11	AA06 6582	Tension Spring	1
12	A896 4692	Link Duplex	1
13	A896 4691	Cover Link	1
14	5447 2681	Snap Ring	1
15	G529 5150	PCB - DCU - RP2	1
16	A896 5256	Sensor Harness	1
17	G529 5254	Duplex Unit Harness	1
18	A896 4715	Base Bracket	1
19	A232 4665	DC Motor - 17W	1
20	A896 4681	Bracket Stepper Motor Feed	1
21	AB01 7457	Gear Pulley - 20Z/40T	1
22	AA04 3520	Timing Belt - S2M120	1
23	A896 4618	Cover Stay Lower Rear	1
24	AW02 0102	Photointerruptor	1
25	A232 4757	Bracket - Feed Sensor	1
26	AA12 0100	Discharge Brush - Front	1
27	AA12 0101	Discharge Brush - Rear	1
28	A896 4612	Stay Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	
103	1105 0229	Clamp	
104	0802 5265	Tapping Screw - M3X6	
105	1105 0328	Harness Clamp - ES-0505	
106	1105 0291	Harness Clamp - LWS-3S	
107	0805 3480	Bushing - 6mm	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G529 5150	PCB - DCU - RP2	7- 15
G529 5254	Duplex Unit Harness	7- 17
G582 4717	Link DC Solenoid (G582)	5- 17

Part No.	Description	Page and Index No.
AA04 3520	Timing Belt - S2M120	7- 22
AA04 3520	Timing Belt - S2M120	5- 22
AA04 3521	Timing Belt - S2M260	7- 4
AA06 0709	Tension Spring	3- 17
AA06 2306	Pressure Spring	3- 9
AA06 2306	Pressure Spring	5- 7
AA06 2307	Tension Spring	5- 12
AA06 6582	Tension Spring	7- 11
AA08 0307	Bushing - M4	3- 10
AA08 0307	Bushing - M4	5- 8
AA08 2074	Bushing - M8	5- 2
AA08 2075	Bushing - M6	7- 2
AA12 0100	Discharge Brush - Front	7- 26
AA12 0101	Discharge Brush - Rear	7- 27
AA16 2046	Cushion - 347x10x5	5- 11
AB01 1088	Gear - 30Z	7- 10
AB01 4053	Gear - 30Z	5- 16
AB01 7455	Gear - 21Z/35Z	5- 21
AB01 7456	Gear - 20Z	5- 20
AB01 7457	Gear Pulley - 20Z/40T	7- 21
AB03 0569	Pulley - 30T	7- 3
AF02 0464	Driven Transport Roller	5- 9
AF02 0464	Driven Transport Roller	3- 11
AF02 0465	Reverse Roller	5- 5
AF02 0466	Transport Roller	7- 5
AW01 0048	Photo Sensor - GP2A28N1	5- 13
AW02 0102	Photointerruptor	7- 24
AW50 0022	Push Switch	7- 8

Part No.	Description	Page and Index No.
A232 4653	Presuure Plate - Guide Plate	3- 12
A232 4657	Inverter Roller	5- 6
A232 4665	DC Motor - 17W	7- 19
A232 4665	DC Motor - 17W	5- 18
A232 4757	Bracket - Feed Sensor	7- 25
A896 1050	Holder	3- 4
A896 1120	Allen Key 2.5	3- 19
A896 1310	Cover Holder Front	3- 5
A896 1320	Cover Holder Rear	3- 3
A896 1330	Cover Holder Middle	3- 6
A896 4612	Stay Lower	7- 28
A896 4617	Cover Stay Lower Rront	7- 6
A896 4618	Cover Stay Lower Rear	7- 23
A896 4620	Guide Plate Entrance	5- 10
A896 4625	Side Plate Front	7- 1
A896 4632	Side Plate Rear	7- 9
A896 4645	Guide Plate Duplex	7- 7
A896 4647	Guide Plate Middle	5- 3
A896 4651	Exchange Powl	3- 14
A896 4655	Guide Plate Driven	3- 15
A896 4675	Bracket Stepper Motor Reverse	5- 19
A896 4681	Bracket Stepper Motor Feed	7- 20
A896 4684	Grip Unlock	5- 1
A896 4686	Pawl Un Lock	5- 15
A896 4691	Cover Link	7- 13
A896 4692	Link Duplex	7- 12
A896 4715	Base Bracket	7- 18
A896 4717	Link DC Solenoid (G529)	5- 17
A896 4725	Bracket Entrance Sensor	5- 14
A896 4750	Cover Duplex Unit	3- 18
A896 4755	Decal Duplex Unit Upper	3- 16
A896 4760	Inner Cover Front	3- 1
A896 4765	Decal Misfeed Removal	3- 2
A896 4770	Inner Cover Rear	3- 8
A896 4781	Decal Grip Upper	3- 13

Part No.	Description	Page and Index No.
A896 4782	Decal Grip Lower	5- 4
A896 4800	Bracket Link	3- 7
A896 5256	Sensor Harness	7- 16

Part No.	Description	Page and Index No.
5447 2681	Snap Ring	7- 14

Part No.	Description	Page and Index No.
0313 0060B	Philips Pan Head Screw - M3x6	5-103
0451 3006B	Tapping Screw - M3x6	3-102
0451 3008B	Tapping Screw - M3x8	7-101
0451 3008H	Tapping Screw - 3x8	3-104
0720 0030E	Retaining Ring - M3	3-103
0720 0030E	Retaining Ring - M3	5-104
0720 0040E	Retaining Ring - M4	7-102
0720 0040E	Retaining Ring - M4	5-107
0720 0060E	Retaining Ring - M6	5-101
0802 5265	Tapping Screw - M3X6	5-102
0802 5265	Tapping Screw - M3X6	7-104
0804 6113	Hexagonal Set Screw - M3x8	3-105
0804 6114	Hexagon Set Screw - M4x12.5	3-101
0805 3480	Bushing - 6mm	7-107
1105 0229	Clamp	7-103
1105 0229	Clamp	5-106
1105 0291	Harness Clamp - LWS-3S	7-106
1105 0328	Harness Clamp - ES-0505	7-105
1105 0328	Harness Clamp - ES-0505	5-105