

Printer/Scanner Unit Type 2045 (B548)

Printer/Scanner Unit Type 2045 (B548)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.PRINTER SCANNER UNIT (B548)	2
PARTS INDEX	5

March ,30 ' 2003

1.PRINTER SCANNER UNIT (B548)



1.PRINTER SCANNER UNIT (B548)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B548 6359	Keytop:Scanner:NA	1
1	B548 6369	Keytop:Scanner:EU	1
2	B548 6358	Keytop:Printer:NA	1
2	B548 6368	Keytop:Printer:EU	1
3	B080 4492	Cover:Surface Of Paper Sensor	1
4	B080 4493	Bracket:Surface Of Paper Sensor	1
5	B007 4497	Bracket:Plate:Feeler	1
6	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
7	A235 4496	Sensor Actuator	1
8	A235 5410	Relay Sensor Harness	1
9	B053 5166	Network Interface Board	1
10	B548 8617	Operation Instructions:Printer/Scanner	1
11	B548 5117	PCB:DIMM:PRT/SCN:EXP:ASS'Y	1
12	B051 5885	Nib Bracket	1
13	A855 5200	Ferrite Core	1
14	AW01 0048	Photosensor - GP2A28N1	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0452 3008Z	Bind Tapping Screw - M3x8	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B548 5117	PCB:DIMM:PRT/SCN:EXP:ASS'Y	3 - 11
B548 6358	Keytop:Printer:NA	3 - 2
B548 6359	Keytop:Scanner:NA	3 - 1
B548 6368	Keytop:Printer:EU	3 - 2
B548 6369	Keytop:Scanner:EU	3 - 1
B548 8617	Operation Instructions:Printer/Scanner	3 - 10

Part No.	Description	Page and Index No.
A235 4496	Sensor Actuator	3 - 7
A235 5410	Relay Sensor Harness	3 - 8
A855 5200	Ferrite Core	3 - 13
B007 4497	Bracket:Plate:Feeler	3 - 5
B051 5885	Nib Bracket	3 - 12
B053 5166	Network Interface Board	3 - 9
B080 4492	Cover:Surface Of Paper Sensor	3 - 3
B080 4493	Bracket:Surface Of Paper Sensor	3 - 4

