

Adjustment Table Type 1232 (B488)

This parts catalog includes MB No. 1

Adjustment Table Type 1232 (B488)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Adjustment Table (B488).....	2
PARTS INDEX	5

April ,6 ' 2005

1.Adjustment Table (B488)



1.Adjustment Table (B488)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AH01 2032 B408 1312	Caster:392N o/o MB1	4
2	B488 1211	Grounding Plate Bracket	1
3	B302 1163	Grounding Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0802 5276	Tapping Screw - M3x6	
102	0453 3006B	Tapping Screw - M3x6	
103	0450 3010B	Tapping Screw - M3x10	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B488 1211	Grounding Plate Bracket	3 - 2

Part No.	Description	Page and Index No.
B302 1163	Grounding Plate	3 - 3
B408 1312	o/o MB1	3 - 1

Part No.	Description	Page and Index No.
AH01 2032	Caster:392N	3 - 1

Part No.	Description	Page and Index No.
0450 3010B	Tapping Screw - M3x10	3 -103
0453 3006B	Tapping Screw - M3x6	3 -102
0802 5276	Tapping Screw - M3x6	3 -101