

Bridge Unit Type 270/320
(A897/G583)

Bridge Unit Type 270/320 (A897/G583)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1.BRIDGE UNIT 1 (A897/G583).....	2
2.BRIDGE UNIT 2 (A897/G583).....	4
3.BRIDGE UNIT 3 (A897/G583).....	6
PARTS INDEX.....	9

September ,30 ' 2000

1.BRIDGE UNIT 1 (A897/G583)




1.BRIDGE UNIT 1 (A897/G583)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A897 6259	Joint Stay - Base Unit	1
2	AA12 0094	Antistatic Brush	1
3	A897 6266	Cover Transport Left	1
4	G020 1327	Knob Screw - M3	1
5	A897 6268	Cover Rear	1
6	A897 6267	Cover Left Upper Rear	1
7	AF04 0558	Driven Roller	8
8	A897 6292	Spring Plate Pressure	12
9	A897 6261	Cover Transport Ass'y	1
10	A897 6351	Cover Exit Upper	1
11	AA02 1030	Magnet Catch	2
12	AA12 0089	Antistatic Brush	1
13	A897 6318	Pin Side Plate	1
14	AA14 0708	Driven Shaft - Exit Roller	1
15	AF04 0565	Driven Exit Roller	2
16	AA06 3596	Compression Spring - Exit Roller	2
17	A897 6356	Cover Exit Left	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0451 3008H	Tapping Screw - 3x8	

2.BRIDGE UNIT 2 (A897/G583)




2.BRIDGE UNIT 2 (A897/G583)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A897 6341	DC Solenoid	1
2	A897 5275	Exit Harness - Joint Unit	1
3	AB01 7500	Idler Pulley Gear	1
4	AB01 7498	Right Gear Pulley	1
5	AA04 3518	Timing Belt - S2M210	1
6	5447 2681	Snap Ring	2
7	AB03 0631	Upper Pulley - Exit Roller	1
8	A897 6311	Side Plate Rear	1
9	A897 6325	Guide Plate Exit	1
10	AF02 0468	Exit Roller	1
11	A897 6331	Gate Pawl	1
12	AA06 6583	Gate Pawl Spring	1
13	AW02 0098	Photosensor	1
14	A897 6323	Guide Plate Upper	1
15	AF02 0469	Right Transport Roller	1
16	A897 6321	Guuide Plate Lower	1
17	A897 6316	Side Plate Front	1
18	A897 6318	Pin Side Plate	1
19	A897 6344	Lever Solenoid	1
20	A897 6342	Bracket DC Solenoid	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0040E	Retaining Ring - M4	
103	0805 3385	Bushing - 6mm	
104	0805 3480	Bushing - 6mm	
105	0802 5276	Tapping Screw With Waser - M3x6	
106	1105 0328	Harness Clamp - ES-0505	
107	1105 0283	Clamp	
108	0313 0040B	Philips Pan Head Screw - M3x4	

3.BRIDGE UNIT 3 (A897/G583)



3.BRIDGE UNIT 3 (A897/G583)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A897 6253	Sheet Base	1
2	A688 3913	Support Plate	1
3	A897 5279	Harness	1
4	A897 6286	Bracket Connector	1
5	A897 6283	Bracket Motor	1
6	AB01 1401	Motor Gear 2	1
7	AB01 7501	Motor Gear 1	1
8	A897 5288	Relay Harness (A897)	1
8	G853 5288	Relay Harness (G583)	1
9	A897 6282	Motor - DC6W (A897)	1
9	G583 6282	Motor - DC6W (G583)	1
10	AA04 3519	Timing Belt - S2M 250	2
11	AA04 3518	Timing Belt - S2M210	1
12	AB01 7499	Exit Roller Pulley	1
13	AB03 0632	Transport Roller Pulley	2
14	AF02 0471	Lower Exit Roller	1
15	AF02 0470	Middle Transport Roller	2
16	AF04 0558	Driven Roller	4
17	A897 6291	Spring Plate Pressure Right	8
18	AA02 1030	Magnet Catch	2
19	G020 5626	Push Switch	2
20	A897 6251	Joint Unit Base	1
21	A897 6256	Bracket Fan	1
22	AX64 0085	Fan Motor - DC 1.68W	1
23	G020 4472	Paper Feed Sensor	1
24	A897 5170	TKB Board	1
25	A897 5271	Detector Harness	1
26	A897 5273	Main Harness	1
27	A897 6288	Cover TKB Board	1
28	A897 6252	Sheet Guide Exit Lower	2
29	A897 5268	Ground Wire Harness	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0720 0040E	Retaining Ring - M4	
103	0451 3006B	Tapping Screw - M3x6	
104	0451 3008H	Tapping Screw - 3x8	
105	1102 7672	Connector - 54111-1615	
106	1105 0334	Edge - 17	
107	1105 0310	Harness Clamp - LWS-1S	
108	0314 0080B	Philips Pan Head Screw - M4x8	
109	0805 3480	Bushing - 6mm	
110	0313 0220B	Philips Pan Head Screw - M3x22	
111	1607 0623	Ferrite Core - Tfc-16-8-13	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
A897 5170	TKB Board	7- 24
A897 5268	Ground Wire Harness	7- 29
A897 5271	Detector Harness	7- 25
A897 5273	Main Harness	7- 26
A897 5275	Exit Harness - Joint Unit	5- 2
A897 5279	Harness	7- 3
A897 5288	Relay Harness (A897)	7- 8
A897 6251	Joint Unit Base	7- 20
A897 6252	Sheet Guide Exit Lower	7- 28
A897 6253	Sheet Base	7- 1
A897 6256	Bracket Fan	7- 21
A897 6259	Joint Stay - Base Unit	3- 1
A897 6261	Cover Transport Ass'y	3- 9
A897 6266	Cover Transport Left	3- 3
A897 6267	Cover Left Upper Rear	3- 6
A897 6268	Cover Rear	3- 5
A897 6282	Motor - DC6W (A897)	7- 9
A897 6283	Bracket Motor	7- 5
A897 6286	Bracket Connector	7- 4
A897 6288	Cover TKB Board	7- 27
A897 6291	Spring Plate Pressure Right	7- 17
A897 6292	Spring Plate Pressure	3- 8
A897 6311	Side Plate Rear	5- 8
A897 6316	Side Plate Front	5- 17
A897 6318	Pin Side Plate	5- 18
A897 6318	Pin Side Plate	3- 13
A897 6321	Guide Plate Lower	5- 16
A897 6323	Guide Plate Upper	5- 14
A897 6325	Guide Plate Exit	5- 9
A897 6331	Gate Pawl	5- 11
A897 6341	DC Solenoid	5- 1
A897 6342	Bracket DC Solenoid	5- 20
A897 6344	Lever Solenoid	5- 19
A897 6351	Cover Exit Upper	3- 10
A897 6356	Cover Exit Left	3- 17

Part No.	Description	Page and Index No.
AA02 1030	Magnet Catch	7- 18
AA02 1030	Magnet Catch	3- 11
AA04 3518	Timing Belt - S2M210	5- 5
AA04 3518	Timing Belt - S2M210	7- 11
AA04 3519	Timing Belt - S2M 250	7- 10
AA06 3596	Compression Spring - Exit Roller	3- 16
AA06 6583	Gate Pawl Spring	5- 12
AA12 0089	Antistatic Brush	3- 12
AA12 0094	Antistatic Brush	3- 2
AA14 0708	Driven Shaft - Exit Roller	3- 14
AB01 1401	Motor Gear 2	7- 6
AB01 7498	Right Gear Pulley	5- 4
AB01 7499	Exit Roller Pulley	7- 12
AB01 7500	Idler Pulley Gear	5- 3
AB01 7501	Motor Gear 1	7- 7
AB03 0631	Upper Pulley - Exit Roller	5- 7
AB03 0632	Transport Roller Pulley	7- 13
AF02 0468	Exit Roller	5- 10
AF02 0469	Right Transport Roller	5- 15
AF02 0470	Middle Transport Roller	7- 15
AF02 0471	Lower Exit Roller	7- 14
AF04 0558	Driven Roller	3- 7
AF04 0558	Driven Roller	7- 16
AF04 0565	Driven Exit Roller	3- 15
AW02 0098	Photosensor	5- 13
AX64 0085	Fan Motor - DC 1.68W	7- 22
G020 1327	Knob Screw - M3	3- 4
G020 4472	Paper Feed Sensor	7- 23
G020 5626	Push Switch	7- 19
G583 6282	Motor - DC6W (G583)	7- 9
G853 5288	Relay Harness (G583)	7- 8

Part No.	Description	Page and Index No.
0313 0040B	Philips Pan Head Screw - M3x4	5-108
0313 0220B	Philips Pan Head Screw - M3x22	7-110
0314 0080B	Philips Pan Head Screw - M4x8	7-108
0450 3008B	Tapping Screw - M3x8	7-101
0450 3008B	Tapping Screw - M3x8	3-101
0451 3006B	Tapping Screw - M3x6	7-103
0451 3006B	Tapping Screw - M3x6	5-101
0451 3008H	Tapping Screw - 3x8	7-104
0451 3008H	Tapping Screw - 3x8	3-102
0720 0040E	Retaining Ring - M4	5-102
0720 0040E	Retaining Ring - M4	7-102
0802 5276	Tapping Screw With Waser - M3x6	5-105
0805 3385	Bushing - 6mm	5-103
0805 3480	Bushing - 6mm	5-104
0805 3480	Bushing - 6mm	7-109
1102 7672	Connector - 54111-1615	7-105
1105 0283	Clamp	5-107
1105 0310	Harness Clamp - LWS-1S	7-107
1105 0328	Harness Clamp - ES-0505	5-106
1105 0334	Edge - 17	7-106
1607 0623	Ferrite Core - Tfc-16-8-13	7-111

Part No.	Description	Page and Index No.