

Controller Interface Type E (A848)

PARTS CATALOG


INTRODUCTION

This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

1.Controller Interface Type E (A848)	2
PARTS INDEX	5

1.Controller Interface Type E (A848)



1.Controller Interface Type E (A848)



Index No.	Part No.	Description	Q'ty Per Assembly
1	A848 1251	Controller Cover	1
2	A848 5877	Seal - UU300286-165	1
3	A848 5834	Rear Upper Frame	1
4	A848 5871	PSU Front Cover	1
5	A848 5808	Upper Front Frame	1
6	G011 1058	Snap Ring	1
7	A848 5866	Shielding Plate	1
8	A848 1046	Interface Unit Bracket	1
9	A848 5108	BUSSW Board	1
10	A848 5217	VIDEO-MB I/F Harness	1
11	A848 5220	Interface Harness - Main MB	1
12	A848 5212	DC Power Supply Harness	1
13	A848 5300	Power Supply Unit - 120V	1
13	A848 5310	Power Supply Unit 230V 54W	1
14	A848 5848	Power Supply Unit Cover	1
15	A848 5221	AC Harness	1
16	A848 5219	Display Harness	1
17	A848 1451	Operation Panel - NA	1
17	A848 1452	Operation Panel - EU	1
18	A848 1256	Seal	1
19	A848 5878	Guide Plate	1
20	A848 5879	Grounding Plate	1
21	A848 5860	Harness Shield Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3X6	
102	0451 4006H	Tapping Screw - M4X6	
103	0451 4006B	Tapping Screw - 4X6	
104	1105 0291	Harness Clamp - LWS-3S	
105	1105 0329	Clamp - ES-0510	
106	0954 4008Z	Double Sens Screw - M4X8	
107	0954 3006Z	Screw - M3X6	
108	1105 0352	Clamp	

PARTS INDEX

Part No.	Description	Page and Index No.
A848 1046	Interface Unit Bracket	3- 8
A848 1251	Controller Cover	3- 1
A848 1256	Seal	3- 18
A848 1451	Operation Panel - NA	3- 17
A848 1452	Operation Panel - EU	3- 17
A848 5108	BUSSW Board	3- 9
A848 5212	DC Power Supply Harness	3- 12
A848 5217	VIDEO-MB I/F Harness	3- 10
A848 5219	Display Harness	3- 16
A848 5220	Interface Harness - Main MB	3- 11
A848 5221	AC Harness	3- 15
A848 5300	Power Supply Unit - 120V	3- 13
A848 5310	Power Supply Unit 230V 54W	3- 13
A848 5808	Upper Front Frame	3- 5
A848 5834	Rear Upper Frame	3- 3
A848 5848	Power Supply Unit Cover	3- 14
A848 5860	Harness Shield Plate	3- 21
A848 5866	Shielding Plate	3- 7
A848 5871	PSU Front Cover	3- 4
A848 5877	Seal - UU300286-165	3- 2
A848 5878	Guide Plate	3- 19
A848 5879	Grounding Plate	3- 20

Part No.	Description	Page and Index No
G011 1058	Snap Ring	3- 6

Part No.	Description	Page and Index No.
0451 3006B	Tapping Screw - M3X6	3-101
0451 4006B	Tapping Screw - 4X6	3-103
0451 4006H	Tapping Screw - M4X6	3-102
0954 3006Z	Screw - M3X6	3-107
0954 4008Z	Double Sens Screw - M4X8	3-106
1105 0291	Harness Clamp - LWS-3S	3-104
1105 0329	Clamp - ES-0510	3-105
1105 0352	Clamp	3-108

Part No.	Description	Page and Index No