

# **DF40 (A365)**

**This parts catalog includes MB No 1 to 6.**

# PARTS CATALOG





## INTRODUCTION

This chapter instructs you the numbers and names of this parts on this machine.


## INDEX to PARTS CATALOG

|                                            |    |
|--------------------------------------------|----|
| <b>Location of Unit</b> .....              | 3  |
| 1. Exterior 1 (A365) .....                 | 4  |
| 2. Exterior 2 (A365) .....                 | 6  |
| 3. Feed-in Section (A365) .....            | 8  |
| 4. Transport and Exit Section (A365) ..... | 10 |
| 5. DF Main Board (A365) .....              | 12 |
| <b>PartS Index</b> .....                   | 15 |

LOCATION OF UNIT


|                                                                                                                                                                   |                                                                                                                                                     |                                                                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>1. EXTERIOR 1 (A365)</div> <div></div> <div>See Page 4</div>                | <div>2. EXTERIOR 2 (A365)</div> <div></div> <div>See Page 6</div> | <div>3. FEED-IN SECTION (A365)</div> <div></div> <div>See Page 8</div> |
| <div>TRANSPORT AND EXIT SECTION (A365)</div> <div></div> <div>See Page 10</div> |                                                                                                                                                     |                                                                                                                                                           |

# 1. EXTERIOR 1 (A365)





## 2. EXTERIOR 2 (A365)




## 2. EXTERIOR 2 (A365)

| Index No. | Part No.  | Description                 | Q'ty Per Assembly |
|-----------|-----------|-----------------------------|-------------------|
| 1         | A365 1330 | Grip Cover                  | 1                 |
| 2         | A365 1217 | Paper Exit Guide            | 1                 |
| 3         | A365 1222 | Exit Support Roller         | 2                 |
| 4         | A365 1221 | Support Roller Shaft        | 1                 |
| 5         | A365 1070 | Paper Feed Guide            | 1                 |
| 6         | A365 1410 | Right Hinge                 | 1                 |
| 7         | A365 1584 | Transformer Cover           | 1                 |
| 8         | A365 1482 | Grounding Bracket           | 1                 |
| 9         | A365 5335 | Registration Sensor         | 1                 |
| 10        | A365 5231 | Power Supply Harness - 115V | 1                 |
| 10        | A365 5232 | Power Supply Harness - 220V | 1                 |
| 11        | A365 2030 | Decal - Mode                | 1                 |
| 12        | A365 1400 | Left Hinge                  | 1                 |
| 13        | A365 1479 | Lift Switch Actuator        | 1                 |
| 14        | G648 5320 | Microswitch                 | 1                 |
| 15        | A365 1583 | Main Board Cover            | 1                 |
| 16        | A365 1582 | Main Motor Cover            | 1                 |
| 17        | 5875 2088 | Shoulder Screw- M4          | 3                 |

| Index No. | Part No.   | Description                               | Q'ty Per Assembly |
|-----------|------------|-------------------------------------------|-------------------|
| 101       | 0344 0060W | Philips Truss Head Screw- M4x6            |                   |
| 102       | 1106 0713  | Cable Holder                              |                   |
| 103       | 0314 0060W | Philips Pan Head Screw - M4x6             |                   |
| 104       | 0252 0080W | Screw - M2x8                              |                   |
| 105       | 0801 0137  | Philips Pan Head Screw With Spring - M4x6 |                   |
| 106       | 0801 1185  | Philips Truss Head Screw - M4x8           |                   |

### 3. FEED-IN SECTION (A365)





### 3. FEED-IN SECTION (A365)


| Index No. | Part No.  | Description                  | Q'ty Per Assembly |
|-----------|-----------|------------------------------|-------------------|
| 1         | A365 1051 | Timing Belt - 122XL          | 3                 |
| 2         | A365 1045 | Pick-up Pulley - Large       | 1                 |
| 3         | A365 1046 | Pick-up Pulley - Small       | 1                 |
| 4         | A365 1018 | Gear - 20Z                   | 1                 |
| 5         | A365 1001 | Rear Side Plate              | 1                 |
| 6         | A365 5010 | DF Main Board                | 1                 |
| 7         | A365 5181 | Transformer - 115V           | 1                 |
| 7         | A365 5182 | Transformer - 220V           | 1                 |
| 8         | A365 1315 | Transformer Bracket          | 1                 |
| 9         | A300 5621 | Optical Fiber Harness        | 1                 |
| 10        | A365 5221 | Encoder Harness              | 1                 |
| 11        | A365 1026 | Feed Roller Shaft            | 1                 |
| 12        | 5940 1088 | Upper Relay Feed Roller      | 6                 |
| 13        | A365 1027 | Feed Roller                  | 1                 |
| 14        | A365 1055 | Set Sensor Bracket .         | 1                 |
| 15        | A365 5338 | Original Set Sensor          | 1                 |
| 16        | A365 5260 | Jam Indicator Ass'y          | 1                 |
| 17        | A365 5090 | Main Motor - DC 9W           | 1                 |
| 18        | A365 1024 | Timing Belt - 122XL - Orange | 1                 |
| 19        | 5053 0447 | Bushing - 6mm                | 6                 |
| 20        | A365 1040 | Pick-up Roller               | 1                 |
| 21        | A365 1011 | Gear - 18/40Z                | 2                 |
| 22        | A365 1005 | Photointerruptor Bracket     | 1                 |
| 23        | 5443 2713 | Wave Washer                  | 1                 |
| 24        | A365 1012 | Gear-40Z                     | 1                 |
| 25        | A365 1010 | Gear-20Z                     | 1                 |
| 26        | A365 1085 | Cushion-3x6x10               | 1                 |
| 27        | A365 5324 | Pick-up Solenoid             | 1                 |
| 28        | AW02 0041 | Photointerruptor             | 1                 |
|           | A099 5520 | o/o MB 5                     |                   |
| 29        | A365 1032 | Pulse Generator              | 1                 |
| 30        | A365 1029 | Pulse Generator Shaft        | 1                 |
| 31        | A365 5320 | PaperFeed Clutch             | 1                 |
| 32        | A365 1023 | Gear-16Z                     | 1                 |
| 33        | A365 1063 | Pick-up Release Spring       | 1                 |



| Index No. | Part No.   | Description                    | Q'ty Per Assembly |
|-----------|------------|--------------------------------|-------------------|
| 34        | A365 1038  | Pick-up Roller Shaft           | 1                 |
| 35        | A365 1059  | Pick-up Lever Shaft            | 1                 |
| 36        | A365 1022  | Pull-out Roller                | 1                 |
| 37        | A365 1060  | Pick-up Lever                  | 1                 |
| 38        | A365 1007  | Front Side Plate               | 1                 |
| 39        | A365 1062  | Lever -Pick-up Solenoid        | 1                 |
| 40        | A365 5250  | Ground Wire                    | 1                 |
|           |            |                                |                   |
| 101       | 0314 0060W | Philips Pan Head Screw - M4x6  |                   |
| 102       | 0720 0060E | Retaining Ring - M6            |                   |
| 103       | 0632 0080G | Parallel Key-2x8mm             |                   |
| 104       | 0313 0050W | Philips Pan Head Screw - M3x5  |                   |
| 105       | 0313 0030W | Philips Pan Head Screw - M3x3  |                   |
| 106       | 0632 0120G | Pin-2x12mm                     |                   |
| 107       | 0720 0040E | Retaining Ring - M4            |                   |
| 108       | 0313 0040W | Philips Pan Head Screw - M3x4  |                   |
| 109       | 0314 0100W | Philips Pan Head Screw - M4x10 |                   |
| 110       | 0741 3506  | Ball Bearing - 6x12x4 mm       |                   |
| 111       | 1105 0087  | Clamp                          |                   |
| 112       | 1105 0199  | Clamp                          |                   |
| 113       | 0632 0120G | Parallel Pin - 2x12mm          |                   |
| 114       | 1107 0617  | Fuse - 2.0A/250V               |                   |
| 115       | 1105 0109  | Cord Keep                      |                   |
| 116       | 1102 5970  | Connector LP-01 - 220V         |                   |
| 117       | 0701 0060B | Flat Washer - M6               |                   |



#### 4. TRANSPORT AND EXIT SECTION (A365)



#### 4. TRANSPORT AND EXIT SECTION (A365)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | AG07 0004 | Magnet Catch                     | 2                 |
| 2         | A365 1336 | Magnet Holder                    | 1                 |
| 3         | 54472681  | Snap Ring                        | 1                 |
| 4         | A365 1114 | Belt Tension Spring              | 2                 |
| 5         | A365 1195 | Bushing - Right Transport Roller | 2                 |
| 6         | A365 1186 | Exit Pulley - Small              | 1                 |
| 7         | A365 1207 | Exit Roller Drive Belt           | 1                 |
| 8         | 5053 0447 | Bushing - 6mm                    | 6                 |
| 9         | A365 1205 | Exit Roller Drive Pulley         | 1                 |
| 10        | A365 1211 | Front Exit Guide Bracket         | 1                 |
| 11        | A365 1201 | Exit Roller                      | 1                 |
| 12        | A365 1107 | Front Frame - Sub                | 1                 |
| 13        | A365 1247 | Antistatic Brush                 | 1                 |
| 14        | A365 1213 | Rear Exit Guide Bracket          | 1                 |
| 15        | A365 1190 | Grounding Plate                  | 1                 |
| 16        | A395 1184 | Belt Drive Roller                | 1                 |
|           | A365 1183 | O/O MB4                          |                   |
| 17        | A365 1118 | Belt Tension Roller              | 3                 |
| 18        | A365 1106 | Front Frame - Main               | 1                 |
| 19        | A422 1108 | Stopper                          | 4                 |
| 20        | A365 1101 | Rear Frame                       | 1                 |
| 21        | A365 1109 | Gear - 18Z                       | 1                 |
| 22        | A465 1127 | Transport Belt                   | 1                 |
| 23        | A395 1172 | Belt Drive Roller                | 1                 |
|           | A365 1172 | O/O MB4                          |                   |
| 24        | A365 1176 | Belt Pressure Roller             | 1                 |
| 25        | A365 1255 | Mylar - 10x85mm                  | 1                 |
| 26        | G011 3275 | Snap Ring                        | 1                 |
| 27        | A365 1130 | Transport Belt Guide             | 4                 |
| 28        | A365 1394 | Cushion - 3x10x220               | 1                 |

| Index No. | Part No.   | Description                       | Q'ty Per Assembly |
|-----------|------------|-----------------------------------|-------------------|
| 101       | 0353 0050W | Tapping Screw - M3x5              |                   |
| 102       | 0314 0060W | Philips Pan Head Screw - M4x6     |                   |
| 103       | 0720 0040E | Retaining Ring - M4               |                   |
| 104       | 0632 0120G | Parallel Pin - 2x12               |                   |
| 105       | 0805 3383  | Bushing - 5mm                     |                   |
| 106       | 0433 0082B | Hexagon Head Tapping Screw - M3x8 |                   |

## 5. DF MAIN BOARD (A365)

### AR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| AR1        | 129       |
| AR2        | 129       |
| AR3        | 129       |

### CAPACITOR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| C 2        | 139       |
| C 3        | 139       |
| C 4        | 139       |
| C 5        | 138       |
| C 7        | 138       |
| C 8        | 132       |
| C 9        | 139       |
| C10        | 138       |
| C11        | 138       |
| C12        | 138       |

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| C13        | 138       |
| C14        | 138       |
| C15        | 134       |
| C16        | 138       |
| C17        | 138       |
| C18        | 135       |
| C19        | 137       |
| C20        | 138       |
| C21        | 136       |
| C22        | 138       |

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| C23        | 140       |
| C24        | 133       |
| C25        | 138       |

### COIL

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| L1         | 131       |
| L2         | 141       |

### CONNECTOR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| CN101      | 102       |
| CN110      | 106       |
| CN111      | 108       |
| CN112      | 107       |
| CN113      | 111       |
| CN114      | 109       |
| CN115      | 103       |
| CN116      | 110       |
| CN117      | 105       |
| CN118      | 104       |

### DIODE

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| D1         | 117       |
| D2         | 117       |
| D3         | 116       |
| D4         | 116       |

### FUSE

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| F1         | 114       |
| (F1)       | 113       |

### C

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| IC 1       | 120       |
| IC2        | 121       |
| IC3        | 126       |
| IC4        | 122       |
| IC5        | 124       |
| IC6        | 119       |
| IC7        | 5         |
| (IC7)      | 112       |
| IC8        | 125       |
| IC9        | 123       |

### BR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| BR1        | 118       |

### RESISTOR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| R 2        | 143       |
| R3         | 142       |
| R 4        | 143       |
| R5         | 144       |
| R 6        | 149       |
| R 7        | 146       |
| R8         | 144       |
| R 9        | 144       |
| R10        | 145       |
| R13        | 145       |

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| R14        | 144       |
| R15        | 146       |
| R16        | 142       |
| R17        | 142       |
| R18        | 142       |
| R19        | 149       |
| R20        | 142       |
| R21        | 142       |
| R22        | 148       |
| R23        | 143       |

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| R24        | 128       |
| R25        | 144       |
| R26        | 147       |

### SW

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| Sw1        | 115       |

### TEST POINT

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| TP1        | 101       |
| TP4        | 101       |
| TP5        | 101       |
| TP6        | 101       |

### VARIABLE RESISTOR

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| VR 1       | 130       |

### XTL

| SYMBOL NO. | INDEX NO. |
|------------|-----------|
| XTL1       | 127       |

## 5. DF MAIN BOARD (A365)

| Index No. | Part No.  | Description           | Q'ty Per Assembly |
|-----------|-----------|-----------------------|-------------------|
| *         | A365 5010 | DF Main Board         | 1                 |
| 1         | A365 5172 | Heat Sink             | 1                 |
| 2         | A365 5176 | Heat Sink             | 1                 |
| 3         | A365 5350 | Insulation Sheet      | 1                 |
| 4         | A365 5355 | Insulation Sheet      | 1                 |
| 5         | A365 5110 | IC - AM27C256-205DC   | 1                 |
| 101       | 1101 0328 | Connector Pin Contact |                   |
| 102       | 1102 1077 | Connector - 3P        |                   |
| 103       | 1102 4201 | CT Header - 2P        |                   |
| 104       | 1102 5003 | Connector - 2P        |                   |
| 105       | 1102 0901 | Connector - 2P        |                   |
| 106       | 1102 5887 | Connector - 3P        |                   |
| 107       | 1103 1392 | Connector - 2P        |                   |
| 108       | 1103 1542 | Connector - 3P        |                   |
| 109       | 1103 1726 | Connector - 4P        |                   |
| 110       | 1103 1768 | Connector - 2P        |                   |
| 111       | 1103 1769 | Connector - 3P        |                   |
| 112       | 1104 0271 | IC Socket - 28P       |                   |
| 113       | 1104 0577 | Fuse Holder           |                   |
| 114       | 1107 0617 | Fuse-2.0A/250V        |                   |
| 115       | 1204 1422 | DIP Switch            |                   |
| 116       | 1401 0611 | Diode- IS1588         |                   |
| 117       | 1402 0247 | Diode-W06B            |                   |
| 118       | 1402 0601 | Diode-RBV-401         |                   |

| Index No. | Part No.  | Description                    | Q'ty Per Assembly |
|-----------|-----------|--------------------------------|-------------------|
| 119       | 1407 1026 | IC-SN74LS373N                  |                   |
| 120       | 1407 1964 | IC-TD62304AP                   |                   |
| 121       | 1407 3092 | IC-TC74HC08AP                  |                   |
| 122       | 1407 3410 | IC-μPD78C10ACW                 |                   |
| 123       | 1408 0402 | IC-STR2024                     |                   |
| 124       | 1408 0408 | IC-PST518A                     |                   |
| 125       | 1408 0638 | IC-7805A                       |                   |
| 126       | 1408 0826 | IC-TA8428K                     |                   |
| 127       | 1503 0347 | Oscillator-12MHz               |                   |
| 128       | 1600 1315 | Resistor- 75Q5W                |                   |
| 129       | 1601 7527 | Resistor Array - 10K Ohm       |                   |
| 130       | 1601 8170 | Resistor 10K Ohm               |                   |
| 131       | 1602 0953 | Coil - 800μH 2.5A              |                   |
| 132       | 1604 1179 | Capacitor- 10μF DC50V ±20%     |                   |
| 133       | 1604 1733 | Capacitor - 4.7μF 35V          |                   |
| 134       | 1604 1881 | Capacitor - 4.7μF 25V ±20%     |                   |
| 135       | 1604 2215 | Capacitor - 330μF 10V          |                   |
| 136       | 1604 2453 | Capacitor - 4700μF 50V         |                   |
| 137       | 1604 2454 | Capacitor - 1000μF 50V         |                   |
| 138       | 1606 0807 | Capacitor - 0.1μF +80%-20% 50V |                   |
| 139       | 1606 0998 | Ceramic Capacitor - 0.01μF 50V |                   |
| 140       | 1606 1508 | Capacitor - 10000pF 500V       |                   |
| 141       | 1607 0538 | Choke Coil - HP-023A           |                   |
| 142       | 1611 4103 | Resistor- 10K Ohm I/4V ±5%     |                   |
| 143       | 1611 4151 | Resistor -150 Ohm I/4W         |                   |
| 144       | 1611 4222 | Resistor - 2.2k Ohm I/4V ±5%   |                   |
| 145       | 1611 4271 | Resistor - 270 Ohm I/4W ±5%    |                   |
| 146       | 1611 4333 | Resistor - 33 Ohm I/4W ±5%     |                   |
| 147       | 1611 4393 | Resistor - 39k Ohm I/4W ±5%    |                   |
| 148       | 1611 4470 | Resistor - 47 Ohm I/4V ±5%     |                   |
| 149       | 1611 4472 | Resistor -4.7k Ohm I/4W ±5%    |                   |
| 150       | 1402 1125 | Zener Diode - IW-RD33FB2       |                   |
|           |           | MB2 (ADDED)                    |                   |
| 151       | 1106 0701 | Tube - 0.8                     |                   |
|           |           | MB2 (ADDED)                    |                   |

# PARTS INDEX

| Part No.  | Description                                  | Page and Index No. |
|-----------|----------------------------------------------|--------------------|
| A365 0630 | Original Table Ass'y                         | 5- 18              |
| A365 0661 | ADF Interface Bracket Ass'y-115V MB6 (ADDED) | 5-27               |
| A365 0662 | ADF Interface Bracket Ass'y-220V MB6 (ADDED) | 5- 27              |
| A365 1001 | Rear Side Plate                              | 9- 5               |
| A365 1005 | Photointerruptor Bracket                     | 9-22               |
| A365 1007 | Front Side Plate                             | 9-38               |
| A365 1010 | Gear - 20Z                                   | 9- 25              |
| A365 1011 | Gear - 18/40Z                                | 9-21               |
| A365 1012 | Gear - 40Z                                   | 9- 24              |
| A365 1018 | Gear - 20Z                                   | 9- 4               |
| A365 1022 | Pull-out Roller                              | 9- 36              |
| A365 1023 | Gear - 16Z                                   | 9- 32              |
| A365 1024 | Timing Belt- 122XL -Orange                   | 9- 18              |
| A365 1026 | Feed Roller Shaft                            | 9- 11              |
| A365 1027 | Feed Roller                                  | 9- 13              |
| A365 1029 | Pulse Generator Shaft                        | 9- 30              |
| A365 1032 | Pulse Generator                              | 9-29               |
| A365 1038 | Pick-up Roller Shaft                         | 9- 34              |
| A365 1040 | Pick-up Roller                               | 9-20               |
| A365 1045 | Pick-up Pulley-Large                         | 9- 2               |
| A365 1046 | Pick-up Pulley - Small                       | 9- 3               |
| A365 1051 | Timing Belt- 122XL                           | 9- 1               |
| A365 1055 | Set Sensor Bracket                           | 9- 14              |
| A365 1059 | Pick-up Lever Shaft                          | 9-35               |
| A365 1060 | Pick-up Lever                                | 9-37               |
| A365 1062 | Lever -Pick-up Solenoid                      | 9- 39              |
| A365 1063 | Pick-up Release Spring                       | 9-33               |
| A365 1070 | Paper Feed Guide                             | 7- 5               |
| A365 1085 | Cushion - 3x6x10                             | 9- 26              |
| A365 1101 | Rear Frame                                   | 11- 20             |
| A365 1106 | Front Frame - Main                           | 11- 18             |
| A365 1107 | Front Frame - Sub                            | 11- 12             |
| A365 1109 | Gear-18Z                                     | 11- 21             |
| A365 1114 | Belt Tension Spring                          | 11- 4              |
| A365 1118 | Belt Tension Roller                          | 11- 17             |

| Part No.  | Description                      | Page and Index No. |
|-----------|----------------------------------|--------------------|
| A365 1130 | Transport Belt Guide             | 11- 27             |
| A365 1172 | 0/0 MB4                          | 11- 23             |
| A365 1176 | Belt Pressure Roller             | 11- 24             |
| A365 1183 | 0/0 MB4                          | 11- 16             |
| A365 1186 | Exit Pulley - Small              | 11- 6              |
| A365 1190 | Grounding Plate                  | 11- 15             |
| A365 1195 | Bushing - Right Transport Roller | 11- 5              |
| A365 1201 | Exit Roller                      | 11- 11             |
| A365 1205 | Exit Roller Drive Pulley         | 11- 9              |
| A365 1207 | Exit Roller Drive Belt           | 11- 7              |
| A365 1211 | Front Exit Guide Bracket         | 11- 10             |
| A365 1213 | Rear Exit Guide Bracket          | 11- 14             |
| A365 1217 | Paper Exit Guide                 | 7- 2               |
| A365 1221 | Support Roller Shaft             | 7- 4               |
| A365 1222 | Exit Support Roller              | 7- 3               |
| A365 1247 | Antistatic Brush                 | 11- 13             |
| A365 1255 | Mylar - 10x85mm                  | 11- 25             |
| A365 1310 | DF Upper Cover                   | 5- 17              |
| A365 1315 | Transformer Bracket              | 9- 8               |
| A365 1330 | Grip Cover                       | 7- 1               |
| A365 1336 | Magnet Holder                    | 11- 2              |
| A365 1352 | Friction Belt Holder             | 5- 13              |
| A365 1370 | Original Table                   | 5- 4               |
| A365 1375 | Original Guide - Front           | 5- 1               |
| A365 1380 | Original Guide - Rear            | 5- 2               |
| A365 1390 | Rack Guide Bracket               | 5- 6               |
| A365 1393 | Original Stack Guide             | 5- 5               |
| A365 1394 | Cushion - 3x10Xx20               | 11- 28             |
| A365 1400 | Left Hinge                       | 7- 12              |
| A365 1410 | Right Hinge                      | 7- 6               |
| A365 1479 | Lift Switch Actuator             | 7- 13              |
| A365 1482 | Grounding Bracket                | 7- 8               |
| A365 1485 | Upper Unit Stand MB3 (ADDED)     | 5- 21              |
| A365 1486 | Magnet MB3 (ADDED)               | 5- 23              |
| A365 1495 | Knob Screw                       | 5- 20              |

| Part No.  | Description                     | Page and Index No. |
|-----------|---------------------------------|--------------------|
| A365 1582 | Main Motor Cover                | 7- 16              |
| A365 1583 | Main Board Cover                | 7- 15              |
| A365 1584 | Transformer Cover               | 7- 7               |
| A365 2020 | Indicator Cover                 | 5- 16              |
| A365 2030 | Decal-Mode                      | 7- 11              |
| A365 2060 | Decal-DF                        | 5- 10              |
| A365 2080 | Instruction Decal MB3 (ADDED)   | 5-24               |
| A365 5010 | DF Main Board                   | 9- 6               |
| A365 5010 | DF Main Board                   | 13- *              |
| A365 5090 | Main Motor-DC9W                 | 9- 17              |
| A365 5110 | IC-AM27C256-205DC               | 13- 5              |
| A365 5121 | interface Board-ADF MB6 (ADDED) | 5-28               |
| A365 5172 | Heat Sink                       | 13- 1              |
| A365 5176 | Heat Sink                       | 13- 2              |
| A365 5181 | Transformer - 115V              | 9- 7               |
| A365 5182 | Transformer - 220V              | 9- 7               |
| A365 5221 | Encoder Harness                 | 9- 10              |
| A365 5231 | Power Supply Harness -115V      | 7- 10              |
| A365 5232 | Power Supply Harness -220V      | 7- 10              |
| A365 5250 | Ground Wire                     | 9- 40              |
| A365 5260 | Jam Indicator Ass'y             | 9- 16              |
| A365 5320 | Paper Feed Clutch               | 9-31               |
| A365 5324 | Pick-up Solenoid                | 9-27               |
| A365 5335 | Registration Sensor             | 7- 9               |
| A365 5338 | Original Set Sensor             | 9- 15              |
| A365 5350 | Insulation Sheet                | 13- 3              |
| A365 5355 | Insulation Sheet                | 13- 4              |
| A365 6001 | Screw Driver MB3 (ADDED)        | 5- 25              |
| A395 1172 | Belt Drive Roller               | 11- 23             |
| A395 1184 | Belt Drive Roller               | 11- 16             |

| Part No.  | Description                        | Page and Index No. |
|-----------|------------------------------------|--------------------|
| AA14 3183 | Stepped Screw MB3 (ADDED)          | 5- 22              |
| AG07 0004 | Magnet Catch                       | 11- 1              |
| AW02 0041 | Photointerruptor                   | 9- 28              |
| A077 1160 | Bracket -ADF Connector MB6 (ADDED) | 5- 30              |
| A077 1162 | ADF Bracket MB6 (ADDED)            | 5- 31              |
| A077 1361 | Shoulder Screw MB6 (ADDED)         | 5- 32              |
| A077 5316 | DF Harness-115V MB6 (ADDED)        | 5- 29              |
| A077 5317 | DF Harness-220V MB6 (ADDED)        | 5- 29              |
| A099 5520 | o/o MB 5                           | 9- 28              |
| A300 5621 | Optical Fiber Harness              | 9- 9               |
| A422 1108 | Stopper                            | 11- 19             |
| A422 1355 | Friction Belt Spring               | 5- 15              |
| A422 1356 | Pin - 3x26mm                       | 5- 14              |
| A422 1361 | Rack - Side Guide                  | 5- 9               |
| A465 1127 | Transport Belt                     | 11- 22             |
| A497 1170 | Friction Belt                      | 5- 11              |
| GO11 3275 | Snap Ring                          | 11- 26             |
| G648 5320 | Microswitch                        | 7- 14              |
| 5053 0447 | Bushing - 6mm                      | 9- 19              |
| 5053 0447 | Bushing - 6mm                      | 11- 8              |
| 5443 2657 | Gear - 28Z                         | 5- 7               |
| 5443 2712 | Cork Pad                           | 5- 19              |
| 5443 2713 | Wave Washer                        | 5- 8               |
| 5443 2713 | Wave Washer                        | 9- 23              |
| 5446 5832 | Connector Guide Pin MB3 (ADDED)    | 5- 26              |
| 5447 2681 | Snap Ring                          | 11- 3              |
| 5875 2088 | Shoulder Screw - M4                | 5- 12              |
| 5875 2088 | Shoulder Screw - M4                | 7- 17              |
| 5894 2747 | Mylar - Original Guides            | 5- 3               |
| 5940 1088 | Upper Relay Feed Roller            | 9- 12              |



| Part No.   | Description                                          | Page and Index No. |
|------------|------------------------------------------------------|--------------------|
| 0252 0080W | Screw - M2x8                                         | 7-104              |
| 031 30030W | Philips Pan Head Screw - M3x3                        | 9-105              |
| 0313 0040W | Philips Pan Head Screw - M3x4                        | 9-108              |
| 0313 0050W | Philips Pan Head Screw - M3x5                        | 9-104              |
| 031 40060W | Philips Pan Head Screw - M4x6                        | 7-103              |
| 031 40060W | Philips Pan Head Screw - M4x6                        | 9-101              |
| 031 40060W | Philips Pan Head Screw - M4x6                        | 11-102             |
| 0314 0100W | Philips Pan Head Screw - M4x10                       | 9-109              |
| 0323 0060W | Philips Sunken Head Screw - M3x6 MB6 (ADDED)         | 5-102              |
| 0344 0060W | Philips Truss Head Screw - M4x6                      | 7-101              |
| 0353 0050W | Tapping Screw - M3x5                                 | 11-101             |
| 0413 0082W | Tapping Screw - M3x8                                 | 5-101              |
| 0433 0082B | Hexagon Head Tapping Screw - M3x8                    | 11-106             |
| 0632 0080G | Parallel Key - 2x8mm                                 | 9-103              |
| 0632 0120G | Pin - 2x12mm                                         | 9-106              |
| 0632 0120G | Parallel Pin - 2x12mm                                | 9-113              |
| 0632 0120G | Parallel Pin - 2x12                                  | 11-104             |
| 0701 0060B | Flat Washer - M6                                     | 9-117              |
| 0720 0040E | Retaining Ring - M4                                  | 9-107              |
| 0720 0040E | Retaining Ring - M4                                  | 11-103             |
| 0720 0060E | Retaining Ring - M6                                  | 9-102              |
| 0741 3506  | Ball Bearing - 6x12x4 mm                             | 9-110              |
| 0801 0137  | Philips Pan Head Screw With Spring - M4x6            | 7-105              |
| 0801 1185  | Philips Truss Head Screw - M4x8                      | 7-106              |
| 0805 3383  | Bushing - 5mm                                        | 11-105             |
| 0950 3008W | Philips Screw With Lock Washer - M3x8<br>MB6 (ADDED) | 5-103              |
| 0950 4006W | Philips Screw With Lock Washer - M3x6<br>MB6 (ADDED) | 5-104              |
| 1101 0328  | Connector Pin Contact                                | 13-101             |
| 1102 0901  | Connector - 2P                                       | 13-105             |
| 1102 1077  | Connector - 3P                                       | 13-102             |
| 1102 4201  | CT Header - 2P                                       | 13-103             |
| 1102 5003  | Connector - 2P                                       | 13-104             |
| 1102 5887  | Connector - 3P                                       | 13-106             |

| Part No. | Description                          | Page and Index No. |
|----------|--------------------------------------|--------------------|
| 11025970 | Connector LP-01 -220V                | 9-116              |
| 11031392 | Connector - 2P                       | 13-107             |
| 11031542 | Connector - 3P                       | 13-108             |
| 11031726 | Connector - 4P                       | 13-109             |
| 11031768 | Connector - 2P                       | 13-110             |
| 11031769 | Connector - 3P                       | 13-111             |
| 11040271 | IC Socket - 28P                      | 13-112             |
| 11040577 | Fuse Holder                          | 13-113             |
| 11050087 | Clamp                                | 9-111              |
| 11050109 | Cord Keep                            | 9-115              |
| 11050160 | Clamp MB6 (ADDED)                    | 5-105              |
| 11050199 | Clamp                                | 9-112              |
| 11050267 | Wire Clamp MB6 (ADDED)               | 5-106              |
| 11060701 | Tube - 0.8 MB2 (ADDED)               | 13-151             |
| 11060713 | Cable Holder                         | 7-102              |
| 11070617 | Fuse - 2.0A/250V                     | 9-114              |
| 11070617 | Fuse - 2.0A/250V                     | 13-114             |
| 12041422 | DIP Switch                           | 13-115             |
| 14010611 | Diode - 1S1588                       | 13-116             |
| 14020247 | Diode - W06B                         | 13-117             |
| 14020601 | Diode - RBV -401                     | 13-118             |
| 14021125 | Zener Diode - 1W-RD33FB2 MB2 (ADDED) | 13-150             |
| 14071026 | IC - SN74LS373N                      | 13-119             |
| 14071964 | IC - TD62304AP                       | 13-120             |
| 14073092 | IC - TC74HC08AP                      | 13-121             |
| 14073410 | IC - $\mu$ PD78C10ACW                | 13-122             |
| 14080402 | IC - STR2024                         | 13-123             |
| 14080408 | IC - PST518A                         | 13-124             |
| 14080638 | IC - 17805A                          | 13-125             |
| 14080826 | IC - TA8428K                         | 13-126             |
| 15030347 | Oscillator - 12 MHz                  | 13-127             |
| 16001315 | Resistor - 75S25W                    | 13-128             |
| 16017527 | Resistor Array - 10K Ohm             | 13-129             |
| 16018170 | Resistor 10K Ohm                     | 13-130             |
| 16020953 | Coil - 800 $\mu$ H 2.5A              | 13-131             |

| Part No.  | Description                            | Page and Index No. |
|-----------|----------------------------------------|--------------------|
| 16041179  | Capacitor - 10 $\mu$ F DC50V $\pm$ 20% | 13-132             |
| 16041733  | Capacitor - 4.7 $\mu$ F 35V            | 13-133             |
| 16041881  | Capacitor - 4.7 $\mu$ F 25V $\pm$ 20%  | 13-134             |
| 1604 2215 | Capacitor - 330 $\mu$ F 10V            | 13-135             |
| 1604 2453 | Capacitor - 4700 $\mu$ F 50V           | 13-136             |
| 1604 2454 | Capacitor - 1000 $\mu$ F 50V           | 13-137             |
| 1606 0807 | Capacitor - 0.1 $\mu$ F + 80%-20% 50V  | 13-138             |
| 1606 0998 | Ceramic Capacitor - 0.01 $\mu$ F 50V   | 13-139             |
| 1606 1508 | Capacitor - 10000pF 500V               | 13-140.            |
| 1607 0538 | Choke Coil - HP-023A                   | 13-141             |
| 1611 4103 | Resistor - 10k $\Omega$ 1/4V $\pm$ 5%  | 13-142             |
| 1611 4151 | Resistor - 150 $\Omega$ 1/4W           | 13-143             |
| 1611 4222 | Resistor - 2.2k $\Omega$ 1/4V $\pm$ 5% | 13-144             |
| 1611 4271 | Resistor - 270 $\Omega$ 1/4W $\pm$ 5%  | 13-145             |
| 1611 4333 | Resistor - 33 $\Omega$ 1/4W $\pm$ 5%   | 13-146             |
| 1611 4393 | Resistor - 39k $\Omega$ 1/4W $\pm$ 5%  | 13-147             |
| 1611 4470 | Resistor - 47 $\Omega$ 1/4V $\pm$ 5%   | 13-148             |
| 1611 4472 | Resistor - 4.7k $\Omega$ 1/4W $\pm$ 5% | 13-149             |

| Part No. | Description | Page and Index No. |
|----------|-------------|--------------------|
|          |             |                    |