

# DF62 (A610)

**This parts catalog is includes Mb.No 1 to 6**

## **PARTS CATALOG**

### **INTRODUCTION**


This chapter instructs you the numbers and names of parts on this machine.

### **INDEX to PARTS CATALOG**

|                                          |           |
|------------------------------------------|-----------|
| <b>LOCATION OF UNIT .....</b>            | <b>2</b>  |
| 1.EXTERIOR (A610) .....                  | 4         |
| 2.ORIGINAL FEED SECTION 1 (A610) .....   | 6         |
| 3.ORIGINAL FEED SECTION 2 (A610) .....   | 8         |
| 4.ORIGINAL FEED SECTION 3 (A610) .....   | 10        |
| 5.TRANSPORT SECTION (A610) .....         | 12        |
| 6.INVERTER AND EXIT SECTION (A610) ..... | 14        |
| 7.ELECTRICAL SECTION (A610) .....        | 16        |
| 8.DECAL AND DOCUMENT (A610) .....        | 18        |
| <b>Pats Index .....</b>                  | <b>21</b> |


## LOCATION OF UNIT

1.EXTERIOR (A610)




See Page 5

2.ORIGINAL FEED SECTION 1 (A610)




See Page 7

3.ORIGINAL FEED SECTION 2 (A610)




See Page 9

4.ORIGINAL FEED SECTION 3 (A610)




See Page 11

5.TRANSPORT SECTION (A610)




See Page 13

6.INVERTER AND EXIT SECTION (A610)




See Page 15

**LOCATION OF UNIT**

|                                                                                                                                         |  |  |
|-----------------------------------------------------------------------------------------------------------------------------------------|--|--|
| <p>7.ELECTRICAL SECTION (A610)</p>  <p>See Page 17</p> |  |  |
|                                                                                                                                         |  |  |

1.EXTERIOR (A610)




## 1.EXTERIOR (A610)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | A610 4531 | Left Cover                       | 1                 |
| 2         | A610 6031 | Decal - Original Misfeed         | 1                 |
| 3         | A610 6011 | Decal - Original Size            | 1                 |
| 4         | A376 1902 | Left Cover Bracket               | 1                 |
| 5         | A610 4511 | Upper Cover                      | 1                 |
| 6         | A548 1941 | Display Panel                    | 1                 |
| 7         | A376 3242 | Antistatic Brush                 | 1                 |
| 8         | A610 4527 | Grounding Plate                  | 1                 |
| 9         | A610 4591 | Main Board Cover                 | 1                 |
| 10        | A610 4551 | Original Table                   | 1                 |
| 11        | A565 2151 | Side Fence Rail                  | 1                 |
| 12        | A610 4581 | Side Fence                       | 1                 |
| 13        | A376 4599 | Side Fence Pad                   | 1                 |
| 14        | A548 1931 | Decal - Original Table           | 1                 |
| 15        | A376 4911 | Stepped Screw - Left Hinge       | 2                 |
| 16        | 5875 2088 | Shoulder Screw - M4              | 3                 |
| 17        | A610 4671 | Original Mylar                   | 1                 |
| 18        | A376 4125 | Grip Bracket                     | 1                 |
| 19        | A610 4672 | Original Table Guard             | 1                 |
| 20        | A610 4601 | Lower Feed-out Cover             | 1                 |
| 21        | A054 2977 | Decal - Vertical Transport Guide | 1                 |
| 22        | A610 6041 | Decal - Original Exit            | 1                 |
| 23        | AA06 6278 | Spring                           | 1                 |
| 24        | A469 3350 | Guide Stud                       | 1                 |
| 25        | 5446 2824 | Screw - Duplex Guide Plate       | 2                 |
| 26        | A610 4621 | Front Lower Cover                | 1                 |
| 27        | A548 6131 | Cushion - 20x190x30              | 1                 |
| 28        | A610 4525 | Upper Cover Seal MB5 (ADDED)     | 1                 |

| Index No. | Part No.   | Description                        | Q'ty Per Assembly |
|-----------|------------|------------------------------------|-------------------|
| 101       | 0353 0050B | Philips Truss Head Screw - M3x5    |                   |
| 102       | 0344 0080F | Philips Truss Head Screw - M4x8    |                   |
| 103       | 0344 0060F | Philips Truss Head Screw - M4x6    |                   |
| 104       | 0802 5237  | Binding Self-tapping Screw - M4x10 |                   |
| 105       | 0314 0060B | Philips Pan Head Screw - M4x6      |                   |
| 106       | 0951 5010B | Philips Screw With Washer - M5x10  |                   |

2.ORIGINAL FEED SECTION 1 (A610)




## 2.ORIGINAL FEED SECTION 1 (A610)

| Index No. | Part No.  | Description                    | Q'ty Per Assembly |
|-----------|-----------|--------------------------------|-------------------|
| 1         | 5446 2824 | Screw - Duplex Guide Plate     | 1                 |
| 2         | A610 1251 | Original Upper Guide           | 1                 |
| 3         | C217 5524 | Stud - Front Release Lever     | 1                 |
| 4         | A610 1259 | Original Sensor Filter         | 1                 |
| 5         | 5894 2229 | Solenoid Pin                   | 1                 |
| 6         | A376 1355 | Original Stopper Arm           | 1                 |
| 7         | A376 1335 | Release Spring                 | 3                 |
| 8         | A376 1347 | Original Pressure Arm          | 3                 |
| 9         | A376 1343 | Original Pressure Roller       | 3                 |
| 10        | A376 1331 | Original Pressure Shaft        | 1                 |
| 11        | A376 1363 | Front Lever - Original Stopper | 1                 |
| 12        | A376 1264 | Pressure Spring                | 1                 |
| 13        | A376 1257 | Spacer - M4x6x6                | 2                 |
| 14        | A376 1255 | Original Stopper               | 1                 |
| 15        | A376 3541 | Solenoid Cushion               | 1                 |
| 16        | A376 1265 | Pressure Spring                | 1                 |
| 17        | A376 1245 | Entrance Original Guide        | 1                 |
| 18        | 5053 0447 | Bushing - 6mm                  | 2                 |
| 19        | AA04 3250 | Timing Belt - B40S2M122        | 1                 |
| 20        | A610 1525 | Timing Pulley - 16Z/140Z       | 1                 |
| 21        | A610 1521 | Motor Bracket                  | 1                 |
| 22        | A610 1530 | Separation Belt Drive Motor    | 1                 |
| 23        | AX06 0121 | DC Motor - 27W                 | 1                 |
| 24        | A610 1139 | Original Feed Motor Bracket    | 1                 |
| 25        | A376 1615 | Timing Pulley - 22Z            | 1                 |
| 26        | A548 2113 | Motor Cushion                  | 1                 |
| 27        | A548 2111 | Timing Pulley - 20Z            | 1                 |

| Index No. | Part No.   | Description                       | Q'ty Per Assembly |
|-----------|------------|-----------------------------------|-------------------|
| 101       | 0314 0060B | Philips Pan Head Screw - M4x6     |                   |
| 102       | 0720 0040B | Retaining Ring - M4               |                   |
| 103       | 0720 0030B | Retaining Ring - M3               |                   |
| 104       | 0632 0100  | Parallel Pin - M2x10              |                   |
| 105       | 0344 0060F | Philips Truss Head Screw - M4x6   |                   |
| 106       | 0313 0050B | Philips Pan Head Screw - M3x5     |                   |
| 107       | 0313 0060B | Philips Pan Head Screw - M3x6     |                   |
| 108       | 1105 0199  | Clamp                             |                   |
| 109       | 0574 0050E | Hexagon Headless Set Screw - M4x5 |                   |

3.ORIGINAL FEED SECTION 2 (A610)




### 3.ORIGINAL FEED SECTION 2 (A610)

| Index No. | Part No.         | Description                      | Q'ty Per Assembly |
|-----------|------------------|----------------------------------|-------------------|
| 1         | A610 1115        | Front Side Plate                 | 1                 |
| 2         | A610 1215        | Belt Drive Shaft Holder          | 1                 |
| 3         | 5053 0447        | Bushing - 6mm                    | 2                 |
| 4         | A548 1283        | Bushing - 6x10x6.5mm             | 4                 |
| 5         | A610 1477        | Separation Belt Roller           | 2                 |
| 6         | A610 1472        | Separation Belt Arm              | 2                 |
| 7         | AA06 3386        | Pressure Spring                  | 4                 |
| 8         | A610 1483        | Separation Belt Driven Shaft     | 2                 |
| 9         | <b>A610 1485</b> | <b>Separation Belt</b>           | <b>2</b>          |
| 10        | A610 1476        | Separation Belt Driven Roller    | 2                 |
| 11        | A610 1480        | Separation Belt Drive Shaft      | 1                 |
| 12        | A610 1545        | Original Feed Roller             | 1                 |
| 13        | A376 1457        | Feed Roller Driven Shaft         | 1                 |
| 14        | A376 1465        | Feed Roller Bushing              | 1                 |
| 15        | A376 1467        | Feed Roller Pressure Spring      | 1                 |
| 16        | A376 1461        | Feed Roller Bushing              | 1                 |
| 17        | <b>A376 1445</b> | <b>Feed Roller</b>               | <b>2</b>          |
| 18        | 5215 2621        | Snap Ring - M6                   | 5                 |
| 19        | A376 1447        | Middle Feed Roller               | 1                 |
| 20        | A376 1415        | Feed Roller Drive Shaft          | 1                 |
| 21        | 5053 0223        | Bushing - 8mm                    | 1                 |
| 22        | AW01 0066        | Photosensor - PS-R50D1-B         | 2                 |
| 23        | A376 1197        | Left Bracket - Paper Size Sensor | 1                 |
| 24        | A610 1195        | Original Feed Sensor Bracket     | 1                 |
| 25        | AW02 0021        | Photointerruptor - 175487-3      | 2                 |
| 26        | A610 1190        | Paper Guide Sheet                | 1                 |
| 27        | A610 1160        | Middle Stay                      | 1                 |
| 28        | A376 1193        | Registration Sensor Bracket      | 1                 |
| 29        | A610 1137        | Magnetic Bracket                 | 1                 |
| 30        | A376 1549        | Timing Pulley - 60Z/20Z          | 1                 |
| 31        | A376 1623        | Timing Belt - B60S2M186          | 1                 |
| 32        | A610 1121        | Rear Side Plate                  | 1                 |
| 33        | A376 1419        | Timing Pulley - 22Z/23Z          | 1                 |
| 34        | A610 1432        | Spacer - 8x12x17                 | 1                 |
| 35        | A376 1423        | Timing Belt - B60S2M126          | 1                 |

| Index No. | Part No.   | Description                       | Q'ty Per Assembly |
|-----------|------------|-----------------------------------|-------------------|
| 36        | A376 1553  | Timing Belt - B60S3M144           | 1                 |
| 37        | AX20 0127  | Magnetic Clutch                   | 1                 |
| 38        | A610 1495  | Sensor Bracket                    | 1                 |
| 39        | A610 1491  | Timing Pulley - T24S3M            | 1                 |
| 40        | AA04 3251  | Timing Belt - B40S3M141           | 1                 |
| 41        | A610 1492  | Encoder                           | 1                 |
| 42        | A610 1134  | Sensor Cover Bracket              | 1                 |
| 43        | A610 1475  | Adjusting Plate                   | 2                 |
|           |            |                                   |                   |
| 101       | 0720 0060B | Retaining Ring - M6               |                   |
| 102       | 0314 0060B | Philips Pan Head Screw - M4x6     |                   |
| 103       | 0740 3008  | Ball Bearing - 8x22x7             |                   |
| 104       | 0720 0040B | Retaining Ring - M4               |                   |
| 105       | 1105 0199  | Clamp                             |                   |
| 106       | 0313 0100B | Philips Pan Head Screw - M3x10    |                   |
| 107       | 1105 0328  | Harness Clamp - ES-0505           |                   |
| 108       | 0742 3808  | Ball Bearing - 8x16x5             |                   |
| 109       | 0632 0120  | Parallel Pin - M2x12              |                   |
| 110       | 0574 0050E | Hexagon Headless Set Screw - M4x5 |                   |
| 111       | 0313 0050B | Philips Pan Head Screw - M3x5     |                   |
| 112       | 0623 0100  | Spring Pin - 3x10                 |                   |

4.ORIGINAL FEED SECTION 3 (A610)




#### 4.ORIGINAL FEED SECTION 3 (A610)

| Index No. | Part No.  | Description                    | Q'ty Per Assembly |
|-----------|-----------|--------------------------------|-------------------|
| 1         | 5875 2088 | Shoulder Screw - M4            | 4                 |
| 2         | AA12 0032 | Antistatic Brush               | 1                 |
| 3         | A610 1235 | Original Feed Base             | 1                 |
| 4         | A610 1561 | Idle Roller                    | 1                 |
| 5         | A610 1565 | Pressure Arm                   | 2                 |
| 6         | A610 1221 | Arm Shaft                      | 1                 |
| 7         | A610 1220 | Idle Roller Bracket            | 1                 |
| 8         | A610 1211 | Lower Original Guide           | 1                 |
| 9         | A376 1292 | Front Timing Pulley            | 1                 |
| 10        | A376 1567 | Arm Pressure Spring            | 2                 |
| 11        | A610 1142 | Original Sensor Right Bracket  | 1                 |
| 12        | A610 1311 | Original Feed Roller - Rear    | 1                 |
| 13        | AW01 0066 | Photosensor - PS-R50D1-B       | 1                 |
| 14        | A376 1141 | Upper Paper Feed Stay          | 1                 |
| 15        | A610 1597 | Sensor Bracket                 | 1                 |
| 16        | AW02 0021 | Photointerruptor - 175487-3    | 2                 |
| 17        | A376 1385 | Stopper Solenoid Bracket       | 1                 |
| 18        | A376 1382 | Release Spring                 | 1                 |
| 19        | A610 1384 | Original Stopper Solenoid      | 1                 |
| 20        | A376 1291 | Rear Timing Pulley             | 1                 |
| 21        | A376 1295 | Spacer - M6x10x5               | 1                 |
| 22        | 5053 0447 | Bushing - 6mm                  | 4                 |
| 23        | A376 1149 | Pick-up Relay Roller Bracket   | 1                 |
| 24        | A610 1147 | Original Sensor Bracket        | 1                 |
| 25        | A610 1283 | Original Feed Roller - Front   | 1                 |
| 26        | A376 1145 | Front Bracket - Pick-up Roller | 1                 |
| 27        | A376 1319 | Timing Belt - B60S2M98         | 1                 |
| 28        | A610 1315 | Timing Pulley - 20Z            | 1                 |
| 29        | A610 1245 | Sensor Seal MB3 (ADDED)        | 3                 |

| Index No. | Part No.   | Description                        | Q'ty Per Assembly |
|-----------|------------|------------------------------------|-------------------|
| 101       | 0802 5237  | Binding Self-tapping Screw - M4x10 |                   |
| 102       | 0314 0060B | Philips Pan Head Screw - M4x6      |                   |
| 103       | 0720 0030B | Retaining Ring - M3                |                   |
| 104       | 0720 0060B | Retaining Ring - M6                |                   |
| 105       | 0313 0050B | Philips Pan Head Screw - M3x5      |                   |
| 106       | 0720 0040B | Retaining Ring - M4                |                   |
| 107       | 1105 0199  | Clamp                              |                   |
| 108       | 0313 0100B | Philips Pan Head Screw - M3x10     |                   |
| 109       | 1105 0229  | Clamp                              |                   |

5.TRANSPORT SECTION (A610)




## 5.TRANSPORT SECTION (A610)

| Index No. | Part No.         | Description                               | Q'ty Per Assembly |
|-----------|------------------|-------------------------------------------|-------------------|
| 1         | A610 2111        | Transfer Unit                             | 1                 |
| 2         | A376 2155        | Transport Unit Upper Stopper              | 3                 |
| 3         | 5053 0447        | Bushing - 6mm                             | 2                 |
| 4         | A422 1078        | Bushing - 6x12x4mm                        | 1                 |
| 5         | A610 2121        | Transfer Belt Driven Roller               | 1                 |
| 6         | A610 2141        | Belt Drive Roller                         | 1                 |
| 7         | <b>A376 2196</b> | <b>Transport Belt</b>                     | <b>1</b>          |
| 8         | A610 2136        | Bushing                                   | 8                 |
| 9         | A610 2131        | Belt Pressure Roller                      | 4                 |
| 10        | A610 2220        | Hinge Shaft                               | 2                 |
|           | A610 2213        | O/O MB6                                   |                   |
| 11        | A610 2214        | Hinge Arm                                 | 2                 |
| 12        | A610 2137        | Pressure Roller Bushing                   | 2                 |
| 13        | A610 2161        | Belt Pressure Roller - 24                 | 1                 |
| 14        | A610 2181        | Transfer Belt Guide                       | 2                 |
| 15        | A376 2157        | Transport Unit Rear Stopper               | 1                 |
| 16        | A376 2132        | Belt Driven Roller                        | 1                 |
| 17        | A610 2151        | Transport Stay                            | 1                 |
| 18        | A469 3350        | Guide Stud                                | 1                 |
| 19        | AA14 3062        | Shoulder Screw - M4                       | 1                 |
| 20        | A610 2212        | Transport Hinge Bracket                   | 2                 |
| 21        | A610 2132        | Pressure Bushing                          | 2                 |
| 22        | A610 2133        | Tension Spring                            | 2                 |
| 23        | A548 1611        | Philips Pan Head Screw - M4x6 MB1 (ADDED) | 4                 |

| Index No. | Part No.   | Description                   | Q'ty Per Assembly |
|-----------|------------|-------------------------------|-------------------|
| 101       | 0314 0060B | Philips Pan Head Screw - M4x6 |                   |
| 102       | 0720 0040B | Retaining Ring - M4           |                   |
| 103       | 0720 0030B | Retaining Ring - M3           |                   |
| 104       | 0951 4006B | Screw - M4x6                  |                   |
| 105       | 0741 3506  | Ball Bearing - 6x12x4 mm      |                   |

6.INVERTER AND EXIT SECTION (A610)




## 6.INVERTER AND EXIT SECTION (A610)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | A610 3111 | Front Side Plate                 | 1                 |
| 2         | 5420 4860 | Bushing - 8mm                    | 1                 |
| 3         | 5447 2681 | Snap Ring                        | 1                 |
| 4         | 5053 0447 | Bushing - 6mm                    | 2                 |
| 5         | A376 3537 | Inverter Guide Spring            | 1                 |
| 6         | A610 3126 | Original Exit Roller             | 1                 |
| 7         | A376 3145 | Inverter Guide Plate             | 1                 |
| 8         | A376 3137 | Inverter Guide                   | 1                 |
| 9         | A054 2977 | Decal - Vertical Transport Guide | 1                 |
| 10        | A376 3125 | Inverter Roller                  | 1                 |
| 11        | A376 3612 | Inverter Lever Spring            | 1                 |
| 12        | A376 3172 | Inverter Pawl Bushing            | 1                 |
| 13        | A610 3141 | Invertor Pawl                    | 1                 |
| 14        | A610 3218 | Feed-out Driven Roller Arm       | 4                 |
| 15        | A610 3215 | Feed-out Driven Roller           | 4                 |
| 16        | AA06 3389 | Pressure Spring                  | 4                 |
| 17        | A610 3148 | Upper Feed-out Guide             | 1                 |
| 18        | AW01 0066 | Photosensor - PS-R50D1-B         | 1                 |
| 19        | A610 3161 | Sensor Bracket                   | 1                 |
| 20        | A376 3153 | Lower Driven Roller              | 4                 |
| 21        | A610 3156 | Feed-out Driven Roller Holder    | 4                 |
|           | A610 3155 | O/O MB2                          |                   |
| 22        | A610 3121 | Rear Side Plate                  | 1                 |
| 23        | AA04 3254 | Timing Belt - B40S2M152          | 2                 |
| 24        | A376 3515 | Timing Pulley - 48Z/22Z          | 1                 |
| 25        | A376 3516 | Timing Pulley - 21Z              | 1                 |
| 26        | A610 3532 | Timing Pulley - 18Z              | 1                 |
| 27        | A610 3535 | Motor Cushion                    | 1                 |
| 28        | AX06 0082 | Belt Drive Motor - DC19W         | 1                 |
| 29        | AX11 0056 | DC Solenoid - 24V                | 1                 |
| 30        | A376 3541 | Solenoid Cushion                 | 1                 |
| 31        | A376 3531 | Solenoid Stopper                 | 1                 |
| 32        | A610 3512 | Feed-out Motor Bracket           | 1                 |
| 33        | A610 3157 | Feed-out Roller Spring           | 4                 |
|           | A376 3611 | O/O MB2                          |                   |

| Index No. | Part No.   | Description                         | Q'ty Per Assembly |
|-----------|------------|-------------------------------------|-------------------|
| 34        | 5894 2229  | Solenoid Pin                        | 1                 |
| 101       | 0314 0060B | Philips Pan Head Screw - M4x6       |                   |
| 102       | 0802 5237  | Binding Self-tapping Screw - M4x10  |                   |
| 103       | 0720 0060B | Retaining Ring - M6                 |                   |
| 104       | 0720 0040B | Retaining Ring - M4                 |                   |
| 105       | 0313 0100B | Philips Pan Head Screw - M3x10      |                   |
| 106       | 1105 0328  | Harness Clamp - ES-0505             |                   |
| 107       | 0742 3808  | Ball Bearing - 8x16x5               |                   |
| 108       | 0633 0160E | Pin - 3x16mm                        |                   |
| 109       | 0951 3004B | Philps Screw With Flat Washer -M3x4 |                   |
| 110       | 1105 0199  | Clamp                               |                   |
| 111       | 0574 0050E | Hexagon Headless Set Screw - M4x5   |                   |
| 112       | 0313 0060B | Philips Pan Head Screw - M3x6       |                   |
| 113       | 0720 0030B | Retaining Ring - M3                 |                   |

7.ELECTRICAL SECTION (A610)








## 7.ELECTRICAL SECTION (A610)

| Index No. | Part No.  | Description                 | Q'ty Per Assembly |
|-----------|-----------|-----------------------------|-------------------|
| 1         | A610 5820 | IC - UVEPROM 256KX8 120NS   | 1                 |
| 2         | A610 4179 | Front Stay                  | 1                 |
| 3         | AA04 3253 | Timing Belt - B60S2M278     | 1                 |
| 4         | AA04 3252 | Timing Belt - B60S3M225     | 1                 |
| 5         | A376 1615 | Timing Pulley - 22Z         | 1                 |
| 6         | A376 2524 | Timing Pulley - 60Z/20Z     | 1                 |
| 7         | A610 2511 | Transfer Motor Bracket      | 1                 |
| 8         | AA06 0590 | Pressure Spring             | 1                 |
| 9         | A351 3459 | Idler                       | 1                 |
| 10        | A610 2530 | Transport Tension Bracket   | 1                 |
| 11        | A610 2550 | LED Harness                 | 1                 |
| 12        | A376 5757 | LED Harness                 | 1                 |
| 13        | AX06 0121 | DC Motor - 27W              | 1                 |
| 14        | A610 5500 | Main Control Board          | 1                 |
| 15        | A610 5710 | Original Feed Harness       | 1                 |
| 16        | A610 5705 | Separation Solenoid Harness | 1                 |
| 17        | A610 5700 | Motor Harness               | 1                 |
| 18        | A610 5715 | Invertor Harness            | 1                 |
| 19        | A610 5770 | Separation Motor Harness    | 1                 |
| 20        | AW03 0032 | Optical Fiber               | 1                 |
| 21        | A610 4117 | Left Stay Shaft             | 1                 |
|           | A610 4113 | O/O MB6                     |                   |
| 22        | AA14 3039 | Spring Holder               | 2                 |
| 23        | A548 1135 | Spring Plate                | 1                 |
| 24        | A610 4112 | Right Stay                  | 1                 |
| 25        | A610 4118 | Right Stay Shaft            | 1                 |
|           | A610 4114 | O/O MB6                     |                   |
| 26        | A610 4111 | Left Stay                   | 1                 |
| 27        | A376 5755 | Interface Harness           | 1                 |
| 28        | A610 4191 | Harness Holder              | 1                 |
| 29        | A610 4175 | Motor Cushion               | 1                 |
| 30        | A610 4250 | Hinge Stopper               | 2                 |
| 31        | A610 4140 | Left Hinge                  | 1                 |
| 32        | A351 4281 | Anti-vibration Cushion      | 2                 |
| 33        | A610 4160 | Right Hinge                 | 1                 |

| Index No. | Part No.   | Description                       | Q'ty Per Assembly |
|-----------|------------|-----------------------------------|-------------------|
| 34        | A548 1531  | Safety Switch Feeler              | 1                 |
| 35        | A610 5785  | Lift-up Harness                   | 1                 |
| 36        | AW02 0021  | Photointerruptor - 175487-3       | 2                 |
| 37        | A548 1541  | Safety Switch Bracket             | 1                 |
| 38        | A610 4155  | Spring Plate                      | 1                 |
| 101       | 1105 0310  | Wire Clamp                        |                   |
| 102       | 0314 0060B | Philips Pan Head Screw - M4x6     |                   |
| 103       | 0574 0050E | Hexagon Headless Set Screw - M4x5 |                   |
| 104       | 0313 0060B | Philips Pan Head Screw - M3x6     |                   |
| 105       | 0720 0060B | Retaining Ring - M6               |                   |
| 106       | 0720 0040B | Retaining Ring - M4               |                   |
| 107       | 0951 4008B | Philips Screw With Washer - M4x8  |                   |
| 108       | 1106 0383  | Supportor - P.C.B                 |                   |
| 109       | 1105 0326  | Locking Support                   |                   |
| 110       | 1105 0199  | Clamp                             |                   |
| 111       | 1105 0159  | PCB Stud                          |                   |
| 112       | 1107 0752  | Fuse - 5A 250V                    |                   |
|           | 1107 0459  | O/O MB4                           |                   |
| 112       | 1107 0404  | Fuse - 0.3A 250V                  |                   |
| 114       | 1106 0289  | Bushing - SR-5N-1                 |                   |
| 115       | 1105 0328  | Harness Clamp - ES-0505           |                   |
| 116       | 1403 0493  | LED - Green                       |                   |
| 117       | 0720 0070B | Retaining Ring - M7               |                   |

8.DECAL AND DOCUMENT (A610)

|                                                                                     |                                                                                    |                                                                                      |                                                                                      |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| 1                                                                                   | 3                                                                                  | 4                                                                                    | 5                                                                                    |
|    |  |  |   |
| 2                                                                                   |                                                                                    |                                                                                      | 6                                                                                    |
|  |                                                                                    |                                                                                      |  |

## 8.DECAL AND DOCUMENT (A610)

| Index No. | Part No.  | Description                      | Q'ty Per Assembly |
|-----------|-----------|----------------------------------|-------------------|
| 1         | A054 2977 | Decal - Vertical Transport Guide | 1                 |
| 2         | A376 6051 | Decal - Paper Feed Guide         | 1                 |
| 3         | A548 1931 | Decal - Original Table           | 1                 |
| 4         | A610 6011 | Decal - Original Size            | 1                 |
| 5         | A610 6031 | Decal - Original Misfeed         | 1                 |
| 6         | A610 6041 | Decal - Original Exit            | 1                 |

| Index No. | Part No. | Description | Q'ty Per Assembly |
|-----------|----------|-------------|-------------------|
|           |          |             |                   |

# **PARTS INDEX**

## PM Parts Index

| Section Name                                               | Part No.  | Description in Service Manual | Description in Parts Catalog | Q'ty Per Assembly | Page and Index No |
|------------------------------------------------------------|-----------|-------------------------------|------------------------------|-------------------|-------------------|
| TRANSPORT SECTION (A610)<br>ORIGINAL FEED SECTION 2 (A610) | A376 2196 | Transport Belt                | Transport Belt               | 1                 | 13- 7             |
|                                                            | A376 1445 | Feed Roller                   | Feed Roller                  | 2                 | 9- 17             |
|                                                            | A610 1485 | Separation Belt               | Separation Belt              | 2                 | 9- 9              |

## Parts Index

| Part No.  | Description                   | Page and Index No. |
|-----------|-------------------------------|--------------------|
| A610 1115 | Front Side Plate              | 9- 1               |
| A610 1121 | Rear Side Plate               | 9- 32              |
| A610 1134 | Sensor Cover Bracket          | 9- 42              |
| A610 1137 | Magnetic Bracket              | 9- 29              |
| A610 1139 | Original Feed Motor Bracket   | 7- 24              |
| A610 1142 | Original Sensor Right Bracket | 11- 11             |
| A610 1147 | Original Sensor Bracket       | 11- 24             |
| A610 1160 | Middle Stay                   | 9- 27              |
| A610 1190 | Paper Guide Sheet             | 9- 26              |
| A610 1195 | Original Feed Sensor Bracket  | 9- 24              |
| A610 1211 | Lower Original Guide          | 11- 8              |
| A610 1215 | Belt Drive Shaft Holder       | 9- 2               |
| A610 1220 | Idle Roller Bracket           | 11- 7              |
| A610 1221 | Arm Shaft                     | 11- 6              |
| A610 1235 | Original Feed Base            | 11- 3              |
| A610 1245 | Sensor Seal MB3 (ADDED)       | 11- 29             |
| A610 1251 | Original Upper Guide          | 7- 2               |
| A610 1259 | Original Sensor Filter        | 7- 4               |
| A610 1283 | Original Feed Roller - Front  | 11- 25             |
| A610 1311 | Original Feed Roller - Rear   | 11- 12             |
| A610 1315 | Timing Pulley - 20Z           | 11- 28             |
| A610 1384 | Original Stopper Solenoid     | 11- 19             |
| A610 1432 | Spacer - 8x12x17              | 9- 34              |
| A610 1472 | Separation Belt Arm           | 9- 6               |
| A610 1475 | Adjusting Plate               | 9- 43              |
| A610 1476 | Separation Belt Driven Roller | 9- 10              |
| A610 1477 | Separation Belt Roller        | 9- 5               |
| A610 1480 | Separation Belt Drive Shaft   | 9- 11              |
| A610 1483 | Separation Belt Driven Shaft  | 9- 8               |
| A610 1485 | Separation Belt               | 9- 9               |
| A610 1491 | Timing Pulley - T24S3M        | 9- 39              |
| A610 1492 | Encoder                       | 9- 41              |
| A610 1495 | Sensor Bracket                | 9- 38              |
| A610 1521 | Motor Bracket                 | 7- 21              |
| A610 1525 | Timing Pulley - 16Z/140Z      | 7- 20              |

| Part No.  | Description                   | Page and Index No |
|-----------|-------------------------------|-------------------|
| A610 1530 | Separation Belt Drive Motor   | 7- 22             |
| A610 1545 | Original Feed Roller          | 9- 12             |
| A610 1561 | Idle Roller                   | 11- 4             |
| A610 1565 | Pressure Arm                  | 11- 5             |
| A610 1597 | Sensor Bracket                | 11- 15            |
| A610 2111 | Transfer Unit                 | 13- 1             |
| A610 2121 | Transfer Belt Driven Roller   | 13- 5             |
| A610 2131 | Belt Pressure Roller          | 13- 9             |
| A610 2132 | Pressure Bushing              | 13- 21            |
| A610 2133 | Tension Spring                | 13- 22            |
| A610 2136 | Bushing                       | 13- 8             |
| A610 2137 | Pressure Roller Bushing       | 13- 12            |
| A610 2141 | Belt Drive Roller             | 13- 6             |
| A610 2151 | Transport Stay                | 13- 17            |
| A610 2161 | Belt Pressure Roller - 24     | 13- 13            |
| A610 2181 | Transfer Belt Guide           | 13- 14            |
| A610 2212 | Transport Hinge Bracket       | 13- 20            |
| A610 2213 | Hinge Shaft                   | 13- 10            |
| A610 2214 | Hinge Arm                     | 13- 11            |
| A610 2511 | Transfer Motor Bracket        | 17- 7             |
| A610 2530 | Transport Tension Bracket     | 17- 10            |
| A610 2550 | LED Harness                   | 17- 11            |
| A610 3111 | Front Side Plate              | 15- 1             |
| A610 3121 | Rear Side Plate               | 15- 22            |
| A610 3126 | Original Exit Roller          | 15- 6             |
| A610 3141 | Invertor Pawl                 | 15- 13            |
| A610 3148 | Upper Feed-out Guide          | 15- 17            |
| A610 3155 | O/O MB2                       | 15- 21            |
| A610 3156 | Feed-out Driven Roller Holder | 15- 21            |
| A610 3157 | Feed-out Roller Spring        | 15- 33            |
| A610 3161 | Sensor Bracket                | 15- 19            |
| A610 3215 | Feed-out Driven Roller        | 15- 15            |
| A610 3218 | Feed-out Driven Roller Arm    | 15- 14            |
| A610 3512 | Feed-out Motor Bracket        | 15- 32            |
| A610 3532 | Timing Pulley - 18Z           | 15- 26            |

| Part No.  | Description                 | Page and Index No. |
|-----------|-----------------------------|--------------------|
| A610 3535 | Motor Cushion               | 15- 27             |
| A610 4111 | Left Stay                   | 17- 26             |
| A610 4112 | Right Stay                  | 17- 24             |
| A610 4113 | Left Stay Shaft             | 17- 21             |
| A610 4114 | Right Stay Shaft            | 17- 25             |
| A610 4140 | Left Hinge                  | 17- 31             |
| A610 4155 | Spring Plate                | 17- 38             |
| A610 4160 | Right Hinge                 | 17- 33             |
| A610 4175 | Motor Cushion               | 17- 29             |
| A610 4179 | Front Stay                  | 17- 2              |
| A610 4191 | Harness Holder              | 17- 28             |
| A610 4250 | Hinge Stopper               | 17- 30             |
| A610 4511 | Upper Cover                 | 5- 5               |
| A610 4527 | Grounding Plate             | 5- 8               |
| A610 4531 | Left Cover                  | 5- 1               |
| A610 4551 | Original Table              | 5- 10              |
| A610 4581 | Side Fence                  | 5- 12              |
| A610 4591 | Main Board Cover            | 5- 9               |
| A610 4601 | Lower Feed-out Cover        | 5- 20              |
| A610 4621 | Front Lower Cover           | 5- 26              |
| A610 4671 | Original Mylar              | 5- 17              |
| A610 4672 | Original Table Guard        | 5- 19              |
| A610 5500 | Main Control Board          | 17- 14             |
| A610 5700 | Motor Harness               | 17- 17             |
| A610 5705 | Separation Solenoid Harness | 17- 16             |
| A610 5710 | Original Feed Harness       | 17- 15             |
| A610 5715 | Invertor Harness            | 17- 18             |
| A610 5770 | Separation Motor Harness    | 17- 19             |
| A610 5785 | Lift-up Harness             | 17- 35             |
| A610 5820 | IC - UVEPROM 256KX8 120NS   | 17- 1              |
| A610 6011 | Decal - Original Size       | 5- 3               |
| A610 6011 | Decal - Original Size       | 19- 4              |
| A610 6031 | Decal - Original Misfeed    | 5- 2               |
| A610 6031 | Decal - Original Misfeed    | 19- 5              |
| A610 6041 | Decal - Original Exit       | 5- 22              |

| Part No.  | Description           | Page and Index No |
|-----------|-----------------------|-------------------|
| A610 6041 | Decal - Original Exit | 19- 6             |

| Part No.  | Description                 | Page and Index No. |
|-----------|-----------------------------|--------------------|
| AA04 3250 | Timing Belt - B40S2M122     | 7- 19              |
| AA04 3251 | Timing Belt - B40S3M141     | 9- 40              |
| AA04 3252 | Timing Belt - B60S3M225     | 17- 4              |
| AA04 3253 | Timing Belt - B60S2M278     | 17- 3              |
| AA04 3254 | Timing Belt - B40S2M152     | 15- 23             |
| AA06 0590 | Pressure Spring             | 17- 8              |
| AA06 3386 | Pressure Spring             | 9- 7               |
| AA06 3389 | Pressure Spring             | 15- 16             |
| AA06 6278 | Spring                      | 5- 23              |
| AA12 0032 | Antistatic Brush            | 11- 2              |
| AA14 3039 | Spring Holder               | 17- 22             |
| AA14 3062 | Shoulder Screw - M4         | 13- 19             |
| AW01 0066 | Photosensor - PS-R50D1-B    | 11- 13             |
| AW01 0066 | Photosensor - PS-R50D1-B    | 15- 18             |
| AW01 0066 | Photosensor - PS-R50D1-B    | 9- 22              |
| AW02 0021 | Photointerruptor - 175487-3 | 11- 16             |
| AW02 0021 | Photointerruptor - 175487-3 | 9- 25              |
| AW02 0021 | Photointerruptor - 175487-3 | 17- 36             |
| AW03 0032 | Optical Fiber               | 17- 20             |
| AX06 0082 | Belt Drive Motor - DC19W    | 15- 28             |
| AX06 0121 | DC Motor - 27W              | 7- 23              |
| AX06 0121 | DC Motor - 27W              | 17- 13             |
| AX11 0056 | DC Solenoid - 24V           | 15- 29             |
| AX20 0127 | Magnetic Clutch             | 9- 37              |
| C217 5524 | Stud - Front Release Lever  | 7- 3               |

| Part No.  | Description                      | Page and Index No |
|-----------|----------------------------------|-------------------|
| A054 2977 | Decal - Vertical Transport Guide | 19- 1             |
| A054 2977 | Decal - Vertical Transport Guide | 15- 9             |
| A054 2977 | Decal - Vertical Transport Guide | 5- 21             |
| A351 3459 | Idler                            | 17- 9             |
| A351 4281 | Anti-vibration Cushion           | 17- 32            |
| A376 1141 | Upper Paper Feed Stay            | 11- 14            |
| A376 1145 | Front Bracket - Pick-up Roller   | 11- 26            |
| A376 1149 | Pick-up Relay Roller Bracket     | 11- 23            |
| A376 1193 | Registration Sensor Bracket      | 9- 28             |
| A376 1197 | Left Bracket - Paper Size Sensor | 9- 23             |
| A376 1245 | Entrance Original Guide          | 7- 17             |
| A376 1255 | Original Stopper                 | 7- 14             |
| A376 1257 | Spacer - M4x6x6                  | 7- 13             |
| A376 1264 | Pressure Spring                  | 7- 12             |
| A376 1265 | Pressure Spring                  | 7- 16             |
| A376 1291 | Rear Timing Pulley               | 11- 20            |
| A376 1292 | Front Timing Pulley              | 11- 9             |
| A376 1295 | Spacer - M6x10x5                 | 11- 21            |
| A376 1319 | Timing Belt - B60S2M98           | 11- 27            |
| A376 1331 | Original Pressure Shaft          | 7- 10             |
| A376 1335 | Release Spring                   | 7- 7              |
| A376 1343 | Original Pressure Roller         | 7- 9              |
| A376 1347 | Original Pressure Arm            | 7- 8              |
| A376 1355 | Original Stopper Arm             | 7- 6              |
| A376 1363 | Front Lever - Original Stopper   | 7- 11             |
| A376 1382 | Release Spring                   | 11- 18            |
| A376 1385 | Stopper Solenoid Bracket         | 11- 17            |
| A376 1415 | Feed Roller Drive Shaft          | 9- 20             |
| A376 1419 | Timing Pulley - 22Z/23Z          | 9- 33             |
| A376 1423 | Timing Belt - B60S2M126          | 9- 35             |
| A376 1445 | Feed Roller                      | 9- 17             |
| A376 1447 | Middle Feed Roller               | 9- 19             |
| A376 1457 | Feed Roller Driven Shaft         | 9- 13             |
| A376 1461 | Feed Roller Bushing              | 9- 16             |
| A376 1465 | Feed Roller Bushing              | 9- 14             |

| Part No.  | Description                  | Page and Index No. |
|-----------|------------------------------|--------------------|
| A376 1467 | Feed Roller Pressure Spring  | 9- 15              |
| A376 1549 | Timing Pulley - 60Z/20Z      | 9- 30              |
| A376 1553 | Timing Belt - B60S3M144      | 9- 36              |
| A376 1567 | Arm Pressure Spring          | 11- 10             |
| A376 1615 | Timing Pulley - 22Z          | 17- 5              |
| A376 1615 | Timing Pulley - 22Z          | 7- 25              |
| A376 1623 | Timing Belt - B60S2M186      | 9- 31              |
| A376 1902 | Left Cover Bracket           | 5- 4               |
| A376 2132 | Belt Driven Roller           | 13- 16             |
| A376 2155 | Transport Unit Upper Stopper | 13- 2              |
| A376 2157 | Transport Unit Rear Stopper  | 13- 15             |
| A376 2196 | Transport Belt               | 13- 7              |
| A376 2524 | Timing Pulley - 60Z/20Z      | 17- 6              |
| A376 3125 | Inverter Roller              | 15- 10             |
| A376 3137 | Inverter Guide               | 15- 8              |
| A376 3145 | Inverter Guide Plate         | 15- 7              |
| A376 3153 | Lower Driven Roller          | 15- 20             |
| A376 3172 | Inverter Pawl Bushing        | 15- 12             |
| A376 3242 | Antistatic Brush             | 5- 7               |
| A376 3515 | Timing Pulley - 48Z/22Z      | 15- 24             |
| A376 3516 | Timing Pulley - 21Z          | 15- 25             |
| A376 3531 | Solenoid Stopper             | 15- 31             |
| A376 3537 | Inverter Guide Spring        | 15- 5              |
| A376 3541 | Solenoid Cushion             | 15- 30             |
| A376 3541 | Solenoid Cushion             | 7- 15              |
| A376 3611 | O/O MB2                      | 15- 33             |
| A376 3612 | Inverter Lever Spring        | 15- 11             |
| A376 4125 | Grip Bracket                 | 5- 18              |
| A376 4599 | Side Fence Pad               | 5- 13              |
| A376 4911 | Stepped Screw - Left Hinge   | 5- 15              |
| A376 5755 | Interface Harness            | 17- 27             |
| A376 5757 | LED Harness                  | 17- 12             |
| A376 6051 | Decal - Paper Feed Guide     | 19- 2              |
| A422 1078 | Bushing - 6x12x4mm           | 13- 4              |
| A469 3350 | Guide Stud                   | 13- 18             |

| Part No.  | Description                               | Page and Index No |
|-----------|-------------------------------------------|-------------------|
| A469 3350 | Guide Stud                                | 5- 24             |
| A548 1135 | Spring Plate                              | 17- 23            |
| A548 1283 | Bushing - 6x10x6.5mm                      | 9- 4              |
| A548 1531 | Safety Switch Feeler                      | 17- 34            |
| A548 1541 | Safety Switch Bracket                     | 17- 37            |
| A548 1611 | Philips Pan Head Screw - M4x6 MB1 (ADDED) | 13- 23            |
| A548 1931 | Decal - Original Table                    | 5- 14             |
| A548 1931 | Decal - Original Table                    | 19- 3             |
| A548 1941 | Display Panel                             | 5- 6              |
| A548 2111 | Timing Pulley - 20Z                       | 7- 27             |
| A548 2113 | Motor Cushion                             | 7- 26             |
| A548 6131 | Cushion - 20x190x30                       | 5- 27             |
| A565 2151 | Side Fence Rail                           | 5- 11             |

| Part No.  | Description                | Page and Index No. |
|-----------|----------------------------|--------------------|
| 5053 0223 | Bushing - 8mm              | 9- 21              |
| 5053 0447 | Bushing - 6mm              | 15- 4              |
| 5053 0447 | Bushing - 6mm              | 7- 18              |
| 5053 0447 | Bushing - 6mm              | 9- 3               |
| 5053 0447 | Bushing - 6mm              | 11- 22             |
| 5053 0447 | Bushing - 6mm              | 13- 3              |
| 5215 2621 | Snap Ring - M6             | 9- 18              |
| 5420 4860 | Bushing - 8mm              | 15- 2              |
| 5446 2824 | Screw - Duplex Guide Plate | 5- 25              |
| 5446 2824 | Screw - Duplex Guide Plate | 7- 1               |
| 5447 2681 | Snap Ring                  | 15- 3              |
| 5875 2088 | Shoulder Screw - M4        | 5- 16              |
| 5875 2088 | Shoulder Screw - M4        | 11- 1              |
| 5894 2229 | Solenoid Pin               | 7- 5               |
| 5894 2229 | Solenoid Pin               | 15- 34             |

| Part No.   | Description                       | Page and Index No |
|------------|-----------------------------------|-------------------|
| 0313 0050B | Philips Pan Head Screw - M3x5     | 11-105            |
| 0313 0050B | Philips Pan Head Screw - M3x5     | 9-111             |
| 0313 0050B | Philips Pan Head Screw - M3x5     | 7-106             |
| 0313 0060B | Philips Pan Head Screw - M3x6     | 17-104            |
| 0313 0060B | Philips Pan Head Screw - M3x6     | 15-112            |
| 0313 0060B | Philips Pan Head Screw - M3x6     | 7-107             |
| 0313 0100B | Philips Pan Head Screw - M3x10    | 15-105            |
| 0313 0100B | Philips Pan Head Screw - M3x10    | 11-108            |
| 0313 0100B | Philips Pan Head Screw - M3x10    | 9-106             |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 13-101            |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 11-102            |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 17-102            |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 9-102             |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 15-101            |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 5-105             |
| 0314 0060B | Philips Pan Head Screw - M4x6     | 7-101             |
| 0344 0060F | Philips Truss Head Screw - M4x6   | 7-105             |
| 0344 0060F | Philips Truss Head Screw - M4x6   | 5-103             |
| 0344 0080F | Philips Truss Head Screw - M4x8   | 5-102             |
| 0353 0050B | Philips Truss Head Screw - M3x5   | 5-101             |
| 0574 0050E | Hexagon Headless Set Screw - M4x5 | 9-110             |
| 0574 0050E | Hexagon Headless Set Screw - M4x5 | 15-111            |
| 0574 0050E | Hexagon Headless Set Screw - M4x5 | 7-109             |
| 0574 0050E | Hexagon Headless Set Screw - M4x5 | 17-103            |
| 0623 0100  | Spring Pin - 3x10                 | 9-112             |
| 0632 0100  | Parallel Pin - M2x10              | 7-104             |
| 0632 0120  | Parallel Pin - M2x12              | 9-109             |
| 0633 0160E | Pin - 3x16mm                      | 15-108            |
| 0720 0030B | Retaining Ring - M3               | 15-113            |
| 0720 0030B | Retaining Ring - M3               | 7-103             |
| 0720 0030B | Retaining Ring - M3               | 13-103            |
| 0720 0030B | Retaining Ring - M3               | 11-103            |
| 0720 0040B | Retaining Ring - M4               | 9-104             |
| 0720 0040B | Retaining Ring - M4               | 15-104            |
| 0720 0040B | Retaining Ring - M4               | 13-102            |

| Part No.   | Description                         | Page and Index No. |
|------------|-------------------------------------|--------------------|
| 0720 0040B | Retaining Ring - M4                 | 11-106             |
| 0720 0040B | Retaining Ring - M4                 | 17-106             |
| 0720 0040B | Retaining Ring - M4                 | 7-102              |
| 0720 0060B | Retaining Ring - M6                 | 11-104             |
| 0720 0060B | Retaining Ring - M6                 | 17-105             |
| 0720 0060B | Retaining Ring - M6                 | 9-101              |
| 0720 0060B | Retaining Ring - M6                 | 15-103             |
| 0720 0070B | Retaining Ring - M7                 | 17-117             |
| 0740 3008  | Ball Bearing - 8x22x7               | 9-103              |
| 0741 3506  | Ball Bearing - 6x12x4 mm            | 13-105             |
| 0742 3808  | Ball Bearing - 8x16x5               | 15-107             |
| 0742 3808  | Ball Bearing - 8x16x5               | 9-108              |
| 0802 5237  | Binding Self-tapping Screw - M4x10  | 11-101             |
| 0802 5237  | Binding Self-tapping Screw - M4x10  | 5-104              |
| 0802 5237  | Binding Self-tapping Screw - M4x10  | 15-102             |
| 0951 3004B | Philps Screw With Flat Washer -M3x4 | 15-109             |
| 0951 4006B | Screw - M4x6                        | 13-104             |
| 0951 4008B | Philips Screw With Washer - M4x8    | 17-107             |
| 0951 5010B | Philips Screw With Washer - M5x10   | 5-106              |
| 1105 0159  | PCB Stud                            | 17-111             |
| 1105 0199  | Clamp                               | 7-108              |
| 1105 0199  | Clamp                               | 17-110             |
| 1105 0199  | Clamp                               | 15-110             |
| 1105 0199  | Clamp                               | 9-105              |
| 1105 0199  | Clamp                               | 11-107             |
| 1105 0229  | Clamp                               | 11-109             |
| 1105 0310  | Wire Clamp                          | 17-101             |
| 1105 0326  | Locking Support                     | 17-109             |
| 1105 0328  | Harness Clamp - ES-0505             | 15-106             |
| 1105 0328  | Harness Clamp - ES-0505             | 9-107              |
| 1105 0328  | Harness Clamp - ES-0505             | 17-115             |
| 1106 0289  | Bushing - SR-5N-1                   | 17-114             |
| 1106 0383  | Supportor - P.C.B                   | 17-108             |
| 1107 0404  | Fuse - 0.3A 250V                    | 17-112             |
| 1107 0459  | Fuse - 5A 250V                      | 17-112             |

| Part No.  | Description | Page and Index No |
|-----------|-------------|-------------------|
| 1403 0493 | LED - Green | 17-116            |