

DF79 (B617)

DF79 (B617)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.ARDF 1 (B617).....	2
2.ARDF 2 (B617).....	4
3.ARDF 3 (B617).....	6
4.ARDF 4 (B617).....	8
5.ARDF 5 (B617).....	10
6.ARDF 6 (B617).....	12
7.ARDF 7 (B617).....	14
8.DECAL AND DOCUMENT (B617)	16
PARTS INDEX	19

October ,16 ' 2003

1.ARDF 1 (B617)




1.ARDF 1 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 4811	Front Cover	1
2	A628 3115	Knob Screw - M4	2
3	5446 2824	Screw - Duplex Guide Plate	2
4	B386 4873	Positioning Plate	2
5	A859 4871	Actuator - Original Sensor	1
6	A859 4872	Actuator Bracket	1
7	A859 4881	Cushion Paper Feed	1
8	B386 4842	Left Cover	1
9	B386 6014	Decal - Removal Misfeed	1
10	B387 6021	Size Indication Decal	1
11	AA06 3311	Transport Roller Spring	2
12	A859 4836	Bushing Exit Driven Roller	2
13	A859 4837	Exit Driven Roller	1
14	B386 4871	Upper Cover	1
15	B386 4821	Rear Cover	1
16	B386 7102	Scale:Machine Or Copier:Adhesion	1
17	AC01 3004	Exposure Glass	1
18	A859 7211	Stepped Screw	2
19	G564 6077	Decal:Exposure Glass:5-lang	1
20	B387 6053	Original Scale Decal - A4	1
20	B387 6054	Original Scale Decal - LT	1
21	A858 4871	Cover Sponge - Front	1
22	A858 4872	Cover Sponge - Front Right	1
23	A628 3118	Screw Driver - DF	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0452 3008B	Tapping Screw - M3x8	
103	0451 3008H	Tapping Screw - M3x8	

2.ARDF 2 (B617)




2.ARDF 2 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5447 2681	Snap Ring	1
2	H060 2126	Bushing - M6x7	2
3	5215 2621	Snap Ring - M6	1
4	A859 2355	Lever Pressure Plate	1
5	B386 4651		

Index No.	Part No.	Description	Q'ty Per Assembly
36	A858 2313	Spring Plate Pressure Roller Feed	4
37	A858 4671	Roller Driven	8
38	A858 4676	Spring Plate Pressure Roller	4
39	A859 4664	Sheet - Paper Size Sensor Board	1
40			

3.ARDF 3 (B617)



3.ARDF 3 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 2220	Cover Reverse Roller	1
2	A859 2241	Reverse Roller	1
3	A294 6700	Torque Limiter - 53mnm	1
4	5053 0447	Bushing - 6mm	1
5	A859 1621	Separation Guide	1
6	B386 1610	Separation Stay	1
7	5304 1639	Bushing - 8mm	2
8	A859 2230	Ball Bearing - 6x13x5	1
9	AW02 0075	Photointerruptor	1
10	B386 1123	Sensor Bracket	1
11	AA13 2013	Spacer	2
12	AA06 3315	Spring - Belt Drive Shaft	1
13	A859 2132	Front Guide - Paper Feed	1
14	A628 1225	Bushing - 8mm	4
15	A859 2141	Belt Paper Feed	1
16	A859 2114	Drive Roller - Paper Feed Belt	1
17	A859 2121	Gear - 22Z	1
18	A859 2131	Rear Guide - Paper Feed	1
19	A859 2120	Drive Shaft - Paper Feed Belt	1
20	A859 2110	Belt Holder	1
21	AA06 3318	Spring - Belt Guide Roller	2
22	A859 2112	Drive Shaft - Paper Feed Belt	1
23	B387 2113	Roller - Paper Feed Belt	1
24	A859 2162	Shaft - Pick Up Roller	1
25	G412 3821	Holder - Pick Up	1
26	A859 2167	Gear - 22Z	1
27	G412 3831	Pulley - 22Z	1
28	5206 2686	Snap Ring	1
29	B386 2171	Pickup Roller	1
30	A859 2163	Collar Pick Up	1
31	A859 2164	Pulley - 2Z	1
32	A859 2166	Timing Belt - 2XL	1
33	A859 4216	Shaft - Electromagnetic Clutch	1
34	A859 2210	Shaft - Reverse Roller	1
35	A858 4231	Gear - 20Z	1


Index No.	Part No.	Description	Q'ty Per Assembly
36	A859 4222	Flange - Pulley	1
37	A858 4221	Gear - 31Z	1
38	A859 2100	Belt Unit Paper Feed	1
101	0802 5276	Tapping Screw With Washer - M3x6	
102	0720 0040B	Retaining Ring - M4	
103	0720 0060B	Retaining Ring - M6	
104	1105 0109	Cord Keep	
105	0451 3006B	Tapping Screw - M3x6	
106	0632 0100	Parallel Pin - M2x10	
107	0720 0030B	Retaining Ring - M3	
108	1106 0193	Bushing - 7.9mm	

4.ARDF 4 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5446 2824	Screw - Duplex Guide Plate	2
2	A859 4331	Timing Belt - 2XL	1
3	A697 1125	Stepped Screw - Lever	1
4	A859 4341	Tension Spring	1
5	B351 4135	Magnet Catch - Original Table	2
6	A859 3317	Shaft - Contact Point	1
7	A859 3318	Torsion Spring Front	1
8	A859 3316	Lever - Pullout	1
9	A859 3319	Torsion Spring - Rear	1
10	A859 3311	Transport Driven Roller	1
11	A859 3313	Driven Shaft - Pressure	1
12	B386 4881	Left Lower Cover	1
13	B386 4856	Cover - Transport Driven Roller	1
14	A859 1723	Left Lower Guide	1
15	A859 1722	Entrance Guide	1
16	B386 1710	Left Lower Stay	1
17	A859 3511	Guide - Exposure Glass	1
18	B386 3130	Exit Roller - Drive	1
19	A859 2230	Ball Bearing - 6x13x5	2
20	A859 4271	Pulley - 31/32Z	1
21	A859 4272	Flange	1
22	A590 2214	Screw - M3x5	1
23	A858 4392	Torque Limiter	1
24	A858 3710	Exchange Powl - Reverse	1
25	A859 3225	Discharge Brush	1
26	B386 4861	Reverse Tray	1
27	B386 3140	Reverse Roller - Drive	1
28	A859 4321	Pulley-20Z	1
29	B386 4311	Adjusting Pin - M6	1
30	A858 3717	Tension Spring - Exchange Powl	1
31	A858 3715	Lever - Exchange Powl	1
32	5053 0447	Bushing - 6mm	1
33	5447 2681	Snap Ring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0040B	Retaining Ring - M4	
103	0720 0030B	Retaining Ring - M3	

5.ARDF 5 (B617)




5.ARDF 5 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 3210	Guide Plate - Transport Roller	1
2	A859 1322	Spring Plate	2
3	AW01 0093	Photo Sensor - PS-117ND1	2
4	B617 5705	Harness - Sensor	2
5	B386 1311	Left Stay	1
6	5304 1639	Bushing - 8mm	1
7	5053 0447	Bushing - 6mm	1
8	B386 1320	Bracket - Transport Roller	1
9	A859 3110	Transport Roller	1
10	B386 3121	Transport Roller - Middle	1
11	A859 3431	Spring Front	1
12	5447 2681	Snap Ring	2
13	A859 3220	Guide Plate - Upper Exit	1
14	A859 3430	Spring Rear	1
15	A859 3411	Exit Guide Plate	1
16	A859 6023	Decal Green	1
17	A859 3412	Shaft - Exit Guide Plate	2
18	A859 3420	Middle Driven Roller	2
19	A859 3425	Spring Plate	2
20	H511 5006	Stamper	1
21	B386 3413	Cover - Exit Guide Plate	1
22	B386 3231	Reverse Guide Plate	1
23	A858 3236	Discharge Brush L50	3

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4014B	Tapping Screw - M4x14	
103	0720 0060B	Retaining Ring - M6	
104	0720 0040B	Retaining Ring - M4	
105	1106 0193	Bushing - 7.9mm	
106	0452 3008B	Tapping Screw - M3x8	

6.ARDF 6 (B617)




6.ARDF 6 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B379 5800	Harness - Interface	1
2	B617 5700	Harness - Main Sensor	1
3	B386 1831	Right Hinge	1
4	A859 1841	Filler - DF Open Sensor	1
5	A334 4678	Rack Shield Mylar	1
6			

Index No.	Part No.	Description	Q'ty Per Assembly
36	B387 1951	Spring - Paper Size Sensor	1
37	B386 1121	APS Feeller Bracket	1
38	B617 5713	Harness - Original Tray	1
101	0451 3006B	Tapping Screw - M3x6	
102	0451 4006B	Tapping Screw - 4x6	

7.ARDF 7 (B617)



7.ARDF 7 (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A859 1221	Spacer	2
2	G412 3721	Platen Cover Sheet	1
3	B386 1511	Middle Stay	2
4	A859 3614	Sponge Left Platen Cover	1
5	A859 3613	Sponge Platen Cover	3
6	B386 3615	Base - Platen Cover	1
7	B386 1211	Front Side Plate	1
8	B386 1110	Rear Side Plate	1
9	B386 3617	Platen Sheet Mylar	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	

8.DECAL AND DOCUMENT (B617)

1	2		
3	4		
5	6	7	8

8.DECAL AND DOCUMENT (B617)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B386 6014	Decal - Removal Misfeed	1
2	B387 6021	Size Indication Decal	1
3	G564 6077	Decal:Exposure Glass:5-lang	1
4	B387 6053	Original Scale Decal - A4	1
4	B387 6054	Original Scale Decal - LT	1
5	B386 6043	Decal - Side Fence	1
6	B387 6033	Decal - Original Table	1
7	A858 6022	Decal Blue	2
8	A859 6023	Decal Green	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B617 5500	PCB Main Control	13 - 8
B617 5700	Harness - Main Sensor	13 - 2
B617 5701	Harness - Exit Sensor	13 - 27
B617 5703	Harness - Paper Feed Motor	13 - 26
B617 5705	Harness - Sensor	11 - 4
B617 5706	Harness - Reverse Sensor	5 - 35
B617 5713	Harness - Original Tray	13 - 38
B617 5715	Harness - Original Tray	5 - 29
B617 5720	Harness - Registration Sensor	5 - 12

Part No.	Description	Page and Index No.
A028 3264	Stopper Cushion	13 - 11
A294 6700	Torque Limiter - 53mnm	7 - 3
A334 4678	Rack Shield Mylar	13 - 5
A351 4951	Left Side Guide Pad	5 - 19
A590 2214	Screw - M3x5	9 - 22
A628 1225	Bushing - 8mm	7 - 14
A628 3115	Knob Screw - M4	3 - 2
A628 3118	Screw Driver - DF	3 - 23
A661 1884	Pulley - 20T/48T	13 - 15
A697 1125	Stepped Screw - Lever	9 - 3
A858 2313	Spring Plate Pressure Roller Feed	5 - 36
A858 2319	Feeler - Reverse	5 - 34
A858 3236	Discharge Brush L50	11 - 23
A858 3710	Exchange Powl - Reverse	9 - 24
A858 3715	Lever - Exchange Powl	9 - 31
A858 3717	Tension Spring - Exchange Powl	9 - 30
A858 4134	Tension Spring - Idler	13 - 32
A858 4181	Timing Belt - 2XL	13 - 33
A858 4221	Gear - 31Z	7 - 37
A858 4231	Gear - 20Z	7 - 35
A858 4251	Coupled Pulley - 20/32Z	13 - 30
A858 4261	Timing Belt - 2XL	13 - 31
A858 4392	Torque Limiter	9 - 23
A858 4431	DC Solenoid - 24V	13 - 35
A858 4671	Roller Driven	5 - 37
A858 4676	Spring Plate Pressure Roller	5 - 38
A858 4681	Sheet - Paper Tray	5 - 18
A858 4871	Cover Sponge - Front	3 - 21
A858 4872	Cover Sponge - Front Right	3 - 22
A858 5707	Transport Motor Harness	13 - 9
A858 6022	Decal Blue	17 - 7
A858 6022	Decal - Blue	5 - 33
A859 1131	Insulating Sheet	13 - 17
A859 1221	Spacer	15 - 1
A859 1322	Spring Plate	11 - 2

Part No.	Description	Page and Index No.
A859 1621	Separation Guide	7 - 5
A859 1722	Entrance Guide	9 - 15
A859 1723	Left Lower Guide	9 - 14
A859 1841	Filler - DF Open Sensor	13 - 4
A859 2100	Belt Unit Paper Feed	7 - 38
A859 2110	Belt Holder	7 - 20
A859 2112	Drive Shaft - Paper Feed Belt	7 - 22
A859 2114	Drive Roller - Paper Feed Belt	7 - 16
A859 2120	Drive Shaft - Paper Feed Belt	7 - 19
A859 2121	Gear - 22Z	7 - 17
A859 2131	Rear Guide - Paper Feed	7 - 18
A859 2132	Front Guide - Paper Feed	7 - 13
A859 2141	Belt Paper Feed	7 - 15
A859 2162	Shaft - Pick Up Roller	7 - 24
A859 2163	Collar Pick Up	7 - 30
A859 2164	Pulley - 2Z	7 - 31
A859 2166	Timing Belt - 2XL	7 - 32
A859 2167	Gear - 22Z	7 - 26
A859 2210	Shaft - Reverse Roller	7 - 34
A859 2220	Cover Reverse Roller	7 - 1
A859 2230	Ball Bearing - 6x13x5	7 - 8
A859 2230	Ball Bearing - 6x13x5	9 - 19
A859 2241	Reverse Roller	7 - 2
A859 2311	Guide Plate Paper Feed	5 - 6
A859 2315	Separation Pad	5 - 10
A859 2317	Guide Separation Pad	5 - 9
A859 2319	Cushion Base	5 - 8
A859 2352	Pad Pressure Plate	5 - 16
A859 2354	Shaft Base	5 - 14
A859 2355	Lever Pressure Plate	5 - 4
A859 2356	Cushion - Base Bottom	5 - 32
A859 2358	Solenoid Spring	13 - 25
A859 3110	Transport Roller	11 - 9
A859 3210	Guide Plate - Transport Roller	11 - 1
A859 3220	Guide Plate - Upper Exit	11 - 13

Part No.	Description	Page and Index No.
A859 3225	Discharge Brush	9 - 25
A859 3311	Transport Driven Roller	9 - 10
A859 3313	Driven Shaft - Pressure	9 - 11
A859 3316	Lever - Pullout	9 - 8
A859 3317	Shaft - Contact Point	9 - 6
A859 3318	Torsion Spring Front	9 - 7
A859 3319	Torsion Spring - Rear	9 - 9
A859 3411	Exit Guide Plate	11 - 15
A859 3412	Shaft - Exit Guide Plate	11 - 17
A859 3420	Middle Driven Roller	11 - 18
A859 3425	Spring Plate	11 - 19
A859 3430	Spring Rear	11 - 14
A859 3431	Spring Front	11 - 11
A859 3511	Guide - Exposure Glass	9 - 17
A859 3613	Sponge Platen Cover	15 - 5
A859 3614	Sponge Left Platen Cover	15 - 4
A859 4121	Stepper Motor - DC6.2W	13 - 14
A859 4141	Pulley - Idler	13 - 29
A859 4171	Timing Belt - 2XL	13 - 16
A859 4197	Tension Spring Motor	13 - 23
A859 4216	Shaft - Electromagnetic Clutch	7 - 33
A859 4222	Flange - Pulley	7 - 36
A859 4271	Pulley - 31/32Z	9 - 20
A859 4272	Flange	9 - 21
A859 4321	Pulley-20Z	9 - 28
A859 4331	Timing Belt - 2XL	9 - 2
A859 4341	Tension Spring	9 - 4
A859 4421	DC Solenoid	13 - 10
A859 4661	Rack - Front Side Fence	5 - 28
A859 4662	Rack - Rear Side Fence	5 - 25
A859 4663	Electrode Plate - Side Fence	5 - 26
A859 4664	Sheet - Paper Size Sensor Board	5 - 39
A859 4665	Gear - 16Z	5 - 27
A859 4836	Bushing Exit Driven Roller	3 - 12
A859 4837	Exit Driven Roller	3 - 13

Part No.	Description	Page and Index No.
A859 4871	Actuator - Original Sensor	3 - 5
A859 4872	Actuator Bracket	3 - 6
A859 4876	Cushion Left	5 - 15
A859 4881	Cushion Paper Feed	3 - 7
A859 6023	Decal Green	11 - 16
A859 6023	Decal Green	17 - 8
A859 7211	Stepped Screw	3 - 18
B351 4135	Magnet Catch - Original Table	9 - 5
B379 4111	Bracket - Motor	13 - 21
B379 4131	Adjusting Pin - Idler	13 - 28
B379 5800	Harness - Interface	13 - 1
B386 1110	Rear Side Plate	15 - 8
B386 1121	APS Feeller Bracket	13 - 37
B386 1122	Right Sensor Bracket	13 - 6
B386 1123	Sensor Bracket	7 - 10
B386 1125	APS Feeller	13 - 24
B386 1211	Front Side Plate	15 - 7
B386 1311	Left Stay	11 - 5
B386 1315	Bracket - Electromagnetic Clutch	13 - 19
B386 1320	Bracket - Transport Roller	11 - 8
B386 1511	Middle Stay	15 - 3
B386 1610	Separation Stay	7 - 6
B386 1710	Left Lower Stay	9 - 16
B386 1811	Left Hinge	13 - 22
B386 1831	Right Hinge	13 - 3
B386 2171	Pickup Roller	7 - 29
B386 2351	Original Feed Plate	5 - 17
B386 2353	Pressure Plate - Base	5 - 13
B386 3121	Transport Roller - Middle	11 - 10
B386 3130	Exit Roller - Drive	9 - 18
B386 3140	Reverse Roller - Drive	9 - 27
B386 3231	Reverse Guide Plate	11 - 22
B386 3413	Cover - Exit Guide Plate	11 - 21
B386 3615	Base - Platen Cover	15 - 6
B386 3617	Platen Sheet Mylar	15 - 9

Part No.	Description	Page and Index No.
B386 4311	Adjusting Pin - M6	9 - 29
B386 4411	Solenoid Bracket	13 - 12
B386 4621	Upper Original Table	5 - 24
B386 4631	Lower Original Table	5 - 7
B386 4641	Front Side Fence Ass'y	5 - 20
B386 4651	Inner Back Side Fence Ass'y	5 - 5
B386 4691	Mylar Seal - 28x107	5 - 42
B386 4692	Mylar Seal - 16x45	5 - 41
B386 4693	Mylar Seal	5 - 40
B386 4811	Front Cover	3 - 1
B386 4821	Rear Cover	3 - 15
B386 4842	Left Cover	3 - 8
B386 4856	Cover - Transport Driven Roller	9 - 13
B386 4861	Reverse Tray	9 - 26
B386 4871	Upper Cover	3 - 14
B386 4873	Positioning Plate	3 - 4
B386 4881	Left Lower Cover	9 - 12
B386 5550	Paper Size Sensor Board	5 - 30
B386 6014	Decal - Removal Misfeed	17 - 1
B386 6014	Decal - Removal Misfeed	3 - 9
B386 6043	Decal - Side Fence	17 - 5
B386 6043	Decal - Side Fence	5 - 21
B386 7102	Scale:Machine Or Copier:Adhesion	3 - 16
B387 1951	Spring - Paper Size Sensor	13 - 36
B387 2113	Roller - Paper Feed Belt	7 - 23
B387 6021	Size Indication Decal	17 - 2
B387 6021	Size Indication Decal	3 - 10
B387 6033	Decal - Original Table	5 - 23
B387 6033	Decal - Original Table	17 - 6
B387 6053	Original Scale Decal - A4	3 - 20
B387 6053	Original Scale Decal - A4	17 - 4
B387 6054	Original Scale Decal - LT	3 - 20
B387 6054	Original Scale Decal - LT	17 - 4
G012 1531	Magnet	5 - 22
G412 3721	Platen Cover Sheet	15 - 2

Part No.	Description	Page and Index No.
G412 3821	Holder - Pick Up	7 - 25
G412 3831	Pulley - 22Z	7 - 27
G564 6077	Decal:Exposure Glass:5-lang	3 - 19
G564 6077	Decal:Exposure Glass:5-lang	17 - 3
H060 2126	Bushing - M6x7	5 - 2
H511 5006	Stamper	11 - 20

Part No.	Description	Page and Index No.
AA06 3311	Transport Roller Spring	3 - 11
AA06 3315	Spring - Belt Drive Shaft	7 - 12
AA06 3318	Spring - Belt Guide Roller	7 - 21
AA13 2013	Spacer	7 - 11
AC01 3004	Exposure Glass	3 - 17
AW01 0087	Photo Sensor - Ass'y	5 - 31
AW01 0093	Photo Sensor - PS-117ND1	11 - 3
AW02 0075	Photointerruptor	7 - 9
AW02 0075	Photointerruptor	5 - 11
AW02 0075	Photointerruptor	13 - 7
AX21 0071	Electromagnetic Clutch - 30z	13 - 20

Part No.	Description	Page and Index No.
0353 0040B	Screw - M3X4	13 -107
0450 3008B	Tapping Screw - M3x8	5 -103
0451 3006B	Tapping Screw - M3x6	7 -105
0451 3006B	Tapping Screw - M3x6	13 -101
0451 3006B	Tapping Screw - M3x6	11 -101
0451 3006B	Tapping Screw - M3x6	3 -101
0451 3006B	Tapping Screw - M3x6	9 -101
0451 3006B	Tapping Screw - M3x6	15 -101
0451 3006B	Tapping Screw - M3x6	5 -101
0451 3008H	Tapping Screw - M3x8	3 -103
0451 4006B	Tapping Screw - 4x6	13 -102
0451 4014B	Tapping Screw - M4x14	11 -102
0452 3008B	Tapping Screw - M3x8	3 -102
0452 3008B	Tapping Screw - M3x8	13 -106
0452 3008B	Tapping Screw - M3x8	5 -102
0452 3008B	Tapping Screw - M3x8	11 -106
0632 0100	Parallel Pin - M2x10	7 -106
0720 0030B	Retaining Ring - M3	7 -107
0720 0030B	Retaining Ring - M3	9 -103
0720 0040B	Retaining Ring - M4	7 -102
0720 0040B	Retaining Ring - M4	9 -102
0720 0040B	Retaining Ring - M4	11 -104
0720 0040B	Retaining Ring - M4	13 -104
0720 0060B	Retaining Ring - M6	7 -103
0720 0060B	Retaining Ring - M6	11 -103
0802 5276	Tapping Screw With Washer - M3x6	7 -101
0951 3006B	Philips Screw With Flat Washer - M3x6	13 -103
1105 0109	Cord Keep	7 -104
1105 0487	Harness Clamp	13 -105
1106 0193	Bushing - 7.9mm	11 -105
1106 0193	Bushing - 7.9mm	7 -108

Part No.	Description	Page and Index No.
5053 0447	Bushing - 6mm	7 - 4
5053 0447	Bushing - 6mm	9 - 32
5053 0447	Bushing - 6mm	11 - 7
5206 2686	Snap Ring	7 - 28
5206 2686	Snap Ring	13 - 13
5215 2621	Snap Ring - M6	5 - 3
5304 1639	Bushing - 8mm	11 - 6
5304 1639	Bushing - 8mm	13 - 18
5304 1639	Bushing - 8mm	7 - 7
5446 2824	Screw - Duplex Guide Plate	3 - 3
5446 2824	Screw - Duplex Guide Plate	9 - 1
5447 2681	Snap Ring	9 - 33
5447 2681	Snap Ring	11 - 12
5447 2681	Snap Ring	5 - 1
5447 2681	Snap Ring	13 - 34