

Fax Option Type 3232
(B750)

Fax Option Type 3232 (B750)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Fax Option Type 3232 (B750)	2
Parts Index	5

April ,6 ' 2005

1.Fax Option Type 3232 (B750)



1.Fax Option Type 3232 (B750)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B750 5885	Bracket:Fax Control Unit	1
2	B750 5175	FCU Interface Board	1
3	B712 5172	PCB:GWFCU3 (NA/TWN)	1
3	B712 5174	PCB:GWFCU3 (EU/AA)	1
4	B750 5183	MBU EXP	1
5	B750 5382	Harness:Connecting:TNV (NA/TWN)	1
5	B750 5384	Harness:Connecting:TNV (EU/AA)	1
6	B750 5888	Bracket:Connector:Large	1
7	B750 5372	Harness:Modular (NA/TWN)	1
7	B750 5374	Harness:Modular (EU/AA)	1
8	B750 5889	Bracket:Connector:Small	1
9	B750 5050	Speaker:GR:170	1
10	B404 5821	Handset Bracket	1
11	H523 5350	Telephone Cable	1
12	G570 1970	Keytop - Right	1
13	G570 2069	Keytop Cover - Right	1
13	B502 7180	Right Cover Keytop - Taiwan	1
14	G570 2065	Keytop SW - Fax (NA)	1
14	G570 2075	Keytop SW - Fax (EU)	1
15	B502 1350	Line & Tel Cap	1
16	B750 8510	Operating Instructions Fax 1 NA	1
16	B750 8511	Operating Instructions Fax 2 NA	1
16	B750 8520	Operating Instructions Fax 1 AA	1
16	B750 8521	Operating Instructions Fax 2 AA	1
16	B750 8530	Operating Instructions Fax 1 TWN	1
16	B750 8531	Operating Instructions Fax 2 TWN	1
16	B750 8600	Operating Instructions:Fax:EU:English:1	1
16	B750 8650	Operating Instructions:Fax:EU:English:2	1
17	B404 3861	SG3 Decal	1
18	H511 5007	Stamp	1
19	B750 5377	Harness:Connecting:Speaker	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0453 3006N	Tapping Screw - M3x6	
103	1105 0508	Harness Clamp - LWS-0711	
104	1102 4473	CT Connector - 2p	
105	1102 5193	Connector - 10P	
106	1105 0522	Edge Saddle - LES0510	
107	1607 1714	Ferrite Core:RFC-6 (NA/TWN)	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B750 5050	Speaker:GR:170	3 - 9
B750 5175	FCU Interface Board	3 - 2
B750 5183	MBU EXP	3 - 4
B750 5372	Harness:Modular (NA/TWN)	3 - 7
B750 5374	Harness:Modular (EU/AA)	3 - 7
B750 5377	Harness:Connecting:Speaker	3 - 19
B750 5382	Harness:Connecting:TNV (NA/TWN)	3 - 5
B750 5384	Harness:Connecting:TNV (EU/AA)	3 - 5
B750 5885	Bracket:Fax Control Unit	3 - 1
B750 5888	Bracket:Connector:Large	3 - 6
B750 5889	Bracket:Connector:Small	3 - 8
B750 8510	Operating Instructions Fax 1 NA	3 - 16
B750 8511	Operating Instructions Fax 2 NA	3 - 16
B750 8520	Operating Instructions Fax 1 AA	3 - 16
B750 8521	Operating Instructions Fax 2 AA	3 - 16
B750 8530	Operating Instructions Fax 1 TWN	3 - 16
B750 8531	Operating Instructions Fax 2 TWN	3 - 16
B750 8600	Operating Instructions:Fax:EU:English:1	3 - 16
B750 8650	Operating Instructions:Fax:EU:English:2	3 - 16

Part No.	Description	Page and Index No.
B404 3861	SG3 Decal	3 - 17
B404 5821	Handset Bracket	3 - 10
B502 1350	Line & Tel Cap	3 - 15
B502 7180	Right Cover Keytop - Taiwan	3 - 13
B712 5172	PCB:GWFCU3 (NA/TWN)	3 - 3
B712 5174	PCB:GWFCU3 (EU/AA)	3 - 3
G570 1970	Keytop - Right	3 - 12
G570 2065	Keytop SW - Fax (NA)	3 - 14
G570 2069	Keytop Cover - Right	3 - 13
G570 2075	Keytop SW - Fax (EU)	3 - 14
H511 5007	Stamp	3 - 18
H523 5350	Telephone Cable	3 - 11

Part No.	Description	Page and Index No.
0451 3006N	Tapping Screw - 3x6	3 - 101
0453 3006N	Tapping Screw - M3x6	3 - 102
1102 4473	CT Connector - 2p	3 - 104
1102 5193	Connector - 10P	3 - 105
1105 0508	Harness Clamp - LWS-0711	3 - 103
1105 0522	Edge Saddle - LES0510	3 - 106
1607 1714	Ferrite Core:RFC-6 (NA/TWN)	3 - 107

Part No.	Description	Page and Index No.