

Fax Option Type 2018
(B620)

Fax Option Type 2018 (B620)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.FAX OPTION (B620)	2
PARTS INDEX.....	5

October ,16 ' 2003

1.FAX OPTION (B620)



1.FAX OPTION (B620)

Index No.	Part No.	Description	Q'ty Per Assembly
1	H511 5007	Stamp	1
2	B039 1463	Application Cover	1
3	B620 1421	Fax Cover NA	1
3	B620 1450	Fax Cover EU	1
4	B404 3861	SG3 Decal	1
5	B404 1454	Fax Key	1
5	B404 1480	Fax Key	1
6	B620 1470	Right Fax Cover NA	1
6	B620 1481	Right Fax Cover EU	1
7	B620 5050	Speaker	1
8	B620 5172	PCB GWFCU3 NA:Ass'y	1
8	B620 5174	PCB GWFCU3 EU Ass'y	1
9	B620 5080	PCB Mbu Ass'y	1
10	B620 5860	Fax Control Unit Panel	1
11	B622 5823	Knob Screw	2
12	B620 1476	Fax Decal	1
13	H523 5350	Telephone Cable	1
14	B620 5866	Fax Control Unit Holder	1
15	B620 8607	Operating Instructions Basic	1
16	B620 8657	Operating Instructions Advance	1
17	B404 5821	Handset Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	1105 0511	Harness Clamp - LWS-0306ZC	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B620 1421	Fax Cover NA	3 - 3
B620 1450	Fax Cover EU	3 - 3
B620 1470	Right Fax Cover NA	3 - 6
B620 1476	Fax Decal	3 - 12
B620 1481	Right Fax Cover EU	3 - 6
B620 5050	Speaker	3 - 7
B620 5080	PCB Mbu Ass'y	3 - 9
B620 5172	PCB GWFCU3 NA:Ass'y	3 - 8
B620 5174	PCB GWFCU3 EU Ass'y	3 - 8
B620 5860	Fax Control Unit Panel	3 - 10
B620 5866	Fax Control Unit Holder	3 - 14
B620 8607	Operating Instructions Basic	3 - 15
B620 8657	Operating Instructions Advance	3 - 16

Part No.	Description	Page and Index No.
B039 1463	Application Cover	3 - 2
B404 1454	Fax Key	3 - 5
B404 1480	Fax Key	3 - 5
B404 3861	SG3 Decal	3 - 4
B404 5821	Handset Bracket	3 - 17
B622 5823	Knob Screw	3 - 11
H511 5007	Stamp	3 - 1
H523 5350	Telephone Cable	3 - 13
0451 3006B	Tapping Screw - M3x6	3 -101
1105 0511	Harness Clamp - LWS-0306ZC	3 -102