

Paper Feed Unit Type 610 (G399)

Paper Feed Unit Type 610 (G399)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.Paper Cassette (G399).....	2
2.Paper Feed (G399).....	4
3.Frame (G399)	6
Parts Index	9

November ,10 ' 2004

1.Paper Cassette (G399)




1.Paper Cassette (G399)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G555 3063	Left Side Fence	1
2	G399 3364	Tray Bottom Plate	1
3	G555 3069	Basepad	1
4	G029 2609	Cassette Protection	2
5	G399 3087	Label:Protection	1
6	G555 3135	Friction Pad:Adhesion	1
7	G029 2657	Compression Spring	1
8	G399 3086	Label - Paper Tray : Operate 2	1
9	G800 3133	Side Fence Gear	1
10	G399 3052	Paper Tray - Rear	1
11	G555 3074	Rear End Fence	1
12	G555 3077	End Fence Spring	1
13	G555 3075	Front End Fence	1
14	G555 3064	Right Side Fence	1
15	G399 3366	Spring - Paper Feed Pressure : 11n	2
16	G096 3071	Paper Tray Arm	2
17	G399 3051	Paper Tray - Front	1
18	G399 3091	Paper Size Detection Plate - EXP	1
19	G399 3085	Label - Paper Tray : Operate 1	1
20	G555 3054	Sheet:Paper Tray:Front	1
21	G399 3050	Paper Tray Ass'y	1
22	G399 3376	Knob:Tray Bottom Plate	2
23	G399 3374	Lever:Spring:Tray Bottom Plate	2
24	G399 3367	Spring - Tray Bottom Plate : 1.6n	2
25	G399 3373	Holder:Spring:Right	1
26	G399 3377	Cover:Knob	2
27	G399 3375	Holder:Spring:Left	1
28	G399 3372	Supporting Plate:Tray Bottom Plate	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0453 3008N	Binding Self Tapping Screw:3x8	

2.Paper Feed (G399)




2.Paper Feed (G399)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G399 5100	PCB - Bank : P4_exp	1
2	G399 3223	Interface Board Bracket	1
3	G399 3250	Magnetic Clutch - 0.35n.m : Z49	1
4	AX04 0215	Stepper Motor:Mm42:Ud1a	1
5	G399 3228	Bracket:Motor	1
6	G399 3112	Shaft - Paper Feed	1
7	G399 3115	Drive Roller - Middle	1
8	G399 5320	Harness - Signal	1
9	G399 3116	Driven Roller - Middle	1
10	G555 3117	Roller Holder	2
11	G555 3142	Pressure Spring	2
12	G555 3119	Transport Detection Feeler	1
13	G555 3127	Feeler Spring	1
14	AW02 0086	Photointerruptor	1
15	G052 3103	Paper Feed Roller	1
16	G399 3111	Housing - Paper Feed Unit : Upper	1
17	G555 3113	Paper Feed Shaft Holder	1
18	G555 3068	Separation Spring	1
19	G399 3210	Push Switch - Paper Size	1
20	G555 3121	Spring Plate - Shaft	1
21	G555 3248	Gear - 20Z	1
22	G555 3247	Gear - 21Z	1
23	G555 3246	Gear - 22Z	1
24	G555 3245	Gear - 21Z	1
25	AA08 2101	Bushing - 6x10x6	2
26	5447 2681	Snap Ring	1
27	AA08 0252	Bushing - M4	1
28	G555 1213	Heat Sink	2
29	G555 1217	Heat Sink:Stepper Motor	1
30	G555 1216	Heat Sink - Base	1
31	G555 1218	Heat Sink - Motor	1
32	5443 2713	Wave Washer	1
33	G399 5300	Harness - I/F	2
34	G399 5340	Harness - Motor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0453 3006N	Tapping Screw - M3x6	
103	0720 0040E	Retaining Ring - M4	
104	1105 0192	Locking Support	
105	1102 8309	Connector:IMSA-9715B-12A	
106	1607 0439	Ferrite Core:TR-20-10-5	

3.Frame (G399)



3.Frame (G399)

Index No.	Part No.	Description	Q'ty Per Assembly
1	G555 3125	Spring Plate - Bottom Plate	1
2	G399 3224	Stepped Screw - Connector	2
3	G555 1097	Spring Plate:Earth:Lower	1
4	G555 3222	Pressure Spring	2
5	G555 3120	Paper End Feeler	1
6	AW02 0086	Photointerruptor	1
7	G399 1052	Left Frame	1
8	G555 1092	Grounding Plate	1
9	G399 1070	Upper Frame	1
10	G399 1065	Upper Cover	1
11	G399 1061	Right Frame	1
12	G555 3126	Paper Volume Arm	1
13	G555 3118	Paper Volume Feeler	1
14	G555 3131	Vertical Transport Guide	1
15	G555 1055	Cushion - Frame	2
16	G399 3111	Housing - Paper Feed Unit : Upper	1
17	G399 1082	Lower Frame	1
18	G399 1098	Ground Plate - Right Middle	1
19	G555 1095	Ground Plate:Upper	1
20	G555 1311	Heat Sink	1
21	G399 1096	Ground Plate - Left Middle	1
22	G399 1094	Ground Plate - Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006N	Tapping Screw - 3x6	
102	0450 3008N	Tapping Screw - M3x8	
103	1102 8308	Connector - 12P	

Parts Index

Parts Index

Part No.	Description	Page and Index No.
G399 1052	Left Frame	7 - 7
G399 1061	Right Frame	7 - 11
G399 1065	Upper Cover	7 - 10
G399 1070	Upper Frame	7 - 9
G399 1082	Lower Frame	7 - 17
G399 1094	Ground Plate - Lower	7 - 22
G399 1096	Ground Plate - Left Middle	7 - 21
G399 1098	Ground Plate - Right Middle	7 - 18
G399 3050	Paper Tray Ass'y	3 - 21
G399 3051	Paper Tray - Front	3 - 17
G399 3052	Paper Tray - Rear	3 - 10
G399 3085	Label - Paper Tray : Operate 1	3 - 19
G399 3086	Label - Paper Tray : Operate 2	3 - 8
G399 3087	Label:Protection	3 - 5
G399 3091	Paper Size Detection Plate - EXP	3 - 18
G399 3111	Housing - Paper Feed Unit : Upper	5 - 16
G399 3111	Housing - Paper Feed Unit : Upper	7 - 16
G399 3112	Shaft - Paper Feed	5 - 6
G399 3115	Drive Roller - Middle	5 - 7
G399 3116	Driven Roller - Middle	5 - 9
G399 3210	Push Switch - Paper Size	5 - 19
G399 3223	Interface Board Bracket	5 - 2
G399 3224	Stepped Screw - Connector	7 - 2
G399 3228	Bracket:Motor	5 - 5
G399 3250	Magnetic Clutch - 0.35n.m : Z49	5 - 3
G399 3364	Tray Bottom Plate	3 - 2
G399 3366	Spring - Paper Feed Pressure : 11n	3 - 15
G399 3367	Spring - Tray Bottom Plate : 1.6n	3 - 24
G399 3372	Supporting Plate:Tray Bottom Plate	3 - 28
G399 3373	Holder:Spring:Right	3 - 25
G399 3374	Lever:Spring:Tray Bottom Plate	3 - 23
G399 3375	Holder:Spring:Left	3 - 27
G399 3376	Knob:Tray Bottom Plate	3 - 22
G399 3377	Cover:Knob	3 - 26
G399 5100	PCB - Bank : P4_exp	5 - 1

Part No.	Description	Page and Index No.
G399 5300	Harness - I/F	5 - 33
G399 5320	Harness - Signal	5 - 8
G399 5340	Harness - Motor	5 - 34

Part No.	Description	Page and Index No.
G029 2609	Cassette Protection	3 - 4
G029 2657	Compression Spring	3 - 7
G052 3103	Paper Feed Roller	5 - 15
G096 3071	Paper Tray Arm	3 - 16
G555 1055	Cushion - Frame	7 - 15
G555 1092	Grounding Plate	7 - 8
G555 1095	Ground Plate:Upper	7 - 19
G555 1097	Spring Plate:Earth:Lower	7 - 3
G555 1213	Heat Sink	5 - 28
G555 1216	Heat Sink - Base	5 - 30
G555 1217	Heat Sink:Stepper Motor	5 - 29
G555 1218	Heat Sink - Motor	5 - 31
G555 1311	Heat Sink	7 - 20
G555 3054	Sheet:Paper Tray:Front	3 - 20
G555 3063	Left Side Fence	3 - 1
G555 3064	Right Side Fence	3 - 14
G555 3068	Separation Spring	5 - 18
G555 3069	Basepad	3 - 3
G555 3074	Rear End Fence	3 - 11
G555 3075	Front End Fence	3 - 13
G555 3077	End Fence Spring	3 - 12
G555 3113	Paper Feed Shaft Holder	5 - 17
G555 3117	Roller Holder	5 - 10
G555 3118	Paper Volume Feeler	7 - 13
G555 3119	Transport Detection Feeler	5 - 12
G555 3120	Paper End Feeler	7 - 5
G555 3121	Spring Plate - Shaft	5 - 20
G555 3125	Spring Plate - Bottom Plate	7 - 1
G555 3126	Paper Volume Arm	7 - 12
G555 3127	Feeler Spring	5 - 13
G555 3131	Vertical Transport Guide	7 - 14
G555 3135	Friction Pad:Adhesion	3 - 6
G555 3142	Pressure Spring	5 - 11
G555 3222	Pressure Spring	7 - 4
G555 3245	Gear - 21Z	5 - 24

Part No.	Description	Page and Index No.
G555 3246	Gear - 22Z	5 - 23
G555 3247	Gear - 21Z	5 - 22
G555 3248	Gear - 20Z	5 - 21
G800 3133	Side Fence Gear	3 - 9

Part No.	Description	Page and Index No.
AA08 0252	Bushing - M4	5 - 27
AA08 2101	Bushing - 6x10x6	5 - 25
AW02 0086	Photointerruptor	5 - 14
AW02 0086	Photointerruptor	7 - 6
AX04 0215	Stepper Motor:Mm42:Ud1a	5 - 4

Part No.	Description	Page and Index No.
0450 3008N	Tapping Screw - M3x8	7 - 102
0451 3006N	Tapping Screw - 3x6	5 - 101
0451 3006N	Tapping Screw - 3x6	7 - 101
0453 3006N	Tapping Screw - M3x6	5 - 102
0453 3008N	Binding Self Tapping Screw:3x8	3 - 101
0720 0040E	Retaining Ring - M4	5 - 103
1102 8308	Connector - 12P	7 - 103
1102 8309	Connector:IMSA-9715B-12A	5 - 105
1105 0192	Locking Support	5 - 104
1607 0439	Ferrite Core:TR-20-10-5	5 - 106

