

PT340 (B621)

## **PT340 (B621)**


### **PARTS CATALOG**

This catalog gives the numbers and names of parts on this machine.

|                          |          |
|--------------------------|----------|
| 1.1BIN TRAY (B621) ..... | 2        |
| <b>PARTS INDEX.....</b>  | <b>5</b> |

**October ,16 ' 2003**

## 1.1BIN TRAY (B621)



## 1.1BIN TRAY (B621)

| Index No. | Part No.  | Description                          | Q'ty Per Assembly |
|-----------|-----------|--------------------------------------|-------------------|
| 1         | B621 4490 | Extension Tray                       | 1                 |
| 2         | B621 4497 | Exit Tray                            | 1                 |
| 3         | B621 4498 | Tray Guide Plate                     | 1                 |
| 4         | AX05 0198 | Stepper Motor DC24V                  | 1                 |
| 5         | B621 5256 | Harness - 1bin Drawer                | 1                 |
| 6         | B621 5120 | PCB 1bin                             | 1                 |
| 7         | B621 4456 | Stepper Motor Bracket Ass'y          | 1                 |
| 8         | A869 4457 | Gear - 18Z                           | 1                 |
| 9         | B621 4460 | Bracket Ground Plate                 | 1                 |
| 10        | A869 4458 | Gear - 19Z                           | 1                 |
| 11        | B621 4487 | Tension Spring                       | 1                 |
| 12        | AX11 0097 | DC Solenoid DC24V/6.2W               | 1                 |
| 13        | B621 4484 | Solenoid Lever                       | 1                 |
| 14        | A250 2779 | Pin - M6                             | 1                 |
| 15        | B621 4480 | Torsion Spring                       | 2                 |
| 16        | B621 4478 | Driven Exit Roller                   | 2                 |
| 17        | AW01 0100 | Paper Feed Sensor                    | 1                 |
| 18        | B621 4453 | Exit Roller                          | 1                 |
| 19        | B621 4499 | Discharge Brush Ground Plate         | 1                 |
| 20        | B621 4493 | Upper Cover Sub-ass'y                | 1                 |
| 21        | AA12 0094 | Antistatic Brush                     | 1                 |
| 22        | AA08 2115 | Bushing 5x10x5                       | 1                 |
| 23        | B621 4452 | Paper Feed Sensor                    | 1                 |
| 24        | G020 5626 | Push Switch                          | 1                 |
| 25        | B621 5257 | Harness - Paper Feed Sensor 1bin     | 1                 |
| 26        | B621 4450 | Upper Frame                          | 1                 |
| 27        | B621 5258 | Harness - 1bin LED                   | 1                 |
| 28        | B621 4461 | Magnet Catch Stay                    | 1                 |
| 29        | B621 4481 | Gate Guide                           | 1                 |
| 30        | G800 4851 | Bushing                              | 3                 |
| 31        | AG07 0014 | Magnet Catch                         | 1                 |
| 32        | B621 5254 | Harness - Paper Detector Sensor 1bin | 1                 |
| 33        | B621 4475 | Lower Frame                          | 1                 |
| 34        | B621 4483 | Paper Feed Sensor Cover              | 1                 |
| 35        | B621 4492 | Exit Tray Sub-Ass'y                  | 1                 |

| Index No. | Part No.   | Description                | Q'ty Per Assembly |
|-----------|------------|----------------------------|-------------------|
| 36        | B621 4470  | Decal - Open And Close     | 1                 |
| 37        | B621 4479  | Exit Bushing               | 4                 |
| 101       | 0453 3006B | Tapping Screw - M3x6       |                   |
| 102       | 0450 3008B | Tapping Screw - M3x8       |                   |
| 103       | 0720 0030B | Retaining Ring - M3        |                   |
| 104       | 1105 0516  | Clamp                      |                   |
| 105       | 1105 0511  | Harness Clamp - LWS-0306ZC |                   |
| 106       | 0451 3006B | Tapping Screw - M3x6       |                   |
| 107       | 0450 3008H | Tapping Screw - M3x8       |                   |

# Parts Index

## Parts Index

| Part No.  | Description                          | Page and Index No. |
|-----------|--------------------------------------|--------------------|
| B621 4450 | Upper Frame                          | 3 - 26             |
| B621 4452 | Paper Feed Sensor                    | 3 - 23             |
| B621 4453 | Exit Roller                          | 3 - 18             |
| B621 4456 | Stepper Motor Bracket Ass'y          | 3 - 7              |
| B621 4460 | Bracket Ground Plate                 | 3 - 9              |
| B621 4461 | Magnet Catch Stay                    | 3 - 28             |
| B621 4470 | Decal - Open And Close               | 3 - 36             |
| B621 4475 | Lower Frame                          | 3 - 33             |
| B621 4478 | Driven Exit Roller                   | 3 - 16             |
| B621 4479 | Exit Bushing                         | 3 - 37             |
| B621 4480 | Torsion Spring                       | 3 - 15             |
| B621 4481 | Gate Guide                           | 3 - 29             |
| B621 4483 | Paper Feed Sensor Cover              | 3 - 34             |
| B621 4484 | Solenoid Lever                       | 3 - 13             |
| B621 4487 | Tension Spring                       | 3 - 11             |
| B621 4490 | Extension Tray                       | 3 - 1              |
| B621 4492 | Exit Tray Sub-Ass'y                  | 3 - 35             |
| B621 4493 | Upper Cover Sub-ass'y                | 3 - 20             |
| B621 4497 | Exit Tray                            | 3 - 2              |
| B621 4498 | Tray Guide Plate                     | 3 - 3              |
| B621 4499 | Discharge Brush Ground Plate         | 3 - 19             |
| B621 5120 | PCB 1bin                             | 3 - 6              |
| B621 5254 | Harness - Paper Detector Sensor 1bin | 3 - 32             |
| B621 5256 | Harness - 1bin Drawer                | 3 - 5              |
| B621 5257 | Harness - Paper Feed Sensor 1bin     | 3 - 25             |
| B621 5258 | Harness - 1bin LED                   | 3 - 27             |

| Part No.  | Description | Page and Index No. |
|-----------|-------------|--------------------|
| A250 2779 | Pin - M6    | 3 - 14             |
| A869 4457 | Gear - 18Z  | 3 - 8              |
| A869 4458 | Gear - 19Z  | 3 - 10             |
| G020 5626 | Push Switch | 3 - 24             |
| G800 4851 | Bushing     | 3 - 30             |

| Part No.  | Description            | Page and Index No. |
|-----------|------------------------|--------------------|
| AA08 2115 | Bushing 5x10x5         | 3 - 22             |
| AA12 0094 | Antistatic Brush       | 3 - 21             |
| AG07 0014 | Magnet Catch           | 3 - 31             |
| AW01 0100 | Paper Feed Sensor      | 3 - 17             |
| AX05 0198 | Stepper Motor DC24V    | 3 - 4              |
| AX11 0097 | DC Solenoid DC24V/6.2W | 3 - 12             |

| Part No.   | Description                | Page and Index No. |
|------------|----------------------------|--------------------|
| 0450 3008B | Tapping Screw - M3x8       | 3 -102             |
| 0450 3008H | Tapping Screw - M3x8       | 3 -107             |
| 0451 3006B | Tapping Screw - M3x6       | 3 -106             |
| 0453 3006B | Tapping Screw - M3x6       | 3 -101             |
| 0720 0030B | Retaining Ring - M3        | 3 -103             |
| 1105 0511  | Harness Clamp - LWS-0306ZC | 3 -105             |
| 1105 0516  | Clamp                      | 3 -104             |