

RT36 (A683)

This parts catalog includes MB No. 1

RT36 (A683)

PARTS CATALOG


This catalog gives the numbers and names of parts on this machine.

CONTENTS

1.EXTERIOR (A683)	2
2.PAPER REGISTRATION (A683)	4
3.PAPER TRAY (A683).....	6
4.FRAME SECTION (A683).....	8
5.DRIVE AND ELECTRICAL SECTION (A683)	10
PARTS INDEX	13

January ,30 ' 2001

1.EXTERIOR (A683)




1.EXTERIOR (A683)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA14 3503	Positioning Pin	2
2	AA14 3504	Coupling Screw	4
3	AA14 3481	Guide Pin Shaft	4
4	AA08 0236	Bushing	2
5	AA06 3571	Compression Spring	2
6	AF02 0420	Driven Roller	1
7	AA14 3482	Screw - M3	2
8	A683 2700	Vertical Transport Guide	1
9	A683 2711	Switch Lever	1
10	A683 1285	Magnetic Catch Cover	1
11	AA06 3572	Compression Spring	4
12	A683 2710	Entrance Guide - Vertical Transport	1
13	A683 1250	Front Cover	1
14	A683 1260	Lower Right Cover	1
15	A683 1275	Upper Right Cover	1
16	A683 1281	Magnetic Catch Bracket	1
17	5447 2681	Snap Ring	1
18	A683 1280	Hinge Bracket	1
19	A683 1265	Upper Cover	1
20	A683 2900	Decal - Paper Handling	1
21	A683 1255	Rear Cover	1
22	A680 4223	Cushion	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0450 3008B	Tapping Screw - M3x8	
102	0451 3008H	Tapping Screw - 3x8	

2.PAPER REGISTRATION (A683)




2.PAPER REGISTRATION (A683)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5053 0223	Bushing - 8mm	3
2	AW02 0107	Photointerruptor	1
3	A683 2632	Sensor Bracket	1
4	A683 2675	Support Plate - Upper Stay	1
5	A380 2460	Pick-up Release Spring	1
6	5053 0447	Bushing - 6mm	3
7	A683 2625	Pickup Solenoid	1
8	AA06 0636	Pressure Spring	1
9	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
10	A683 2622	Sensor Bracket	1
11	AW02 0101	Photointerruptor	1
12	A683 2670	Upper Stay	1
13	AA14 0669	Feed Roller Shaft	1
14	AA06 0741	Pressure Spring	1
15	AA08 3015	Roller Clutch	1
16	AF03 1021	Paper Feed Roller	1
17	5215 2621	Snap Ring - M6	1
18	5447 2706	Gear - 15T	1
19	5447 2681	Snap Ring	2
20	AF03 0021	Pick-up Roller	1
21	A380 2211	Pick-up Arm	1
22	AA06 3571	Compression Spring	2
23	AF02 0420	Driven Roller	1
24	AA08 0236	Bushing	2
25	A683 2681	Upper Guide Plate - Transport	1
26	A683 2685	Lower Guide Plate - Transport	1
27	AF02 0419	Transport Drive Roller	1
28	H516 3625	Spacer - 10x18x2mm	2
29	AF03 2021	Separation Roller	1
30	A134 2885	Torque Limiter	1
31	A683 2650	Feed Roller Base	1
32	A683 2668	Reverse Roller Shaft	1
33	A683 2667	Drive Shaft - Reverse Roller	1
34	AB01 3420	Gear - 18Z	2
35	A683 2666	Pressure Lever	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060E	Retaining Ring - M6	
103	1105 0328	Harness Clamp - ES-0505	
104	1105 0267	Harness Clamp - YMC-10-0	
105	0720 0040E	Retaining Ring - M4	
106	0802 5265	Tapping Screw - M3x6	

3.PAPER TRAY (A683)




3.PAPER TRAY (A683)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A667 2660	Belt Stopper	2
2	AA04 3259	Timing Belt	2
3	AB03 0548	Pulley - 16T	4
4	A335 4351	Guide Roller	4
5	A667 2654	Front Tray Bracket	1
6	A667 2655	Rear Tray Bracket	1
7	5053 0223	Bushing - 8mm	2
8	A683 5320	LCT Main Harness	1
9	A683 2743	Safty Switch Lever	1
10	A683 2741	Safty Switch Bracket	1
11	A683 2742	Plate Spring - Safty Switch	1
12	A683 2750	Front Side Fence	1
13	A667 2644	Supporter - Side Fence	4
14	AX04 0098	Motor - DC 12W	1
15	AB01 4023	Gear - 45z	1
16	A155 5170	Push Switch	1
17	A421 2543	Friction Pad	3
18	AF01 1041	Paper Tray	1
19	A667 2653	Paper Stopper	1
20	A048 2838	Nylon Rivet	1
21	A683 2755	Rear Side Plate	1
22	AA00 2010	Decal - Paper Level	1
23	A683 2585	Support Plate	1
24	A683 2746	Sensor Bracket	1
25	AW02 0056	Photointerruptor - EE-SX4235A-P1	1
26	AA14 5561	Tray Drive Shaft	1
27	A683 2758	Guide Plate	2
28	A683 2550	Side Plate : Front (MB1 ADDED)	1
29	A683 2560	Side Plate : Rear (MB1 ADDED)	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0451 3006B	Tapping Screw - M3x6	
102	0720 0060E	Retaining Ring - M6	
103	0450 3008W	Philips Tapping Screw - M3x8	
104	0633 0140G	Parallel Pin - 3x14	
105	0450 4020B	Tapping Screw - 4x20	
106	1204 2356	Micro Switch - AM51612A531	
107	0633 0180G	Parallel Pin - 3x18mm	
108	0451 4008B	Philips Tapping Screw - M4x8	
109	0313 0180B	Philips Pan Head Screw - M3x18	

4.FRAME SECTION (A683)




4.FRAME SECTION (A683)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A683 2577	Guide Plate Cushion	2
2	AA07 0041	Slide Rail	2
3	A683 1085	Rear Base Racket	1
4	A683 1080	Front Base Bracket	1
5	A683 2575	Guide Plate	1
6	A667 1255	LCT Knob	1
7	A683 2811	Handle Collar	1
8	A667 2571	Lock Lever	2
9	AA06 6294	Torsion Spring	1
10	A007 2757	Sector Gear Bushing	2
11	A007 2756	Bushing - Volume Sensor Shaft	2
12	A683 2813	Front Lock Lever	1
13	A683 2576	Guide Plate - Feed Roller	1
14	A683 2581	Lower Stay	1
15	AG07 0004	Magnetic Catch	1
16	AA06 6295	Torsion Spring	1
17	A683 2812	Lock Stay	1
18	A683 1301	Decal - Model Name Plate (LANIER)	1
			

Index No.	Part No.	Description	Q'ty Per Assembly
101	0453 3005B	Tapping Bind Screw - M3x5	
102	0451 3006B	Tapping Screw - M3x6	
103	0451 3010B	Tapping Screw - M3x10	
104	1105 0310	Harness Clamp - LWS-1S	
105	0451 3008B	Tapping Screw - M3x8	
106	1106 0458	Bushing - 9.9mm	

5.DRIVE AND ELECTRICAL SECTION (A683)



5.DRIVE AND ELECTRICAL SECTION (A683)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A683 1282	Hinge	1
2	A683 5110	LCT Interface Board	1
3	A683 5320	LCT Main Harness	1
4	A683 5310	Interface Harness	1
5	AW02 0056	Photointerruptor - EE-SX4235A-P1	5
6	A667 2666	Sensor Bracket	1
7	AX06 0140	Brushless Motor - DC24V 12.3W	1
8	A683 2695	Motor Bracket	1
9	AB01 7462	Gear - 49Z/21Z	1
10	AB01 4059	Idler Gear - 31Z	1
11	5215 2621	Snap Ring - M6	2
12	AX20 0138	Electrical Clutch	2
13	AB01 7470	Gear - 31Z/37Z	1
14	AB01 4057	Drive Gear - 34Z	1
15	AB01 7463	Gear - 47Z/24Z	1
16	A683 2831	Sensor Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	1105 0113	Edge - P108	
102	0451 4008B	Philips Tapping Screw - M4x8	
103	1105 0291	Harness Clamp - LWS-3S	
104	0451 3006B	Tapping Screw - M3x6	
105	1106 0132	Cord Stopper	
106	1105 0310	Harness Clamp - LWS-1S	
107	1105 0348	Clamp	
108	1105 0267	Harness Clamp - YMC-10-0	
109	0720 0040E	Retaining Ring - M4	
110	1107 0392	Fuse - 6.3A 125V	

Parts Index

PM Parts Index

Section Name	Part No.	Description in Service Manual	Description in Parts Catalog	Q'ty Per Assembly	Page and Index No.
PAPER REGISTRATION (A683)	AF03 1021	Feed Roller	Paper Feed Roller	1	5- 16
	AF03 0021	Pick-up Roller	Pick-up Roller	1	5- 20
	AF03 2021	Separation Roller	Separation Roller	1	5- 29

Parts Index

Part No.	Description	Page and Index No.
A683 1080	Front Base Bracket	9- 4
A683 1085	Rear Base Racket	9- 3
A683 1250	Front Cover	3- 13
A683 1255	Rear Cover	3- 21
A683 1260	Lower Right Cover	3- 14
A683 1265	Upper Cover	3- 19
A683 1275	Upper Right Cover	3- 15
A683 1280	Hinge Bracket	3- 18
A683 1281	Magnetic Catch Bracket	3- 16
A683 1282	Hinge	11- 1
A683 1285	Magnetic Catch Cover	3- 10
A683 1301	Decal - Model Name Plate (LANIER)	9- 18
A683 2550	Side Plate : Front (MB1 ADDED)	7- 28
A683 2560	Side Plate : Rear (MB1 ADDED)	7- 29
A683 2575	Guide Plate	9- 5
A683 2576	Guide Plate - Feed Roller	9- 13
A683 2577	Guide Plate Cushion	9- 1
A683 2581	Lower Stay	9- 14
A683 2585	Support Plate	7- 23
A683 2622	Sensor Bracket	5- 10
A683 2625	Pickup Solenoid	5- 7
A683 2632	Sensor Bracket	5- 3
A683 2650	Feed Roller Base	5- 31
A683 2666	Pressure Lever	5- 35
A683 2667	Drive Shaft - Reverse Roller	5- 33
A683 2668	Reverse Roller Shaft	5- 32
A683 2670	Upper Stay	5- 12
A683 2675	Support Plate - Upper Stay	5- 4
A683 2681	Upper Guide Plate - Transport	5- 25
A683 2685	Lower Guide Plate - Transport	5- 26
A683 2695	Motor Bracket	11- 8
A683 2700	Vertical Transport Guide	3- 8
A683 2710	Entrance Guide - Vertical Transport	3- 12
A683 2711	Switch Lever	3- 9
A683 2741	Safty Switch Bracket	7- 10

Part No.	Description	Page and Index No.
A683 2742	Plate Spring - Safty Switch	7- 11
A683 2743	Safty Switch Lever	7- 9
A683 2746	Sensor Bracket	7- 24
A683 2750	Front Side Fence	7- 12
A683 2755	Rear Side Plate	7- 21
A683 2758	Guide Plate	7- 27
A683 2811	Handle Collar	9- 7
A683 2812	Lock Stay	9- 17
A683 2813	Front Lock Lever	9- 12
A683 2831	Sensor Bracket	11- 16
A683 2900	Decal - Paper Handling	3- 20
A683 5110	LCT Interface Board	11- 2
A683 5310	Interface Harness	11- 4
A683 5320	LCT Main Harness	7- 8
A683 5320	LCT Main Harness	11- 3

Part No.	Description	Page and Index No.
AA00 2010	Decal - Paper Level	7- 22
AA04 3259	Timing Belt	7- 2
AA06 0636	Pressure Spring	5- 8
AA06 0741	Pressure Spring	5- 14
AA06 3571	Compression Spring	5- 22
AA06 3571	Compression Spring	3- 5
AA06 3572	Compression Spring	3- 11
AA06 6294	Torsion Spring	9- 9
AA06 6295	Torsion Spring	9- 16
AA07 0041	Slide Rail	9- 2
AA08 0236	Bushing	3- 4
AA08 0236	Bushing	5- 24
AA08 3015	Roller Clutch	5- 15
AA14 0669	Feed Roller Shaft	5- 13
AA14 3481	Guide Pin Shaft	3- 3
AA14 3482	Screw - M3	3- 7
AA14 3503	Positioning Pin	3- 1
AA14 3504	Coupling Screw	3- 2
AA14 5561	Tray Drive Shaft	7- 26
AB01 3420	Gear - 18Z	5- 34
AB01 4023	Gear - 45z	7- 15
AB01 4057	Drive Gear - 34Z	11- 14
AB01 4059	Idler Gear - 31Z	11- 10
AB01 7462	Gear - 49Z/21Z	11- 9
AB01 7463	Gear - 47Z/24Z	11- 15
AB01 7470	Gear - 31Z/37Z	11- 13
AB03 0548	Pulley - 16T	7- 3
AF01 1041	Paper Tray	7- 18
AF02 0419	Transport Drive Roller	5- 27
AF02 0420	Driven Roller	3- 6
AF02 0420	Driven Roller	5- 23
AF03 0021	Pick-up Roller	5- 20
AF03 1021	Paper Feed Roller	5- 16
AF03 2021	Separation Roller	5- 29
AG07 0004	Magnetic Catch	9- 15

Part No.	Description	Page and Index No.
AW02 0056	Photointerruptor - EE-SX4235A-P1	11- 5
AW02 0056	Photointerruptor - EE-SX4235A-P1	5- 9
AW02 0056	Photointerruptor - EE-SX4235A-P1	7- 25
AW02 0101	Photointerruptor	5- 11
AW02 0107	Photointerruptor	5- 2
AX04 0098	Motor - DC 12W	7- 14
AX06 0140	Brushless Motor - DC24V 12.3W	11- 7
AX20 0138	Electrical Clutch	11- 12
H516 3625	Spacer - 10x18x2mm	5- 28

Part No.	Description	Page and Index No.
A007 2756	Bushing - Volume Sensor Shaft	9- 11
A007 2757	Sector Gear Bushing	9- 10
A048 2838	Nylon Rivet	7- 20
A134 2885	Torque Limiter	5- 30
A155 5170	Push Switch	7- 16
A335 4351	Guide Roller	7- 4
A380 2211	Pick-up Arm	5- 21
A380 2460	Pick-up Release Spring	5- 5
A421 2543	Friction Pad	7- 17
A667 1255	LCT Knob	9- 6
A667 2571	Lock Lever	9- 8
A667 2644	Supporter - Side Fence	7- 13
A667 2653	Paper Stopper	7- 19
A667 2654	Front Tray Bracket	7- 5
A667 2655	Rear Tray Bracket	7- 6
A667 2660	Belt Stopper	7- 1
A667 2666	Sensor Bracket	11- 6
A680 4223	Cushion	3- 22

Part No.	Description	Page and Index No.
5053 0223	Bushing - 8mm	5- 1
5053 0223	Bushing - 8mm	7- 7
5053 0447	Bushing - 6mm	5- 6
5215 2621	Snap Ring - M6	5- 17
5215 2621	Snap Ring - M6	11- 11
5447 2681	Snap Ring	3- 17
5447 2681	Snap Ring	5- 19
5447 2706	Gear - 15T	5- 18

Part No.	Description	Page and Index No.
0313 0180B	Philips Pan Head Screw - M3x18	7-109
0450 3008B	Tapping Screw - M3x8	3-101
0450 3008W	Philips Tapping Screw - M3x8	7-103
0450 4020B	Tapping Screw - 4x20	7-105
0451 3006B	Tapping Screw - M3x6	11-104
0451 3006B	Tapping Screw - M3x6	9-102
0451 3006B	Tapping Screw - M3x6	7-101
0451 3006B	Tapping Screw - M3x6	5-101
0451 3008B	Tapping Screw - M3x8	9-105
0451 3008H	Tapping Screw - 3x8	3-102
0451 3010B	Tapping Screw - M3x10	9-103
0451 4008B	Philips Tapping Screw - M4x8	7-108
0451 4008B	Philips Tapping Screw - M4x8	11-102
0453 3005B	Tapping Bind Screw - M3x5	9-101
0633 0140G	Parallel Pin - 3x14	7-104
0633 0180G	Parallel Pin - 3x18mm	7-107
0720 0040E	Retaining Ring - M4	11-109
0720 0040E	Retaining Ring - M4	5-105

Part No.	Description	Page and Index No.
0720 0060E	Retaining Ring - M6	7-102
0720 0060E	Retaining Ring - M6	5-102
0802 5265	Tapping Screw - M3x6	5-106
1105 0113	Edge - P108	11-101
1105 0267	Harness Clamp - YMC-10-0	5-104
1105 0267	Harness Clamp - YMC-10-0	11-108
1105 0291	Harness Clamp - LWS-3S	11-103
1105 0310	Harness Clamp - LWS-1S	9-104
1105 0310	Harness Clamp - LWS-1S	11-106
1105 0328	Harness Clamp - ES-0505	5-103
1105 0348	Clamp	11-107
1106 0132	Cord Stopper	11-105
1106 0458	Bushing - 9.9mm	9-106
1107 0392	Fuse - 6.3A 125V	11-110
1204 2356	Micro Switch - AM51612A531	7-106