

RT41 (A659)

PARTS CATALOG

INTRODUCTION


This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

LOCATION OF UNIT	2
1.EXTERIOR (A659)	4
2.UPPER TRANSPORT SECTION (A659)	6
3.ELECTRICAL SECTION (A659).....	8
4.FRAME SECTION (A659)	10
5.PAPER FEED SECTION (A659)	12
6.LCT TRAY (A659)	14
7.DRIVE SECTION (A659).....	16
8.TRANSPORT SECTION (A659).....	20
9.DECAL AND DOCUMENT (659).....	22
PARTS INDEX	25


LOCATION OF UNIT

1.EXTERIOR (A659)




See Page 5

2.UPPER TRANSPORT SECTION (A659)




See Page 7

3.ELECTRICAL SECTION (A659)




See Page 9

4.FRAME SECTION (A659)




See Page 11

5.PAPER FEED SECTION (A659)





See Page 13

6.LCT TRAY (A659)




See Page 15

LOCATION OF UNIT

7.DRIVE SECTION (A659)  See Page 17	8.TRANSPORT SECTION (A659)  See Page 19	

1.EXTERIOR (A659)




1.EXTERIOR (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 1286	Upper Rear Cover	1
2	A659 1291	Lower Rear Cover	1
3	A659 1277	Side Cover Ass'y	1
4	A029 1413	Cap	2
5	A659 1315	Rear Supporting Plate	1
6	A659 1211	Upper Cover	1
7	A461 6251	Cushion	1
8	A659 1271	Grip Cover	1
9	AG07 1009	Rotary Catch	1
10	A659 1326	Front Cover - Small	1
11	A659 1256	Upper Front Cover	1
12	A659 2611	Decal - Misfeed Removal	1
13	A659 1272	Door Catch	1
14	A659 1274	Shaft - Cover	2
15	A659 1273	Bracket - Cover	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0313 0060B	Philips Pan Head Screw - M3x6	
104	0951 3006B	Philips Screw With Flat Washer - M3x6	
105	0720 0030E	Retaining Ring - M3	

2.UPPER TRANSPORT SECTION (A659)




2.UPPER TRANSPORT SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 1530	Upper Guide Plate	1
2	A459 1537	Left Mounting Plate - Transport	1
3	A459 1565	Mounting Plate Collar	1
4	A459 1547	Upper Roller	1
5	5887 4155	Shaft Guide - Turn Driven	2
6	5887 4156	Spring - Driven Roller	2
7	A459 1570	Antistatic Brush	1
8	A459 1536	Right Mounting Plate - Transport	1
9	5875 2088	Shoulder Screw - M4	2
10	6802 5703	Grounding Wire	2
11	A659 1539	Entrance Guide Plate	1
12	A459 1525	Transport Lower Guide	1
13	5403 2048	Bushing - 4mm	1
14	A420 3699	Magnet Catch Ass'y	3
15	A459 1566	Stepped Screw	1
16	A459 1546	Transport Drive Roller	2
17	A459 1545	Exit Roller	1
18	A659 1521	Stay - Side Plate	1
19	A459 5410	Photo Sensor - PS PC05	1
20	A659 5340	Harness - Jam Removal	1
21	A659 1510	Front Side Plate - Transport	1
22	A659 1311	Cover - Safety Switch	1
23	A659 1522	Stay - Side Plate	1
24	A659 1515	Rear Side Plate - Transport	1
25	A459 1557	Collar	1
26	A459 1555	Pulley - 22Z	1
27	A459 1558	Timing Belt - 710P2M6	1
28	A458 3281	Idler Roller	1
29	A459 1553	Pulley - 24Z	2
30	5403 1910	Spring Anchor - Stopper Lever	1
31	AB03 0543	Pulley - 30T/37T	1
32	5918 2321	Timing Belt Tightner	1
33	5894 3175	Spring	1
34	AX06 0132	Brushress Motor - 7.8W	1
35	A659 1571	Bracket - Transport Motor	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AB01 4003	Gear - 25Z	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0741 3706	Ball Bearing - 6x10x3	
103	0574 0060E	Hexagon Headless Set Screw - M4x6	
104	0805 3365	Bushing - 8x14mm	
105	0720 0060E	Retaining Ring - M6	
106	0720 0040E	Retaining Ring - M4	
107	0574 0050E	Hexagon Headless Set Screw - M4x5	
108	0805 3145	Ball Bearing - 6x12x4mm	
109	1106 0200	Bushing - 19.44mm	
110	1105 0196	Harness Clamp	
111	0313 0100B	Philips Pan Head Screw - M3x10	

3.ELECTRICAL SECTION (A659)




3.ELECTRICAL SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 1310	Bracket - Safety Switch	1
2	A659 5315	Harness Bracket	1
3	A659 2510	Connector Bracket	1
4	A459 2511	Connector Bracket	1
5	5424 2625	Spring - Connector	2
6	5446 5832	Connector Guide Pin	2
7	A659 2524	Inner Cover - PCB	1
8	A028 5155	Paper Feed Control Board	1
9	A659 5212	Harness Bracket	1
10	A659 5320	Harness - Joint 2	1
11	A659 5330	Relay Harness	1
12	A659 5311	Coupling Harness	1
13	A659 5100	Interfase Board - LCT	1
14	A659 5500	Transformer - 200VA 37V	1
15	A659 2520	Bracket - PCB	1
16	A659 2521	Harness Cover - Transformer	1
17	A459 5220	LCT Sub Control Board	1
18	A659 5150	Interface Board - Brushless Motor	1
19	A659 5370	Harness - Brushless Motor	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	1204 2375	Safety Switch	
103	1106 0459	Bushing - 20.2mm	
104	1106 0430	Bushing - 13mm	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	1105 0193	Nylon Stud	
107	1105 0409	Spacer	
108	1105 0462	Harness Clamp	
109	1106 0200	Bushing - 19.44mm	
110	1105 0196	Harness Clamp	
111	1005 0383	Edging - B	
112	1105 0035	Nylon Clamp - 9n	
113	1105 0010	Nylon Clamp - 6n	
114	1107 0753	Fuse (Glass Case) - 6.3A - 250V	
115	0313 0060B	Philips Pan Head Screw - M3x6	
116	1005 0509	Bushing No.4, 12	
117	1106 0132	Cord Stopper	

4.FRAME SECTION (A659)




4.FRAME SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 1130	Rail Bracket - Left	1
2	5938 2763	Slide Guide	3
3	A659 1120	Joint Stay - Left	1
4	A659 1123	Release Plate	1
5	AA14 3062	Shoulder Screw - M4	2
6	A659 1129	Flat Screw	1
7	A659 1128	Lock Release Arm	1
8	C203 5020	Spring - Feed Roller Pressure	1
9	5413 1882	Stepped Screw	1
10	A659 1136	Rail Bracket - Lower Left	1
11	A459 2340	LCT Stopper Plate	1
12	5446 2560	Cushion - Paper Tray	1
13	A659 1126	Rail Bracket - Right	1
14	AH01 1001	Stand	2
15	A659 1110	Right Stay - Base	1
16	A659 1150	Joint Pin - M8	2
17	A659 2331	Guide Plate - Click	1
18	5446 2566	Detent Arm	1
19	5446 2569	Spring - Detent	1
20	5446 2567	Detent Arm Shaft	1
21	A659 1140	Bracket - Left Frame	1
22	A659 1135	Bracket - Paper Feed Frame	1
23	A659 1142	Left Frame Bracket	1
24	A659 1655	Stay - Drive	1
25	A459 1672	Pressure Plate	1
26	5887 4156	Spring - Driven Roller	1
27	A459 1565	Mounting Plate Collar	1
28	A459 1673	Connector Bracket	1
29	A659 5381	Moter Harness	1
30	5424 2625	Spring - Connector	2
31	5446 5832	Connector Guide Pin	2
32	A659 1671	Bracket - Magnetic Clutch	1
33	AA14 5528	Shaft - Stay	1
34	AB01 3229	Gear - 30Z	1
35	A459 1675	Timing Belt - 400P2M6	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A659 1665	Magnetic Clutch	1
37	5887 4156	Spring - Driven Roller	1
38	A659 1279	Cover Cushion - Front	2
101	1105 0196	Harness Clamp	
102	1005 0383	Edging - B	
103	0951 4006B	Philips Screw With Washer - M4x6	
104	0805 3307	Ball Bearing - 8x14x4mm	
105	0720 0060E	Retaining Ring - M6	
106	0720 0040E	Retaining Ring - M4	
107	0313 0200W	Philips Pan Head Screw - M3x20	
108	0314 0060B	Philips Pan Head Screw - M4x6	
109	0354 0060F	Philips Pan Head Screw - M4x6	
110	0951 4010W	Philips Screw With Flatwasher - M4x10	
111	0805 5003	Caster	
112	0315 0080W	Philips Pan Head Screw - M5x8	

5.PAPER FEED SECTION (A659)




5.PAPER FEED SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A201 5417	Harness - Paper Feed	1
2	A028 3151	Paper Feed Stay	1
3	A028 3166	Spring Suppoter	1
4	AA06 0137	Pick-up Spring	1
5	5447 2768	Stepped Screw - M3	1
6	A201 3169	Pick-up Adjusting Lever	1
7	A028 3173	Paper Feed Solenoid	1
8	A028 3172	Solenoid Bracket	1
9	A028 3264	Stopper Cushion	2
10	5205 5250	LED Sensor Type S	1
11	A659 1635	Feed Cover	1
12	A028 3131	Upper Grip Roller	1
13	A028 3122	Paper Feed Front Side Plate	1
14	A659 1610	Separation Bracket	1
15	5206 2686	Snap Ring	3
16	AF03 1053	Paper Feed Roller	1
17	5205 2594	Gear - 18T	1
18	AF03 1052	Pick-up Roller	1
19	5447 2706	Gear - 15T	1
20	A028 3160	Pick-up Guide	1
21	A028 3157	Pick-up Arm	1
22	A028 3161	Paper Feed Stopper	1
23	AA14 0148	Feed Roller Shaft	1
24	AA06 0139	Spring	1
25	AF02 0071	Grip Roller	1
26	A459 1620	Rear Side Plate	1
27	A028 3148	Paper Feed Control Board Cover	1
28	A028 5160	Registration Sensor Board	1
29	5446 2824	Screw - Duplex Guide Plate	4
30	AB01 3222	Gear - 20Z	1
31	AB01 3220	Gear - 20Z	1
32	AB01 3230	Gear - 40Z	1
33	A028 3008	Drive Motor Joint	1
34	A028 3176	Paper Feed Motor Bracket	1
35	A028 5322	Paper Feed Motor - DC3V 2.25W	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AA14 8511	Separation Drive Shaft	1
37	A201 3100	Separator Stay	1
38	A459 1630	Upper Feed Guide	1
39	A028 3146	Paper Feed Guide Spacer	2
40	AB01 0093	Gear - 18Z	2
41	A459 1625	Lower Feed Guide	1
42	AA14 0146	Paper Feed Guide Shaft	1
43	A028 3142	Feed Sensor Guide	1
44	AF03 1054	Reverse Roller	1
45	A201 3119	Sepasetor Shaft	1
46	AA06 0753	Spring	1
47	A201 3116	Sepasetor Pressure Arm	1
48	A028 3168	Spring Slider	1
49	AB01 3231	Gear - 21Z	1
50	A112 3111	Separation Torque Limiter	1
51	A201 3121	Stopper - Pressure	1
52	A201 2815	Solenoid Bracket	1
53	A201 2813	Keep Solenoid - DC 24V	1
54	A201 2809	Shaft Lever	1
55	AA06 2250	Spring	1
56	AA06 3059	Spring	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0314 0080B	Philips Pan Head Screw - M4x8	
103	0314 0100B	Philips Pan Head Screw - M4x10	
104	0313 0060B	Philips Pan Head Screw - M3x6	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	0720 0040E	Retaining Ring - M4	
107	0720 0060E	Retaining Ring - M6	
108	0805 3307	Ball Bearing - 8x14x4mm	
109	0805 3042	Ball Bearing - 6x10x3mm	
110	1105 0005	Nylon Clamp - 3n	
111	0573 0050E	Hexagon Headless Set Screw - M3x5	

6.LCT TRAY (A659)




6.LCT TRAY (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 2030	End Fence	1
2	A459 2345	LCT Stopper Bracket	1
3	A459 2346	Stopper	1
4	5415 2642	Lock Arm	1
5	A459 2341	Stopper Pin	1
6	A659 2326	Small Cover - Front	1
7	5446 2638	Decal - Paper Lower Limit	1
8	A659 2327	Small Cover - Rear	1
9	AA14 3473	Guide Pin	1
10	A459 2611	Decal - Sensor Size	1
11	A659 5300	Harness - Drawer	1
12	5216 5245	Photointerruptor - II-G-3P-S3T2-E	1
13	A659 2280	Side Fence Holder	1
14	5201 2858	Friction Pad	1
15	A659 2070	Table - Tray	1
16	A459 5400	LCT Operation Board	1
17	A659 2610	Decal - Paper Setting	1
18	A659 1271	Grip Cover	1
19	A659 1215	LCT Cover Ass'y	1
20	A459 2310	Paper End Feeler	1
21	A459 2312	Paper End Feeler Bracket	1
22	A008 2626	Paper End Actuator	1
23	A659 2325	Side Cover	1
24	A459 2335	LCT Guide Plate	1
25	A659 2250	Front Side Fence Ass'y	1
26	A459 2607	Decal - Front Side Fence	1
27	A459 2605	Decal - Fence	1
28	A659 2210	Back Fence Bracket	1
29	A459 2221	Guide Shaft Bracket	1
30	AB03 0544	Back Fence Pulley - Driven	1
31	AA04 3258	Timing Belt - Back Fence	1
32	A659 2235	Back Fence Cover	1
33	AB03 0545	Back Fence Pulley - Drive	1
34	AA14 0633	Guide Shaft	1
35	A459 5410	Photo Sensor - PS PC05	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A459 2606	Decal - Back Fence	1
37	A459 2216	Back Fence Sensor Plate	1
38	A659 2214	Bracket - Back Fence Drive	1
39	A423 5410	DC Motor - 24V 2.9W	1
40	5205 6575	Side Fence Mylar - Front	1
41	A459 2273	Side Fence Pad	2
42	A659 2608	Decal - Side Fence	1
43	A659 2253	Rear Side Fence - Ass'y	1
44	A459 2272	Front Paper Holder	2
45	A459 2275	Rear Paper Holder	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0354 0060F	Philips Pan Head Screw - M4x6	
103	0344 0060F	Philips Truss Head Screw - M4x6	
104	0313 0100B	Philips Pan Head Screw - M3x10	
105	0951 4006B	Philips Screw With Washer - M4x6	
106	0951 4008B	Philips Screw With Washer - M4x8	
107	0574 0050E	Hexagon Headless Set Screw - M4x5	
108	0720 0030E	Retaining Ring - M3	
109	0710 0050B	Hexagon Nut - M5	
110	1105 0229	Clamp	
111	0433 0062W	Hexagon Head Tapping Screw - M3x6	

7.DRIVE SECTION (A659)




7.DRIVE SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 2090	Bushed Chain - Left	2
2	A659 2068	Left Supporting Plate - Sprocket	2
3	A459 2057	Sprocket - 13z	8
4	A459 2056	Sprocket Shaft	8
5	A659 2020	Front Side Plate - Tray	1
6	A459 2095	Tightener Spring	4
7	A659 2065	Sprocket Tightener - Left	2
8	AB01 4005	Gear - 27Z	1
9	AB02 3069	Sprocket - 14t	4
10	AB01 4004	Gear - 27Z	1
11	A659 2060	Sprocket Tightener	2
12	A659 2067	Right Supporting Plate - Sprocket	2
13	A659 2089	Bushed Chain - Right	2
14	A659 2087	Paper End Bracket	1
15	A459 5410	Photo Sensor - PS PC05	1
16	A659 2081	Table Front Shaft	1
17	A659 2082	Table Rear Shaft	1
18	AA14 0632	Lift Driven Shaft	1
19	AA14 0631	Shaft - Table Drive	1
20	A659 2025	Rear Side Plate - Tray	1
21	A659 2281	Holder Bracket - Left	2
22	A459 2316	Paper End Switch Bracket	2
23	5219 5908	Stay - Main Motor	1
24	AX06 0015	DC Motor - DC/42W	1
25	A459 2110	Lift Motor Bracket	1
26	AA16 1104	Cushion - Motor	4
27	6802 5703	Grounding Wire	1
28	A459 2119	Pulley - 22Z	1
29	A459 2124	Pulley - 20Z	1
30	5205 5250	LED Sensor Type S	1
31	A459 2118	Pulley - 50Z	1
32	A459 2135	Timing Belt - 264P3M10	1
33	5446 5463	Dehumidity Heater	1
34	A459 2117	Worm Wheel Shaft	1
35	A459 2116	Worm Wheel	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A459 2140	Pulse Generator	1
37	A459 2121	Worm Gear Collar	1
38	A459 2115	Worm Gear	1
39	A459 2120	Guide Shaft	1
40	A459 2111	Pulse Generator Bracket	1
41	A659 5300	Harness - Drawer	1
42	A459 2512	Connector Bracket	1
43	A659 2010	LCT Base	1
44	A459 2290	Heater Cover	1

7.DRIVE SECTION (A659)




7.DRIVE SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0345 0080Z	Philips Pan Head Screw - M5x8	
103	0313 0100B	Philips Pan Head Screw - M3x10	
104	0951 5008B	Philips Screw With Washer - M5x8	
105	0313 0140B	Philips Pan Head Screw - M3x14	
106	0314 0100B	Philips Pan Head Screw - M4x10	
107	0314 0080B	Philips Pan Head Screw - M4x8	
108	0951 4012B	Philips Screw With Flat Washer	
109	1105 0005	Nylon Clamp - 3n	
110	0951 4006B	Philips Screw With Washer - M4x6	
111	0741 3508	Bushing - 8x14x4mm	
112	0574 0050E	Hexagon Headless Set Screw - M4x5	
113	0575 0060E	Hexagon Headless Set Screw - M5x6	
114	0720 0040E	Retaining Ring - M4	
115	0720 0050E	Retaining Ring - M5	
116	0720 0060E	Retaining Ring - M6	
117	0720 0080E	Retaining Ring - M8	
118	0805 3495	Ball Bearing - 10x15x4	
119	0805 3145	Ball Bearing - 6x12x4mm	
120	0805 3109	Ball Bearing - 10x19x7mm	
121	0805 3204	Ball Bearing - 8x16x5mm	
122	0707 4050B	Bushing - 4 X5	
123	0701 0040G	Flat Washer - M4	
124	0710 0040B	Hexagon Nut - M4	
125	0623 0200E	Spring Pin - 3x20mm	
126	0936 0250	Semicircle Key	
127	0632 0120G	Parallel Pin - 2x12	
128	1106 0430	Bushing - 13mm	
129	1106 0200	Bushing - 19.44mm	
130	1105 0197	Wire Saddle	
131	1204 2438	Micro Switch - VX-52-1A3	

Index No.	Part No.	Description	Q'ty Per Assembly

8.TRANSPORT SECTION (A659)



8.TRANSPORT SECTION (A659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A028 6222	Pressure Lever	8
2	AA06 3058	Spring	9
3	AF02 2026	Transport Driven Roller	4
4	A459 4195	Left Guide Plate Mylar	1
5	A459 4152	Left Guide Plate	1
6	AW01 0004	Photosensor	2
7	A459 4171	Center Guide Knob	1
8	A459 4173	Guard Plare Lock Lever	1
9	5413 1882	Stepped Screw	2
10	A459 4148	Stopper - Center Guide Plate	1
11	A459 4142	Center Guide Plate	1
12	A459 4149	Center Guide Mylar	1
13	AA13 4033	Roller	2
14	A459 4128	Right Middle Guide Plate	1
15	A459 4181	Harness Right Cover	1
16	A459 4122	Right Guide Plate	1
17	A459 5600	Horizontal Transport Harness	1
18	AF02 0095	Transport Roller	2
19	AF02 0097	Transport Drive Roller	1
20	AF02 0096	Transport Relay Roller	1
21	A459 4127	Guide Plate Pin - Right Middle	2
22	5446 2824	Screw - Duplex Guide Plate	1
23	AB03 0036	Pulley - 18Z	4
24	AB03 0037	Idler - 22z	2
25	A459 4072	Idler - 18m	1
26	A459 4070	Tension Bracket	1
27	AA04 3028	Timing Belt - 852P3M6	1
28	AB01 3225	Gear - 25Z	1
29	A459 4182	Harness Rear Cover	1
30	A459 4193	Harness Guide Plate	1
31	AB01 3226	Gear - 24Z	1
32	A459 4100	Paper Guide Plate - Horizontal	1
33	A459 4115	Gear Holder Bracket	1
34	A459 4161	Knob Bracket	1
35	AB01 3227	Gear - 44Z	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A459 4162	Knob Shaft	1
37	AG05 0035	Knob - Fusing	1
38	A459 4156	Left Lever	1
39	AA06 6041	Spring	1
40	5422 1737	Shaft	1
41	A659 4050	Horizontal Transport Unit - Ass'y	1
42	A459 4170	Lock Lever Ass'y	1
43	A659 4160	Knob Ass'y	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0951 4006B	Philips Screw With Washer - M4x6	
103	0313 0120B	Philips Pan Head Screw - M3x12	
104	0720 0030E	Retaining Ring - M3	
105	0720 0040E	Retaining Ring - M4	
106	0720 0050E	Retaining Ring - M5	
107	0720 0060E	Retaining Ring - M6	
108	0805 3145	Ball Bearing - 6x12x4mm	
109	0741 3906	Bushing - M6	
110	0805 3307	Ball Bearing - 8x14x4mm	
111	0622 0100E	Spring Pin - 2x10mm	
112	1105 0005	Nylon Clamp - 3n	

9.DECAL AND DOCUMENT (659)

1

2

3

B4▶
14▶

A4▶
11▶
B5▶

B5▶
11▶
A4▶

14▶
B4▶

4

5

6

7

8

9

9.DECAL AND DOCUMENT (659)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A659 2608	Decal - Side Fence	1
2	A459 2607	Decal - Front Side Fence	1
3	A459 2605	Decal - Fence	1
4	A459 2606	Decal - Back Fence	1
5	5446 2638	Decal - Paper Lower Limit	1
6	AA00 1190	Decal - Ground	1
7	A459 2611	Decal - Sensor Size	1
8	A659 2611	Decal - Misfeed Removal	1
9	A659 2610	Decal - Paper Setting	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Part No.	Description	Page and Index No.
A659 1110	Right Stay - Base	11- 15
A659 1120	Joint Stay - Left	11- 3
A659 1123	Release Plate	11- 4
A659 1126	Rail Bracket - Right	11- 13
A659 1128	Lock Release Arm	11- 7
A659 1129	Flat Screw	11- 6
A659 1130	Rail Bracket - Left	11- 1
A659 1135	Bracket - Paper Feed Frame	11- 22
A659 1136	Rail Bracket - Lower Left	11- 10
A659 1140	Bracket - Left Frame	11- 21
A659 1142	Left Frame Bracket	11- 23
A659 1150	Joint Pin - M8	11- 16
A659 1211	Upper Cover	5- 6
A659 1215	LCT Cover Ass'y	15- 19
A659 1256	Upper Front Cover	5- 11
A659 1271	Grip Cover	5- 8
A659 1271	Grip Cover	15- 18
A659 1272	Door Catch	5- 13
A659 1273	Bracket - Cover	5- 15
A659 1274	Shaft - Cover	5- 14
A659 1277	Side Cover Ass'y	5- 3
A659 1279	Cover Cushion - Front	11- 38
A659 1286	Upper Rear Cover	5- 1
A659 1291	Lower Rear Cover	5- 2
A659 1310	Bracket - Safety Switch	9- 1
A659 1311	Cover - Safety Switch	7- 22
A659 1315	Rear Supporting Plate	5- 5
A659 1326	Front Cover - Small	5- 10
A659 1510	Front Side Plate - Transport	7- 21
A659 1515	Rear Side Plate - Transport	7- 24
A659 1522	Stay - Side Plate	7- 23
A659 1530	Upper Guide Plate	7- 1
A659 1539	Entrance Guide Plate	7- 11
A659 1571	Bracket - Transport Motor	7- 35
A659 1610	Separation Bracket	13- 14

Part No.	Description	Page and Index No.
A659 1635	Feed Cover	13- 11
A659 1655	Stay - Drive	11- 24
A659 1665	Magnetic Clutch	11- 36
A659 1671	Bracket - Magnetic Clutch	11- 32
A659 2010	LCT Base	17- 43
A659 2020	Front Side Plate - Tray	17- 5
A659 2025	Rear Side Plate - Tray	17- 20
A659 2030	End Fence	15- 1
A659 2060	Sprocket Tightener	17- 11
A659 2065	Sprocket Tightener - Left	17- 7
A659 2067	Right Supporting Plate - Sprocket	17- 12
A659 2068	Left Supporting Plate - Sprocket	17- 2
A659 2070	Table - Tray	15- 15
A659 2081	Table Front Shaft	17- 16
A659 2082	Table Rear Shaft	17- 17
A659 2087	Paper End Bracket	17- 14
A659 2089	Bushed Chain - Right	17- 13
A659 2090	Bushed Chain - Left	17- 1
A659 2210	Back Fence Bracket	15- 28
A659 2214	Bracket - Back Fence Drive	15- 38
A659 2235	Back Fence Cover	15- 32
A659 2250	Front Side Fence Ass'y	15- 25
A659 2253	Rear Side Fence - Ass'y	15- 43
A659 2280	Side Fence Holder	15- 13
A659 2281	Holder Bracket - Left	17- 21
A659 2325	Side Cover	15- 23
A659 2326	Small Cover - Front	15- 6
A659 2327	Small Cover - Rear	15- 8
A659 2331	Guide Plate - Click	11- 17
A659 2510	Connector Bracket	9- 3
A659 2520	Bracket - PCB	9- 15
A659 2521	Harness Cover - Transformer	9- 16
A659 2524	Inner Cover - PCB	9- 7
A659 2608	Decal - Side Fence	15- 42
A659 2608	Decal - Side Fence	23- 1

Part No.	Description	Page and Index No.
A659 2610	Decal - Paper Setting	23- 9
A659 2610	Decal - Paper Setting	15- 17
A659 2611	Decal - Misfeed Removal	5- 12
A659 2611	Decal - Misfeed Removal	23- 8
A659 4050	Horizontal Transport Unit - Ass'y	19- 41
A659 4160	Knob Ass'y	19- 43
A659 5100	Interfase Board - LCT	9- 13
A659 5150	Interface Board - Brushless Motor	9- 18
A659 5212	Harness Bracket	9- 9
A659 5300	Harness - Drawer	17- 41
A659 5300	Harness - Drawer	15- 11
A659 5311	Coupling Harness	9- 12
A659 5315	Harness Bracket	9- 2
A659 5320	Harness - Joint 2	9- 10
A659 5330	Relay Harness	9- 11
A659 5340	Harness - Jam Removal	7- 20
A659 5370	Harness - Brushless Motor	9- 19
A659 5381	Moter Harness	11- 29
A659 5500	Transformer - 200VA 37V	9- 14

Part No.	Description	Page and Index No.
AA00 1190	Decal - Ground	23- 6
AA04 3028	Timing Belt - 852P3M6	19- 27
AA04 3258	Timing Belt - Back Fence	15- 31
AA06 0137	Pick-up Spring	13- 4
AA06 0139	Spring	13- 24
AA06 0753	Spring	13- 46
AA06 2250	Spring	13- 55
AA06 3058	Spring	19- 2
AA06 3059	Spring	13- 56
AA06 6041	Spring	19- 39
AA13 4033	Roller	19- 13
AA14 0146	Paper Feed Guide Shaft	13- 42
AA14 0148	Feed Roller Shaft	13- 23
AA14 0631	Shaft - Table Drive	17- 19
AA14 0632	Lift Driven Shaft	17- 18
AA14 0633	Guide Shaft	15- 34
AA14 3062	Shoulder Screw - M4	11- 5
AA14 3473	Guide Pin	15- 9
AA14 5528	Shaft - Stay	11- 33
AA14 8511	Separation Drive Shaft	13- 36
AA16 1104	Cushion - Motor	17- 26
AB01 0093	Gear - 18Z	13- 40
AB01 3220	Gear - 20Z	13- 31
AB01 3222	Gear - 20Z	13- 30
AB01 3225	Gear - 25Z	19- 28
AB01 3226	Gear - 24Z	19- 31
AB01 3227	Gear - 44Z	19- 35
AB01 3229	Gear - 30Z	11- 34
AB01 3230	Gear - 40Z	13- 32
AB01 3231	Gear - 21Z	13- 49
AB01 4003	Gear - 25Z	7- 36
AB01 4004	Gear - 27Z	17- 10
AB01 4005	Gear - 27Z	17- 8
AB02 3069	Sprocket - 14t	17- 9
AB03 0036	Pulley - 18Z	19- 23

Part No.	Description	Page and Index No.
AB03 0037	Idler - 22z	19- 24
AB03 0543	Pulley - 30T/37T	7- 31
AB03 0544	Back Fence Pulley - Driven	15- 30
AB03 0545	Back Fence Pulley - Drive	15- 33
AF02 0071	Grip Roller	13- 25
AF02 0095	Transport Roller	19- 18
AF02 0096	Transport Relay Roller	19- 20
AF02 0097	Transport Drive Roller	19- 19
AF02 2026	Transport Driven Roller	19- 3
AF03 1052	Pick-up Roller	13- 18
AF03 1053	Paper Feed Roller	13- 16
AF03 1054	Reverse Roller	13- 44
AG05 0035	Knob - Fusing	19- 37
AG07 1009	Rotary Catch	5- 9
AH01 1001	Stand	11- 14
AW01 0004	Photosensor	19- 6
AX06 0015	DC Motor - DC/42W	17- 24
AX06 0132	Brushless Motor - 7.8W	7- 34
C203 5020	Spring - Feed Roller Pressure	11- 8

Part No.	Description	Page and Index No.
A008 2626	Paper End Actuator	15- 22
A028 3008	Drive Motor Joint	13- 33
A028 3122	Paper Feed Front Side Plate	13- 13
A028 3131	Upper Grip Roller	13- 12
A028 3142	Feed Sensor Guide	13- 43
A028 3146	Paper Feed Guide Spacer	13- 39
A028 3148	Paper Feed Control Board Cover	13- 27
A028 3151	Paper Feed Stay	13- 2
A028 3157	Pick-up Arm	13- 21
A028 3160	Pick-up Guide	13- 20
A028 3161	Paper Feed Stopper	13- 22
A028 3166	Spring Supporter	13- 3
A028 3168	Spring Slider	13- 48
A028 3172	Solenoid Bracket	13- 8
A028 3173	Paper Feed Solenoid	13- 7
A028 3176	Paper Feed Motor Bracket	13- 34
A028 3264	Stopper Cushion	13- 9
A028 5155	Paper Feed Control Board	9- 8
A028 5160	Registration Sensor Board	13- 28
A028 5322	Paper Feed Motor - DC3V 2.25W	13- 35
A028 6222	Pressure Lever	19- 1
A029 1413	Cap	5- 4
A112 3111	Separation Torque Limiter	13- 50
A201 2809	Shaft Lever	13- 54
A201 2813	Keep Solenoid - DC 24V	13- 53
A201 2815	Solenoid Bracket	13- 52
A201 3100	Separator Stay	13- 37
A201 3116	Sepaseter Pressure Arm	13- 47
A201 3119	Sepaseter Shaft	13- 45
A201 3121	Stopper - Pressure	13- 51
A201 3169	Pick-up Adjusting Lever	13- 6
A201 5417	Harness - Paper Feed	13- 1
A420 3699	Magnet Catch Ass'y	7- 14
A423 5410	DC Motor - 24V 2.9W	15- 39
A458 3281	Idler Roller	7- 28

Part No.	Description	Page and Index No.
A459 1525	Transport Lower Guide	7- 12
A459 1536	Right Mounting Plate - Transport	7- 8
A459 1537	Left Mounting Plate - Transport	7- 2
A459 1545	Exit Roller	7- 17
A459 1546	Transport Drive Roller	7- 16
A459 1547	Upper Roller	7- 4
A459 1553	Pulley - 24Z	7- 29
A459 1555	Pulley - 22Z	7- 26
A459 1557	Collar	7- 25
A459 1558	Timing Belt - 710P2M6	7- 27
A459 1565	Mounting Plate Collar	11- 27
A459 1565	Mounting Plate Collar	7- 3
A459 1566	Stepped Screw	7- 15
A459 1570	Antistatic Brush	7- 7
A459 1620	Rear Side Plate	13- 26
A459 1625	Lower Feed Guide	13- 41
A459 1630	Upper Feed Guide	13- 38
A459 1672	Pressure Plate	11- 25
A459 1673	Connector Bracket	11- 28
A459 1675	Timing Belt - 400P2M6	11- 35
A459 2056	Sprocket Shaft	17- 4
A459 2057	Sprocket - 13z	17- 3
A459 2095	Tightener Spring	17- 6
A459 2110	Lift Motor Bracket	17- 25
A459 2111	Pulse Generator Bracket	17- 40
A459 2115	Worm Gear	17- 38
A459 2116	Worm Wheel	17- 35
A459 2117	Worm Wheel Shaft	17- 34
A459 2118	Pulley - 50Z	17- 31
A459 2119	Pulley - 22Z	17- 28
A459 2120	Guide Shaft	17- 39
A459 2121	Worm Gear Collar	17- 37
A459 2124	Pulley - 20Z	17- 29
A459 2135	Timing Belt - 264P3M10	17- 32
A459 2140	Pulse Generator	17- 36

Part No.	Description	Page and Index No.
A459 2216	Back Fence Sensor Plate	15- 37
A459 2221	Guide Shaft Bracket	15- 29
A459 2272	Front Paper Holder	15- 44
A459 2273	Side Fence Pad	15- 41
A459 2275	Rear Paper Holder	15- 45
A459 2290	Heater Cover	17- 44
A459 2310	Paper End Feeler	15- 20
A459 2312	Paper End Feeler Bracket	15- 21
A459 2316	Paper End Switch Bracket	17- 22
A459 2335	LCT Guide Plate	15- 24
A459 2340	LCT Stopper Plate	11- 11
A459 2341	Stopper Pin	15- 5
A459 2345	LCT Stopper Bracket	15- 2
A459 2346	Stopper	15- 3
A459 2511	Connector Bracket	9- 4
A459 2512	Connector Bracket	17- 42
A459 2605	Decal - Fence	23- 3
A459 2605	Decal - Fence	15- 27
A459 2606	Decal - Back Fence	15- 36
A459 2606	Decal - Back Fence	23- 4
A459 2607	Decal - Front Side Fence	15- 26
A459 2607	Decal - Front Side Fence	23- 2
A459 2611	Decal - Sensor Size	23- 7
A459 2611	Decal - Sensor Size	15- 10
A459 4070	Tension Bracket	19- 26
A459 4072	Idler - 18m	19- 25
A459 4100	Paper Guide Plate - Horizontal	19- 32
A459 4115	Gear Holder Bracket	19- 33
A459 4122	Right Guide Plate	19- 16
A459 4127	Guide Plate Pin - Right Middle	19- 21
A459 4128	Right Middle Guide Plate	19- 14
A459 4142	Center Guide Plate	19- 11
A459 4148	Stopper - Center Guide Plate	19- 10
A459 4149	Center Guide Mylar	19- 12
A459 4152	Left Guide Plate	19- 5

Part No.	Description	Page and Index No.
A459 4156	Left Lever	19- 38
A459 4161	Knob Bracket	19- 34
A459 4162	Knob Shaft	19- 36
A459 4170	Lock Lever Ass'y	19- 42
A459 4171	Center Guide Knob	19- 7
A459 4173	Guard Plare Lock Lever	19- 8
A459 4181	Harness Right Cover	19- 15
A459 4182	Harness Rear Cover	19- 29
A459 4193	Harness Guide Plate	19- 30
A459 4195	Left Guide Plate Mylar	19- 4
A459 5220	LCT Sub Control Board	9- 17
A459 5400	LCT Operation Board	15- 16
A459 5410	Photo Sensor - PS PC05	17- 15
A459 5410	Photo Sensor - PS PC05	7- 19
A459 5410	Photo Sensor - PS PC05	15- 35
A459 5600	Horizontal Transport Harness	19- 17
A461 6251	Cushion	5- 7
A659 1110	Right Stay - Base	11- 15
A659 1120	Joint Stay - Left	11- 3
A659 1123	Release Plate	11- 4
A659 1126	Rail Bracket - Right	11- 13
A659 1128	Lock Release Arm	11- 7
A659 1129	Flat Screw	11- 6
A659 1130	Rail Bracket - Left	11- 1
A659 1135	Bracket - Paper Feed Frame	11- 22
A659 1136	Rail Bracket - Lower Left	11- 10
A659 1140	Bracket - Left Frame	11- 21
A659 1142	Left Frame Bracket	11- 23
A659 1150	Joint Pin - M8	11- 16
A659 1211	Upper Cover	5- 6
A659 1215	LCT Cover Ass'y	15- 19
A659 1256	Upper Front Cover	5- 11
A659 1271	Grip Cover	15- 18
A659 1271	Grip Cover	5- 8
A659 1272	Door Catch	5- 13

Part No.	Description	Page and Index No
A659 1273	Bracket - Cover	5- 15
A659 1274	Shaft - Cover	5- 14
A659 1277	Side Cover Ass'y	5- 3
A659 1279	Cover Cushion - Front	11- 38
A659 1286	Upper Rear Cover	5- 1
A659 1291	Lower Rear Cover	5- 2
A659 1310	Bracket - Safety Switch	9- 1
A659 1311	Cover - Safety Switch	7- 22
A659 1315	Rear Supporting Plate	5- 5
A659 1326	Front Cover - Small	5- 10
A659 1510	Front Side Plate - Transport	7- 21
A659 1515	Rear Side Plate - Transport	7- 24
A659 1522	Stay - Side Plate	7- 23
A659 1530	Upper Guide Plate	7- 1
A659 1539	Entrance Guide Plate	7- 11
A659 1571	Bracket - Transport Motor	7- 35
A659 1610	Separation Bracket	13- 14
A659 1635	Feed Cover	13- 11
A659 1655	Stay - Drive	11- 24
A659 1665	Magnetic Clutch	11- 36
A659 1671	Bracket - Magnetic Clutch	11- 32
A659 2010	LCT Base	17- 43
A659 2020	Front Side Plate - Tray	17- 5
A659 2025	Rear Side Plate - Tray	17- 20
A659 2030	End Fence	15- 1
A659 2060	Sprocket Tightener	17- 11
A659 2065	Sprocket Tightener - Left	17- 7
A659 2067	Right Supporting Plate - Sprocket	17- 12
A659 2068	Left Supporting Plate - Sprocket	17- 2
A659 2070	Table - Tray	15- 15
A659 2081	Table Front Shaft	17- 16
A659 2082	Table Rear Shaft	17- 17
A659 2087	Paper End Bracket	17- 14
A659 2089	Bushed Chain - Right	17- 13
A659 2090	Bushed Chain - Left	17- 1

Part No.	Description	Page and Index No.
A659 2210	Back Fence Bracket	15- 28
A659 2214	Bracket - Back Fence Drive	15- 38
A659 2235	Back Fence Cover	15- 32
A659 2250	Front Side Fence Ass'y	15- 25
A659 2253	Rear Side Fence - Ass'y	15- 43
A659 2280	Side Fence Holder	15- 13
A659 2281	Holder Bracket - Left	17- 21
A659 2325	Side Cover	15- 23
A659 2326	Small Cover - Front	15- 6
A659 2327	Small Cover - Rear	15- 8
A659 2331	Guide Plate - Click	11- 17
A659 2510	Connector Bracket	9- 3
A659 2520	Bracket - PCB	9- 15
A659 2521	Harness Cover - Transformer	9- 16
A659 2524	Inner Cover - PCB	9- 7
A659 2608	Decal - Side Fence	15- 42
A659 2608	Decal - Side Fence	23- 1
A659 2610	Decal - Paper Setting	23- 9
A659 2610	Decal - Paper Setting	15- 17
A659 2611	Decal - Misfeed Removal	5- 12
A659 2611	Decal - Misfeed Removal	23- 8
A659 4050	Horizontal Transport Unit - Ass'y	19- 41
A659 4160	Knob Ass'y	19- 43
A659 5100	Interfase Board - LCT	9- 13
A659 5150	Interface Board - Brushless Motor	9- 18
A659 5212	Harness Bracket	9- 9
A659 5300	Harness - Drawer	17- 41
A659 5300	Harness - Drawer	15- 11
A659 5311	Coupling Harness	9- 12
A659 5315	Harness Bracket	9- 2
A659 5320	Harness - Joint 2	9- 10
A659 5330	Relay Harness	9- 11
A659 5340	Harness - Jam Removal	7- 20
A659 5370	Harness - Brushless Motor	9- 19
A659 5381	Moter Harness	11- 29

Part No.	Description	Page and Index No
A659 5500	Transformer - 200VA 37V	9- 14

Part No.	Description	Page and Index No.
5201 2858	Friction Pad	15- 14
5205 2594	Gear - 18T	13- 17
5205 5250	LED Sensor Type S	17- 30
5205 5250	LED Sensor Type S	13- 10
5205 6575	Side Fence Mylar - Front	15- 40
5206 2686	Snap Ring	13- 15
5216 5245	Photointerruptor - II-G-3P-S3T2-E	15- 12
5219 5908	Stay - Main Motor	17- 23
5403 1910	Spring Anchor - Stopper Lever	7- 30
5403 2048	Bushing - 4mm	7- 13
5413 1882	Stepped Screw	19- 9
5413 1882	Stepped Screw	11- 9
5415 2642	Lock Arm	15- 4
5422 1737	Shaft	19- 40
5424 2625	Spring - Connector	11- 30
5424 2625	Spring - Connector	9- 5
5446 2560	Cushion - Paper Tray	11- 12
5446 2566	Detent Arm	11- 18
5446 2567	Detent Arm Shaft	11- 20
5446 2569	Spring - Detent	11- 19
5446 2638	Decal - Paper Lower Limit	23- 5
5446 2638	Decal - Paper Lower Limit	15- 7
5446 2824	Screw - Duplex Guide Plate	19- 22
5446 2824	Screw - Duplex Guide Plate	13- 29
5446 5463	Dehumidity Heater	17- 33
5446 5832	Connector Guide Pin	11- 31
5446 5832	Connector Guide Pin	9- 6
5447 2706	Gear - 15T	13- 19
5447 2768	Stepped Screw - M3	13- 5
5875 2088	Shoulder Screw - M4	7- 9
5887 4155	Shaft Guide - Turn Driven	7- 5
5887 4156	Spring - Driven Roller	11- 26
5887 4156	Spring - Driven Roller	7- 6
5887 4156	Spring - Driven Roller	11- 37
5894 3175	Spring	7- 33

Part No.	Description	Page and Index No
5918 2321	Timing Belt Tightner	7- 32
5938 2763	Slide Guide	11- 2
6802 5703	Grounding Wire	17- 27
6802 5703	Grounding Wire	7- 10

Part No.	Description	Page and Index No.
0313 0060B	Philips Pan Head Screw - M3x6	5-103
0313 0060B	Philips Pan Head Screw - M3x6	9-115
0313 0060B	Philips Pan Head Screw - M3x6	13-104
0313 0100B	Philips Pan Head Screw - M3x10	15-104
0313 0100B	Philips Pan Head Screw - M3x10	17-103
0313 0100B	Philips Pan Head Screw - M3x10	7-111
0313 0120B	Philips Pan Head Screw - M3x12	19-103
0313 0140B	Philips Pan Head Screw - M3x14	17-105
0313 0200W	Philips Pan Head Screw - M3x20	11-107
0314 0060B	Philips Pan Head Screw - M4x6	5-102
0314 0060B	Philips Pan Head Screw - M4x6	15-101
0314 0060B	Philips Pan Head Screw - M4x6	19-101
0314 0060B	Philips Pan Head Screw - M4x6	11-108
0314 0060B	Philips Pan Head Screw - M4x6	9-101
0314 0060B	Philips Pan Head Screw - M4x6	13-101
0314 0060B	Philips Pan Head Screw - M4x6	17-101
0314 0060B	Philips Pan Head Screw - M4x6	7-101
0314 0080B	Philips Pan Head Screw - M4x8	17-107
0314 0080B	Philips Pan Head Screw - M4x8	13-102
0314 0100B	Philips Pan Head Screw - M4x10	13-103
0314 0100B	Philips Pan Head Screw - M4x10	17-106
0315 0080W	Philips Pan Head Screw - M5x8	11-112
0344 0060F	Philips Truss Head Screw - M4x6	15-103
0344 0060F	Philips Truss Head Screw - M4x6	5-101
0345 0080Z	Philips Pan Head Screw - M5x8	17-102
0354 0060F	Philips Pan Head Screw - M4x6	15-102
0354 0060F	Philips Pan Head Screw - M4x6	11-109
0433 0062W	Hexagon Head Tapping Screw - M3x6	15-111
0573 0050E	Hexagon Headless Set Screw - M3x5	13-111
0574 0050E	Hexagon Headless Set Screw - M4x5	17-112
0574 0050E	Hexagon Headless Set Screw - M4x5	7-107
0574 0050E	Hexagon Headless Set Screw - M4x5	15-107
0574 0060E	Hexagon Headless Set Screw - M4x6	7-103
0575 0060E	Hexagon Headless Set Screw - M5x6	17-113
0622 0100E	Spring Pin - 2x10mm	19-111

Part No.	Description	Page and Index No.
0623 0200E	Spring Pin - 3x20mm	17-125
0632 0120G	Parallel Pin - 2x12	17-127
0701 0040G	Flat Washer - M4	17-123
0707 4050B	Bushing - 4 X5	17-122
0710 0040B	Hexagon Nut - M4	17-124
0710 0050B	Hexagon Nut - M5	15-109
0720 0030E	Retaining Ring - M3	19-104
0720 0030E	Retaining Ring - M3	15-108
0720 0030E	Retaining Ring - M3	5-105
0720 0040E	Retaining Ring - M4	7-106
0720 0040E	Retaining Ring - M4	17-114
0720 0040E	Retaining Ring - M4	19-105
0720 0040E	Retaining Ring - M4	13-106
0720 0040E	Retaining Ring - M4	11-106
0720 0050E	Retaining Ring - M5	19-106
0720 0050E	Retaining Ring - M5	17-115
0720 0060E	Retaining Ring - M6	11-105
0720 0060E	Retaining Ring - M6	19-107
0720 0060E	Retaining Ring - M6	13-107
0720 0060E	Retaining Ring - M6	17-116
0720 0060E	Retaining Ring - M6	7-105
0720 0080E	Retaining Ring - M8	17-117
0741 3508	Bushing - 8x14x4mm	17-111
0741 3706	Ball Bearing - 6x10x3	7-102
0741 3906	Bushing - M6	19-109
0805 3042	Ball Bearing - 6x10x3mm	13-109
0805 3109	Ball Bearing - 10x19x7mm	17-120
0805 3145	Ball Bearing - 6x12x4mm	7-108
0805 3145	Ball Bearing - 6x12x4mm	17-119
0805 3145	Ball Bearing - 6x12x4mm	19-108
0805 3204	Ball Bearing - 8x16x5mm	17-121
0805 3307	Ball Bearing - 8x14x4mm	13-108
0805 3307	Ball Bearing - 8x14x4mm	19-110
0805 3307	Ball Bearing - 8x14x4mm	11-104
0805 3365	Bushing - 8x14mm	7-104

Part No.	Description	Page and Index No.
0805 3495	Ball Bearing - 10x15x4	17-118
0805 5003	Caster	11-111
0936 0250	Semicircle Key	17-126
0951 3006B	Philips Screw With Flat Washer - M3x6	5-104
0951 4006B	Philips Screw With Washer - M4x6	9-105
0951 4006B	Philips Screw With Washer - M4x6	19-102
0951 4006B	Philips Screw With Washer - M4x6	17-110
0951 4006B	Philips Screw With Washer - M4x6	11-103
0951 4006B	Philips Screw With Washer - M4x6	13-105
0951 4006B	Philips Screw With Washer - M4x6	15-105
0951 4008B	Philips Screw With Washer - M4x8	15-106
0951 4010W	Philips Screw With Flatwasher - M4x10	11-110
0951 4012B	Philips Screw With Flat Washer	17-108
0951 5008B	Philips Screw With Washer - M5x8	17-104
1005 0383	Edging - B	11-102
1005 0383	Edging - B	9-111
1005 0509	Bushing No.4, 12	9-116
1105 0005	Nylon Clamp - 3n	19-112
1105 0005	Nylon Clamp - 3n	13-110
1105 0005	Nylon Clamp - 3n	17-109
1105 0010	Nylon Clamp - 6n	9-113
1105 0035	Nylon Clamp - 9n	9-112
1105 0193	Nylon Stud	9-106
1105 0196	Harness Clamp	9-110
1105 0196	Harness Clamp	7-110
1105 0196	Harness Clamp	11-101
1105 0197	Wire Saddle	17-130
1105 0229	Clamp	15-110
1105 0409	Spacer	9-107
1105 0462	Harness Clamp	9-108
1106 0132	Cord Stopper	9-117
1106 0200	Bushing - 19.44mm	9-109
1106 0200	Bushing - 19.44mm	17-129
1106 0200	Bushing - 19.44mm	7-109
1106 0430	Bushing - 13mm	17-128

Part No.	Description	Page and Index No.
1106 0430	Bushing - 13mm	9-104
1106 0459	Bushing - 20.2mm	9-103
1107 0753	Fuse (Glass Case) - 6.3A - 250V	9-114
1204 2375	Safety Switch	9-102
1204 2438	Micro Switch - VX-52-1A3	17-131