

ST30 (A664)

PARTS CATALOG

INTRODUCTION


This chapter instructs you the numbers and names of parts on this machine.

INDEX to PARTS CATALOG

LOCATION OF UNIT	2
1.EXTERIOR (A664)	4
2.STAPLER SECTION 1 (A664)	6
3.STAPLER SECTION 2 (A664)	8
4.ELECTRICAL SECTION (A664).....	10
5.BIN DRIVE SECTION (A664).....	12
6.STAPLER DRIVE SECTION (A664)	14
7.TRANSPORT SECTION (A664).....	16
8.PAPER EXIT SECTION (A664).....	18
9.FRAME SECTION (A664)	20
10.DECAL AND DOCUMENT (A664)	22
PARTS INDEX	25


LOCATION OF UNIT

1. EXTERIOR (A664)




See Page 4

2. STAPLER SECTION 1 (A664)




See Page 6

3. STAPLER SECTION 2 (A664)




See Page 8

4. ELECTRICAL SECTION (A664)




See Page 10

5. BIN DRIVE SECTION (A664)






See Page 12

6. STAPLER DRIVE SECTION (A664)




See Page 14

LOCATION OF UNIT

7. TRANSPORT SECTION (A664)  See Page 16	8. PAPER EXIT SECTION (A664)  See Page 18	9. FRAME SECTION (A664)  See Page 20

1. EXTERIOR (A664)




1. EXTERIOR (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A606 1536	Lower Cover	1
2	A606 1601	Inner Cover - Chack	1
3	A606 1860	Decal - Add Stapler	1
4	A377 1641	Hinge Bracket	2
5	5875 2088	Shoulder Screw - M4	4
6	A377 1631	Upper Wheel Cover	1
7	A664 1547	Rear Cover	1
8	A606 1556	Left Cover	1
9	A606 1526	Front Left Cover	1
10	A606 1576	Front Door	1
11	A606 1645	Hinge	2
12	A606 1595	Small Door Cover	1
13	A377 1651	Magnet Catch Plate	1
14	A377 3546	Guide Roller	6
15	A377 3447	Small Guide Roller	2
16	A606 3510	Bin Ass'y	1
17	A377 3441	End Fence Shaft	1
18	A606 3536	Bin End Fence	1
19	AA06 6225	End Fence Spring	1
20	A377 4151	Jogger Plate	1
21	A606 1616	Small Proof Tray	1
22	A606 1710	Top Cover	1
23	A606 4156	Jogger Cushion	1
24	A606 1696	Clip Tray	1
25	A377 1671	Spacer Cushion	1
26	A664 1191	Front Bracket	1
27	A664 1192	Rear Bracket	1
28	A664 2124	Entrance Guide - EG	1
29	A377 3560	Supporting Bin	1
30	A664 2123	Entrance Guide - FL	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0314 0120B	Philips Pan Head Screw - M4x12	
104	0344 0080F	Philips Truss Head Screw - M4x8	

2. STAPLER SECTION 1 (A664)



2. STAPLER SECTION 1 (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A377 4432	Gripper Arm Shaft - M6	2
2	AA08 0072	Bushing - 6x10x3	15
3	A377 4411	Upper Gripper Arm	2
4	A377 4413	Lower Gripper Arm	2
5	AA06 0061	Spring - Fork Gate Lever	2
6	A498 4625	Arm Cushion	2
7	AA08 2042	Bushing - 6x10x6.5mm	4
8	A377 4434	Gripper Lock Plate	1
9	5413 1882	Stepped Screw	1
10	A664 4436	Bracket:chuck:move:ass'y	1
11	A377 4465	Gripper Guide Rod	1
12	A377 4425	Solenoid Arm Bracket	1
13	A606 4435	Gripper Arm Solenoid	1
14	A377 4421	Solenoid Lever	1
15	AA08 2042	Bushing - 6x10x6.5mm	1
16	A377 4466	Cushion	2
17	A377 4463	Hook	1
18	A377 4455	Slide Roller	1
19	A377 4451	Slider Arm	1
20	A606 4460	Gripper Slide Solenoid	1
21	A377 4491	Timing Belt Stopper	1
22	A664 4441	Bracket:chuck:move:auxiliary:ass'y	1
23	A377 4433	Gripper Arm Shaft - M4	1
24	AA06 0547	Tension Spring	1
25	A377 4471	Gripper Bracket	1
26	AB03 0218	Pulley - 15Z	1
27	AA04 3355	Timing Belt - B40S2M320	1
28	AB03 0516	Timing Pulley - 15Z	1
29	AX05 0057	Stepping Motor - DC24V 3.84W	1
30	A498 4665	Pulley Flange	1
31	AW02 0022	Photointerruptor	1
32	5419 5714	Stepped Screw - M4	1
33	A548 2113	Motor Cushion	1
34	A606 4488	Gripper Harness Bracket	1
35	A377 4485	Gripper Guide Shaft	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A377 4742	Slider Guide	1
101	0720 0040E	Retaining Ring - M4	
102	0720 0030E	Retaining Ring - M3	
103	0951 3005B	Philips Screw With Flat Washer M3x5	
104	0720 0080E	Retaining Ring - M8	
105	0314 0060B	Philips Pan Head Screw - M4x6	
106	0951 4006B	Philips Screw With Washer - M4x6	
107	0313 0050B	Philips Pan Head Screw - M3x5	
108	0574 0040E	Hexagon Headless Set Screw - M4x4	
109	0314 0100B	Philips Pan Head Screw - M4x10	
110	1105 0291	Wire Saddle	
111	1105 0234	Clamp	

This is a detailed exploded view diagram of a mechanical assembly, likely a motor or actuator. The diagram shows various components and their assembly sequence, indicated by dashed lines and callouts. Key parts include:

- Motor/Actuator Unit (4):** The central component with a gear and internal mechanism.
- Base Plate (19):** A long, thin plate that serves as the foundation for the assembly.
- Mounting Brackets (10, 11, 12, 13, 14, 15, 16, 17, 18, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46):** Various brackets and plates used to secure the assembly.
- Fasteners (5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46):** Screws, bolts, and nuts used to hold the assembly together.
- Wiring and Connectors (101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112):** Electrical components and connectors for the assembly.

The diagram includes several callouts and labels:


- Callouts:** 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46.
- Labels:** A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U, V, W, X, Y, Z.

3. STAPLER SECTION 2 (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A606 1607	Entrance Guide	1
2	A606 4883	Spacer	1
3	A606 1605	Stapler Cover	1
4	AJ01 1010	Stapler - EH-560	1
5	5413 1882	Stepped Screw	1
6	A606 1609	Guide Mylar	1
7	AW01 0070	Photosebsor - PS-R11D1-B	1
8	A606 4711	Stapler Bracket	1
9	5442 1659	Stepped Screw - M4	1
10	A377 4738	Harness Bracket	1
11	A377 4736	Timing Belt Stopper	1
12	A377 4741	Roller - M14	2
13	A606 4831	Stapler Slider	1
14	A606 5240	Stapler Sensor Harness	1
15	AW02 0075	Photointerrupter	2
16	A664 4721	Bracket:stay:stapler:ass'y	1
17	A377 4742	Slider Guide	2
18	AB03 0394	Timing Pulley - 30Z	1
19	AA04 3357	Timing Belt - 1110P2M6	1
20	AX04 0067	Stepping Motor - DC 9W	1
21	5887 4185	Idler Pulley	1
22	A377 4726	Stepped Screw - M4x8x14	1
23	A606 5230	Stapler Harness	1
24	A664 4745	Cover:harness:stapler	1
25	5875 2088	Shoulder Screw - M4	2
26	AA06 3544	Pressure Spring	1
27	A606 4861	Stapler Bracket	1
28	A606 4854	Roller - 10	8
29	A606 4851	Middle Bracket	1
30	A606 4841	Slide Rail	1
31	A606 4881	Stepped Screw	1
32	A606 4866	Lever Shaft - Long	1
33	A606 4864	Lock Lever	1
34	AA06 6558	Spring	1
35	A606 4865	Lock Lever Grip	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A606 4873	Spring Plate	1
37	A606 4872	Stapler Stop Lever	1
38	A606 4871	Release Lever Bracket	1
39	A606 4837	Roller - 12	1
40	AA13 2152	Spacer - 8x20x1	1
41	A606 4728	Pulley - 30Z	1
42	A300 3812	Spacer - 6x22x1.5	1
43	A664 3311	Bracket:end Fence:open And Close:as	1
44	A499 2444	Middle Belt Roller	1
45	A606 4712	Stapler Entrance Guiide	1
46	A606 1606	Harness Cover	1
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0313 0100B	Philips Pan Head Screw - M3x10	
104	1106 0241	Bushing - 6.7mm	
105	1106 0193	Bushing - 7.9mm	
106	0951 3005B	Philips Screw With Flat Washer M3x5	
107	0720 0040E	Retaining Ring - M4	
108	1105 0310	Wire Clamp	
109	0314 0040B	Philips Pan Head Screw - M4x4	
110	0951 4006B	Philips Screw With Washer - M4x6	
111	1105 0267	Wire Clamp	
112	1105 0328	Harness Clamp - ES-0505	

4. ELECTRICAL SECTION (A664)




4. ELECTRICAL SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AW03 0039	Optical Fiber - 75 700mm	1
2	A664 5215	DC Power Supply Harness	1
3	A606 5200	Sensor Harness	1
4	A606 5260	Motor Harness	1
5	A606 5210	Lower Motor Harness	1
6	AA04 3348	Timing Belt - 150P3M6	1
7	AB03 0435	Timing Pulley - 16Z	1
8	A377 2217	Cushion - T1.2	4
9	AX05 0057	Stepping Motor - DC24V 3.84W	1
10	A377 2231	Stepping Motor Bracket	1
11	AA04 3349	Timing Belt - 660P3M6	1
12	A300 3812	Spacer - 6x22x1.5	1
13	AB03 3054	Gear Pulley - 70/20Z	1
14	5053 0447	Bushing - 6mm	3
15	AX05 0098	DC Motor - D24V 6W	1
16	AB03 0535	Timing Pulley - 27Z	1
17	A606 2211	Brushless Motor Bracket	1
18	AA14 5215	Clutch Shaft	1
19	AA04 3461	Timing Belt - 136P2M	1
20	A377 2216	Spacer - 6x10x9	1
21	AB01 0337	Gear - 70Z	1
22	AA08 0071	Bushing -6x10x6	1
23	AB03 0325	Pulley - 20Z	1
24	AB03 3053	Gear Pulley - 35/43Z	1
25	5442 5839	Angle - Cord Clamp 30	2
26	A606 2340	Junction Gate Solenoid	1
27	A377 1636	Upper Rear Cover Bracket	2
28	A664 5103	IC - AM27C256-205DC	1
29	AA04 3350	Timing Belt - B60S3M426	1
30	A664 5100	Main Control Board	1
31	A377 3321	End Fence Guide	1
32	AX04 0053	DC Motor - 24V/2.2W	1
33	AW02 0075	Photointerrupter	2
34	A377 3311	End Fence Bracket	1
35	A377 3331	Harness Cover	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	AB01 7305	Gear -18/78Z	1
37	A377 3326	Gear - 70Z	1
38	AA08 0072	Bushing - 6x10x3	2
39	5447 2681	Snap Ring	2
40	A377 3322	End Fence Link	1
41	A377 3315	Link Bracket	1
42	A377 3323	Link Shaft	1
43	5403 6246	Stepped Screw - Cleaning	4
44	A606 2371	Solenoid Bracket	1
45	5206 2686	Snap Ring	1
46	A377 2346	Tension Spring - 20.5mm	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0574 0040E	Hexagon Headless Set Screw - M4x4	
103	0313 0050B	Philips Pan Head Screw - M3x5	
104	1005 0944	Stepping Motor Cushion	
105	0720 0040E	Retaining Ring - M4	
106	0573 0040E	Hexagon Headless Set Screw - M3x4	
107	0800 0072	Philips Pan Head Screw - M2.6x4	
108	0632 0100G	Pin - 2x10mm	
109	0951 4008B	Philips Screw With Washer - M4x8	
110	1105 0034	Nylon Clamp - 7N	
111	1105 0310	Wire Clamp	
112	1105 0134	Locking Support	
113	1105 0291	Wire Saddle	
114	1107 0752	Fuse - 5A-250V	
115	0951 3005B	Philips Screw With Flat Washer M3x5	
116	1102 4473	CT - Connector - 2P	

5. BIN DRIVE SECTION (A664)




5. BIN DRIVE SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A606 3171	Bin Guide	1
2	A606 3176	Rail Spacer	1
3	A377 3151	Timing Pulley - 36Z	1
4	A606 3181	Rail Bracket	1
5	A606 3112	Long Helical Wheel	1
6	A606 3181	Rail Bracket	1
7	A377 3145	Helical Wheel Bushing	1
8	A377 3136	Rear Left Fixing Plate	1
9	AA04 3354	Timing Belt - B40S3M633	1
10	AB03 0393	Timing Pulley - 25Z	1
11	A377 4141	Pulley Bracket	1
12	AA06 0544	Tension Spring	1
13	A664 4131	Stay:jogger:upper:ass'y	1
14	A377 4138	Jogger Shaft	1
15	AA08 2042	Bushing - 6x10x6.5mm	2
16	AA06 6549	Jogger Plate Spring	1
17	A377 4112	Upper Jogger Plate Holder	1
18	A354 4475	Timing Belt Stopper - Side Fence	1
19	A300 3812	Spacer - 6x22x1.5	1
20	AB03 3051	Timing Pulley - 25Z	1
21	A377 4186	Idler Bracket	1
22	5887 4185	Idler Pulley	1
23	5214 1811	Idle Pulley - 20Z	1
24	AA04 3356	Timing Belt - B60S3M1680	1
25	AW02 0075	Photointerrupter	1
26	A377 4181	Jogger Adjusting Bracket	1
27	AA06 0548	Tension Spring	1
28	A377 1116	Stud Screw - M6	1
29	A606 1840	Decal - Service	1
30	A377 4161	Jogger Sensor Bracket	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0574 0040E	Hexagon Headless Set Screw - M4x4	
102	0741 3006	Ball Bearing - 6x17x6mm	
103	0951 4006B	Philips Screw With Washer - M4x6	
104	0720 0040E	Retaining Ring - M4	
105	0314 0060B	Philips Pan Head Screw - M4x6	
106	0965 3008B	Tapping Screw With Washer - M3x8	
107	0720 0080E	Retaining Ring - M8	
108	0313 0080B	Philips Pan Head Screw - M3x8	
109	0720 0060E	Retaining Ring - M6	

6. STAPLER DRIVE SECTION (A664)




6. STAPLER DRIVE SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A300 3812	Spacer - 6x22x1.5	1
2	AB03 3051	Timing Pulley - 25Z	1
3	AA04 3354	Timing Belt - B40S3M633	1
4	A664 4133	Stay:jogger:lower:ass'y	1
5	AA08 2042	Bushing - 6x10x6.5mm	2
6	A354 4475	Timing Belt Stopper - Side Fence	1
7	A377 4138	Jogger Shaft	1
8	AA06 6549	Jogger Plate Spring	1
9	A377 4122	Lower Jogger Plate Holder	1
10	A377 4216	Timing Pulley - 34Z	1
11	AX05 0100	Stepping Motor - 14.5V 0.34A	1
12	A606 5250	Relay Harness - Jogger	1
13	5206 2684	Shoulder Screw - M3	1
14	A377 3242	Adjusting Bracket	1
15	5887 4185	Idler Pulley	1
16	AA04 3352	Timing Belt - B60S3M918	1
17	AA06 0555	Tension Spring	1
18	5887 2245	Spring Anchor	1
19	A377 3212	Posioning Sensor Bracket	1
20	AW02 0022	Photointerruptor	1
21	A377 3161	Timing Pulley - 36Z L8/L12	1
22	A377 3166	Bin Posioning Shutter	1
23	A606 3112	Long Helical Wheel	1
24	5887 2291	Idle Roller	1
25	A377 3262	Tension Bracket	1
26	AA06 0556	Tension Spring	1
27	A469 3142	Idle Pulley Stud - Long	1
28	AA04 3353	Timing Belt - B100S3M300	1
29	AB03 0437	Timing Pulley - 18Z	1
30	A377 3202	Stepping Motor Bracket	1
31	A377 1116	Stud Screw - M6	1
32	AX06 0081	Stepping Motor - DC 8.4W	1
33	A377 3145	Helical Wheel Bushing	1
34	A377 3141	Front Fixing Plate	1
35	A377 3255	Hexagon Headless Set Screw - M4x4	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0720 0040E	Retaining Ring - M4	
103	0313 0080B	Philips Pan Head Screw - M3x8	
104	0720 0080E	Retaining Ring - M8	
105	0951 3005B	Philips Screw With Flat Washer M3x5	
106	0965 3008B	Tapping Screw With Washer - M3x8	
107	0720 0060E	Retaining Ring - M6	
108	0574 0040E	Hexagon Headless Set Screw - M4x4	
109	0951 4006B	Philips Screw With Washer - M4x6	
110	0741 3006	Ball Bearing - 6x17x6mm	
111	0314 0100B	Philips Pan Head Screw - M4x10	
112	1005 0946	Stepping Motor Cushion	
113	0344 0060F	Philips Truss Head Screw - M4x6	
114	0314 0080B	Philips Pan Head Screw - M4x8	

7. TRANSPORT SECTION (A664)




7. TRANSPORT SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	5053 0447	Bushing - 6mm	2
2	5442 5839	Angle - Cord Clamp 30	1
3	5413 1882	Stepped Screw	1
4	AG07 0004	Magnetic Catch	4
5	A377 1661	Door Switch Cover	1
6	A377 1662	Door Switch Actuator	1
7	1204 2384	Interlock Switch	1
8	AW02 0087	Photosensor - LNB4301	1
9	A606 5270	Bin Sensor Harness - Upper	1
10	A664 1141	Stay:upper:ass'y	1
11	AA08 0034	Bushing - 4x5x7	6
12	AA06 3529	Pressure Spring - 14.5mm	6
13	AF02 2097	Driver Roller	3
14	A377 2316	Upper Left Guide	1
15	A377 2350	Exit Roller	1
16	AA12 0027	Antistatic Brush	1
17	A664 2311	Guide Plate:right	1
18	A377 5460	Transport Sensor Harness	2
19	AW02 0049	Photointerruptor - OS - 580213-703	2
20	A664 1151	Stay	2
21	AF02 0305	Transport Roller	1
22	5940 2641	Feed-in Solenoid Spring	1
23	A377 2333	Junction Gate Bracket	1
24	A606 2327	Junction Gate Cushion	1
25	A377 1870	Decal - R1	1
26	A606 2332	Junction Gate Lever	1
27	5940 2641	Feed-in Solenoid Spring	1
28	A377 2331	Junction Gate	1
29	A606 2321	Left Guide Plate	1
30	A377 2326	Support Plate	1
31	AA08 0071	Bushing -6x10x6	2
32	AB03 0374	Timing Pulley - 20Z	1
33	A354 1261	Pulley - 20Z	1
34	A354 1266	Torque Limiter Collar	1
35	A300 3826	Pressure Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	A300 3812	Spacer - 6x22x1.5	1
37	AB03 0278	Idler - 20Z	1
38	A377 2221	Tightener	1
39	AA06 0092	Release Spring	1
40	A606 2328	Junction Gate Cushion	1
101	0314 0060B	Philips Pan Head Screw - M4x6	
102	0720 0040E	Retaining Ring - M4	
103	0802 5233	Tapping Screw - M3x10	
104	0313 0140B	Philips Pan Head Screw - M3x14	
105	1106 0193	Bushing - 7.9mm	
106	1105 0196	Harness Clamp	
107	0720 0030E	Retaining Ring - M3	
108	0951 4006B	Philips Screw With Washer - M4x6	
109	0802 5240	Tapping Bind Screw - M4x12	
110	0720 0060E	Retaining Ring - M6	
111	1105 0291	Wire Saddle	

8. PAPER EXIT SECTION (A664)




8. PAPER EXIT SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A377 1621	Upper Inner Cover	1
2	A606 2180	Lower Entrance Guide	1
3	A377 2166	Middle Guide Mylar	1
4	A664 2127	Connector Guide	1
5	A377 2144	Antistatic Brush	1
6	A377 2142	Grounding Spring Plate	1
7	A377 1138	Magnet Catch Seal	1
8	A377 1656	Inner Cover Angle	2
9	A377 2115	Lower Guide Mylar	2
10	A664 2131	Guide Plate:right Lower	1
11	A377 2141	Left Lower Guide	1
12	AA08 0034	Bushing - 4x5x7	8
13	AF02 2097	Driver Roller	4
14	AA06 3529	Pressure Spring - 14.5mm	8
15	A664 1126	Cover:front:punch	1
16	5413 1882	Stepped Screw	3
17	A377 1875	Decal - R2	1
18	AG07 0004	Magnetic Catch	1
19	A664 1171	Stay:exit	1
20	A377 2161	Middle Guide Plate	1
21	5403 2075	Stepped Screw	1
22	A377 2117	Pressure Spring	2
23	A377 1182	Joint Lever	1
24	A664 1181	Stay:middle	1
25	A377 2146	Exit Guide Mylar	5

Index No.	Part No.	Description	Q'ty Per Assembly
101	0344 0060F	Philips Truss Head Screw - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	1106 0430	Bushing - 13mm	
104	0353 0060W	Philips Pan Head Screw - M3x6	
105	0951 4006B	Philips Screw With Washer - M4x6	

9. FRAME SECTION (A664)




9. FRAME SECTION (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A377 1656	Inner Cover Angle	2
2	5053 0447	Bushing - 6mm	4
3	AB03 3070	Idler Roller	1
4	A377 1666	Lower Sensor Cover	1
5	A498 6085	Caster Stopper	4
6	A377 1626	Lower Inner Cover	1
7	AF02 0306	Exit Roller	1
8	AF02 0304	Transport Roller	2
9	AF02 0305	Transport Roller	1
10	A664 1151	Stay	1
11	A377 1118	Edge Guard	3
12	AH01 2010	Caster - 50m	4
13	A377 1637	Lower Rear Cover Bracket	1
14	A377 3222	Home Position Sensor Bracket	1
15	AW02 0049	Photointerruptor - OS - 580213-703	1
16	AW02 0088	Photosensor - PNB4301	1
17	A606 5280	Bin Sensor Harness - Lower	1
18	A606 1123	Spacer	1
19	AA08 0071	Bushing -6x10x6	4
20	AB03 0434	Timing Pulley - 20Z	2
21	AB03 0278	Idler - 20Z	3
22	AA14 3462	Idler Stud - M4	2
23	AB03 0374	Timing Pulley - 20Z	1
24	A606 1855	Decal - Misfeed Removal	1
25	A606 1850	Decal - Misfeed Removal - Stapler	1
26	A377 2221	Tightener	1
27	AA06 0092	Release Spring	1
28	A377 1116	Stud Screw - M6	2


Index No.	Part No.	Description	Q'ty Per Assembly
101	0951 4006B	Philips Screw With Washer - M4x6	
102	0314 0060B	Philips Pan Head Screw - M4x6	
103	0720 0040E	Retaining Ring - M4	
104	0344 0060F	Philips Truss Head Screw - M4x6	
105	1105 0310	Wire Clamp	
106	0313 0140B	Philips Pan Head Screw - M3x14	
107	0720 0060E	Retaining Ring - M6	
108	0951 4006B	Philips Screw With Washer - M4x6	
109	1105 0196	Harness Clamp	
110	1106 0459	Bushing - 20.2mm	
111	0315 0080B	Philips Pan Head Screw - M5x8	

10. DECAL AND DOCUMENT (A664)


1




2



4



5



7



8



10. DECAL AND DOCUMENT (A664)

Index No.	Part No.	Description	Q'ty Per Assembly
1	A606 1850	Decal - Misfeed Removal - Stapler	1
2	A606 1860	Decal - Add Stapler	1
4	A606 1855	Decal - Misfeed Removal	1
5	A606 1840	Decal - Service	1
7	A377 1875	Decal - R2	1
8	A377 1870	Decal - R1	1

Index No.	Part No.	Description	Q'ty Per Assembly

PARTS INDEX

Part No.	Description	Page and Index No.
A664 1126	Cover:front:punch	19- 15
A664 1141	Stay:upper:ass'y	17- 10
A664 1151	Stay	17- 20
A664 1151	Stay	21- 10
A664 1171	Stay:exit	19- 19
A664 1181	Stay:middle	19- 24
A664 1191	Front Bracket	5- 26
A664 1192	Rear Bracket	5- 27
A664 1547	Rear Cover	5- 7
A664 2123	Entrance Guide - FL	5- 30
A664 2124	Entrance Guide - EG	5- 28
A664 2127	Connector Guide	19- 4
A664 2131	Guide Plate:right Lower	19- 10
A664 2311	Guide Plate:right	17- 17
A664 3311	Bracket:end Fence:open And Close:as	9- 43
A664 4131	Stay:jogger:upper:ass'y	13- 13
A664 4133	Stay:jogger:lower:ass'y	15- 4
A664 4436	Bracket:chuck:move:ass'y	7- 10
A664 4441	Bracket:chuck:move:auxiliary:ass'y	7- 22
A664 4721	Bracket:stay:stapler:ass'y	9- 16
A664 4745	Cover:harness:stapler	9- 24
A664 5100	Main Control Board	11- 30
A664 5103	IC - AM27C256-205DC	11- 28
A664 5215	DC Power Supply Harness	11- 2

Part No.	Description	Page and Index No
AA04 3348	Timing Belt - 150P3M6	11- 6
AA04 3349	Timing Belt - 660P3M6	11- 11
AA04 3350	Timing Belt - B60S3M426	11- 29
AA04 3352	Timing Belt - B60S3M918	15- 16
AA04 3353	Timing Belt - B100S3M300	15- 28
AA04 3354	Timing Belt - B40S3M633	13- 9
AA04 3354	Timing Belt - B40S3M633	15- 3
AA04 3355	Timing Belt - B40S2M320	7- 27
AA04 3356	Timing Belt - B60S3M1680	13- 24
AA04 3357	Timing Belt - 1110P2M6	9- 19
AA04 3461	Timing Belt - 136P2M	11- 19
AA06 0061	Spring - Fork Gate Lever	7- 5
AA06 0092	Release Spring	17- 39
AA06 0092	Release Spring	21- 27
AA06 0544	Tension Spring	13- 12
AA06 0547	Tension Spring	7- 24
AA06 0548	Tension Spring	13- 27
AA06 0555	Tension Spring	15- 17
AA06 0556	Tension Spring	15- 26
AA06 3529	Pressure Spring - 14.5mm	17- 12
AA06 3529	Pressure Spring - 14.5mm	19- 14
AA06 3544	Pressure Spring	9- 26
AA06 6225	End Fence Spring	5- 19
AA06 6549	Jogger Plate Spring	13- 16
AA06 6549	Jogger Plate Spring	15- 8
AA06 6558	Spring	9- 34
AA08 0034	Bushing - 4x5x7	17- 11
AA08 0034	Bushing - 4x5x7	19- 12
AA08 0071	Bushing -6x10x6	11- 22
AA08 0071	Bushing -6x10x6	17- 31
AA08 0071	Bushing -6x10x6	21- 19
AA08 0072	Bushing - 6x10x3	7- 2
AA08 0072	Bushing - 6x10x3	11- 38
AA08 2042	Bushing - 6x10x6.5mm	7- 7
AA08 2042	Bushing - 6x10x6.5mm	7- 15

Part No.	Description	Page and Index No.
AA08 2042	Bushing - 6x10x6.5mm	13- 15
AA08 2042	Bushing - 6x10x6.5mm	15- 5
AA12 0027	Antistatic Brush	17- 16
AA13 2152	Spacer - 8x20x1	9- 40
AA14 3462	Idler Stud - M4	21- 22
AA14 5215	Clutch Shaft	11- 18
AB01 0337	Gear - 70Z	11- 21
AB01 7305	Gear -18/78Z	11- 36
AB03 0218	Pulley - 15Z	7- 26
AB03 0278	Idler - 20Z	17- 37
AB03 0278	Idler - 20Z	21- 21
AB03 0325	Pulley - 20Z	11- 23
AB03 0374	Timing Pulley - 20Z	17- 32
AB03 0374	Timing Pulley - 20Z	21- 23
AB03 0393	Timing Pulley - 25Z	13- 10
AB03 0394	Timing Pulley - 30Z	9- 18
AB03 0434	Timing Pulley - 20Z	21- 20
AB03 0435	Timing Pulley - 16Z	11- 7
AB03 0437	Timing Pulley - 18Z	15- 29
AB03 0516	Timing Pulley - 15Z	7- 28
AB03 0535	Timing Pulley - 27Z	11- 16
AB03 3051	Timing Pulley - 25Z	13- 20
AB03 3051	Timing Pulley - 25Z	15- 2
AB03 3053	Gear Pulley - 35/43Z	11- 24
AB03 3054	Gear Pulley - 70/20Z	11- 13
AB03 3070	Idler Roller	21- 3
AF02 0304	Transport Roller	21- 8
AF02 0305	Transport Roller	17- 21
AF02 0305	Transport Roller	21- 9
AF02 0306	Exit Roller	21- 7
AF02 2097	Driver Roller	17- 13
AF02 2097	Driver Roller	19- 13
AG07 0004	Magnetic Catch	17- 4
AG07 0004	Magnetic Catch	19- 18
AH01 2010	Caster - 50m	21- 12

Part No.	Description	Page and Index No
AJ01 1010	Stapler - EH-560	9- 4
AW01 0070	Photosebsor - PS-R11D1-B	9- 7
AW02 0022	Photointerruptor	7- 31
AW02 0022	Photointerruptor	15- 20
AW02 0049	Photointerruptor - OS - 580213-703	17- 19
AW02 0049	Photointerruptor - OS - 580213-703	21- 15
AW02 0075	Photointerrupter	9- 15
AW02 0075	Photointerrupter	11- 33
AW02 0075	Photointerrupter	13- 25
AW02 0087	Photosensor - LNB4301	17- 8
AW02 0088	Photosensor - PNB4301	21- 16
AW03 0039	Optical Fiber - 75 700mm	11- 1
AX04 0053	DC Motor - 24V/2.2W	11- 32
AX04 0067	Stepping Motor - DC 9W	9- 20
AX05 0057	Stepping Motor - DC24V 3.84W	7- 29
AX05 0057	Stepping Motor - DC24V 3.84W	11- 9
AX05 0098	DC Motor - D24V 6W	11- 15
AX05 0100	Stepping Motor - 14.5V 0.34A	15- 11
AX06 0081	Stepping Motor - DC 8.4W	15- 32

Part No.	Description	Page and Index No.
A300 3812	Spacer - 6x22x1.5	9- 42
A300 3812	Spacer - 6x22x1.5	11- 12
A300 3812	Spacer - 6x22x1.5	13- 19
A300 3812	Spacer - 6x22x1.5	15- 1
A300 3812	Spacer - 6x22x1.5	17- 36
A300 3826	Pressure Spring	17- 35
A354 1261	Pulley - 20Z	17- 33
A354 1266	Torque Limiter Collar	17- 34
A354 4475	Timing Belt Stopper - Side Fence	13- 18
A354 4475	Timing Belt Stopper - Side Fence	15- 6
A377 1116	Stud Screw - M6	13- 28
A377 1116	Stud Screw - M6	15- 31
A377 1116	Stud Screw - M6	21- 28
A377 1118	Edge Guard	21- 11
A377 1138	Magnet Catch Seal	19- 7
A377 1182	Joint Lever	19- 23
A377 1621	Upper Inner Cover	19- 1
A377 1626	Lower Inner Cover	21- 6
A377 1631	Upper Wheel Cover	5- 6
A377 1636	Upper Rear Cover Bracket	11- 27
A377 1637	Lower Rear Cover Bracket	21- 13
A377 1641	Hinge Bracket	5- 4
A377 1651	Magnet Catch Plate	5- 13
A377 1656	Inner Cover Angle	19- 8
A377 1656	Inner Cover Angle	21- 1
A377 1661	Door Switch Cover	17- 5
A377 1662	Door Switch Actuator	17- 6
A377 1666	Lower Sensor Cover	21- 4
A377 1671	Spacer Cushion	5- 25
A377 1870	Decal - R1	17- 25
A377 1870	Decal - R1	25- 8
A377 1875	Decal - R2	19- 17
A377 1875	Decal - R2	25- 7
A377 2115	Lower Guide Mylar	19- 9
A377 2117	Pressure Spring	19- 22

Part No.	Description	Page and Index No
A377 2141	Left Lower Guide	19- 11
A377 2142	Grounding Spring Plate	19- 6
A377 2144	Antistatic Brush	19- 5
A377 2146	Exit Guide Mylar	19- 25
A377 2161	Middle Guide Plate	19- 20
A377 2166	Middle Guide Mylar	19- 3
A377 2216	Spacer - 6x10x9	11- 20
A377 2217	Cushion - T1.2	11- 8
A377 2221	Tightener	17- 38
A377 2221	Tightener	21- 26
A377 2231	Stepping Motor Bracket	11- 10
A377 2316	Upper Left Guide	17- 14
A377 2326	Support Plate	17- 30
A377 2331	Junction Gate	17- 28
A377 2333	Junction Gate Bracket	17- 23
A377 2346	Tension Spring - 20.5mm	11- 46
A377 2350	Exit Roller	17- 15
A377 3136	Rear Left Fixing Plate	13- 8
A377 3141	Front Fixing Plate	15- 34
A377 3145	Helical Wheel Bushing	13- 7
A377 3145	Helical Wheel Bushing	15- 33
A377 3151	Timing Pulley - 36Z	13- 3
A377 3161	Timing Pulley - 36Z L8/L12	15- 21
A377 3166	Bin Positioning Shutter	15- 22
A377 3202	Stepping Motor Bracket	15- 30
A377 3212	Positioning Sensor Bracket	15- 19
A377 3222	Home Position Sensor Bracket	21- 14
A377 3242	Adjusting Bracket	15- 14
A377 3255	Hexagon Headless Set Screw - M4x4	15- 35
A377 3262	Tension Bracket	15- 25
A377 3311	End Fence Bracket	11- 34
A377 3315	Link Bracket	11- 41
A377 3321	End Fence Guide	11- 31
A377 3322	End Fence Link	11- 40
A377 3323	Link Shaft	11- 42

Part No.	Description	Page and Index No.
A377 3326	Gear - 70Z	11- 37
A377 3331	Harness Cover	11- 35
A377 3441	End Fence Shaft	5- 17
A377 3447	Small Guide Roller	5- 15
A377 3546	Guide Roller	5- 14
A377 3560	Supporting Bin	5- 29
A377 4112	Upper Jogger Plate Holder	13- 17
A377 4122	Lower Jogger Plate Holder	15- 9
A377 4138	Jogger Shaft	13- 14
A377 4138	Jogger Shaft	15- 7
A377 4141	Pulley Bracket	13- 11
A377 4151	Jogger Plate	5- 20
A377 4161	Jogger Sensor Bracket	13- 30
A377 4181	Jogger Adjusting Bracket	13- 26
A377 4186	Idler Bracket	13- 21
A377 4216	Timing Pulley - 34Z	15- 10
A377 4411	Upper Gripper Arm	7- 3
A377 4413	Lower Gripper Arm	7- 4
A377 4421	Solenoid Lever	7- 14
A377 4425	Solenoid Arm Bracket	7- 12
A377 4432	Gripper Arm Shaft - M6	7- 1
A377 4433	Gripper Arm Shaft - M4	7- 23
A377 4434	Gripper Lock Plate	7- 8
A377 4451	Slider Arm	7- 19
A377 4455	Slide Roller	7- 18
A377 4463	Hook	7- 17
A377 4465	Gripper Guide Rod	7- 11
A377 4466	Cushion	7- 16
A377 4471	Gripper Bracket	7- 25
A377 4485	Gripper Guide Shaft	7- 35
A377 4491	Timing Belt Stopper	7- 21
A377 4726	Stepped Screw - M4x8x14	9- 22
A377 4736	Timing Belt Stopper	9- 11
A377 4738	Harness Bracket	9- 10
A377 4741	Roller - M14	9- 12

Part No.	Description	Page and Index No
A377 4742	Slider Guide	7- 36
A377 4742	Slider Guide	9- 17
A377 5460	Transport Sensor Harness	17- 18
A469 3142	Idle Pulley Stud - Long	15- 27
A498 4625	Arm Cushion	7- 6
A498 4665	Pulley Flange	7- 30
A498 6085	Caster Stopper	21- 5
A499 2444	Middle Belt Roller	9- 44
A548 2113	Motor Cushion	7- 33
A606 1123	Spacer	21- 18
A606 1526	Front Left Cover	5- 9
A606 1536	Lower Cover	5- 1
A606 1556	Left Cover	5- 8
A606 1576	Front Door	5- 10
A606 1595	Small Door Cover	5- 12
A606 1601	Inner Cover - Chack	5- 2
A606 1605	Stapler Cover	9- 3
A606 1606	Harness Cover	9- 46
A606 1607	Entrance Guide	9- 1
A606 1609	Guide Mylar	9- 6
A606 1616	Small Proof Tray	5- 21
A606 1645	Hinge	5- 11
A606 1696	Clip Tray	5- 24
A606 1710	Top Cover	5- 22
A606 1840	Decal - Service	13- 29
A606 1840	Decal - Service	25- 5
A606 1850	Decal - Misfeed Removal - Stapler	21- 25
A606 1850	Decal - Misfeed Removal - Stapler	25- 1
A606 1855	Decal - Misfeed Removal	21- 24
A606 1855	Decal - Misfeed Removal	25- 4
A606 1860	Decal - Add Stapler	5- 3
A606 1860	Decal - Add Stapler	25- 2
A606 2180	Lower Entrance Guide	19- 2
A606 2211	Brushless Motor Bracket	11- 17
A606 2321	Left Guide Plate	17- 29

Part No.	Description	Page and Index No.
A606 2327	Junction Gate Cushion	17- 24
A606 2328	Junction Gate Cushion	17- 40
A606 2332	Junction Gate Lever	17- 26
A606 2340	Junction Gate Solenoid	11- 26
A606 2371	Solenoid Bracket	11- 44
A606 3112	Long Helical Wheel	13- 5
A606 3112	Long Helical Wheel	15- 23
A606 3171	Bin Guide	13- 1
A606 3176	Rail Spacer	13- 2
A606 3181	Rail Bracket	13- 4
A606 3181	Rail Bracket	13- 6
A606 3510	Bin Ass'y	5- 16
A606 3536	Bin End Fence	5- 18
A606 4156	Jogger Cushion	5- 23
A606 4435	Gripper Arm Solenoid	7- 13
A606 4460	Gripper Slide Solenoid	7- 20
A606 4488	Gripper Harness Bracket	7- 34
A606 4711	Stapler Bracket	9- 8
A606 4712	Stapler Entrance Guide	9- 45
A606 4728	Pulley - 30Z	9- 41
A606 4831	Stapler Slider	9- 13
A606 4837	Roller - 12	9- 39
A606 4841	Slide Rail	9- 30
A606 4851	Middle Bracket	9- 29
A606 4854	Roller - 10	9- 28
A606 4861	Stapler Bracket	9- 27
A606 4864	Lock Lever	9- 33
A606 4865	Lock Lever Grip	9- 35
A606 4866	Lever Shaft - Long	9- 32
A606 4871	Release Lever Bracket	9- 38
A606 4872	Stapler Stop Lever	9- 37
A606 4873	Spring Plate	9- 36
A606 4881	Stepped Screw	9- 31
A606 4883	Spacer	9- 2
A606 5200	Sensor Harness	11- 3

Part No.	Description	Page and Index No
A606 5210	Lower Motor Harness	11- 5
A606 5230	Stapler Harness	9- 23
A606 5240	Stapler Sensor Harness	9- 14
A606 5250	Relay Harness - Jogger	15- 12
A606 5260	Motor Harness	11- 4
A606 5270	Bin Sensor Harness - Upper	17- 9
A606 5280	Bin Sensor Harness - Lower	21- 17
5053 0447	Bushing - 6mm	11- 14
5053 0447	Bushing - 6mm	17- 1
5053 0447	Bushing - 6mm	21- 2
5206 2684	Shoulder Screw - M3	15- 13
5206 2686	Snap Ring	11- 45
5214 1811	Idle Pulley - 20Z	13- 23
5403 2075	Stepped Screw	19- 21
5403 6246	Stepped Screw - Cleaning	11- 43
5413 1882	Stepped Screw	7- 9
5413 1882	Stepped Screw	9- 5
5413 1882	Stepped Screw	17- 3
5413 1882	Stepped Screw	19- 16
5419 5714	Stepped Screw - M4	7- 32
5442 1659	Stepped Screw - M4	9- 9
5442 5839	Angle - Cord Clamp 30	11- 25
5442 5839	Angle - Cord Clamp 30	17- 2
5447 2681	Snap Ring	11- 39
5875 2088	Shoulder Screw - M4	5- 5
5875 2088	Shoulder Screw - M4	9- 25
5887 2245	Spring Anchor	15- 18
5887 2291	Idle Roller	15- 24
5887 4185	Idler Pulley	9- 21
5887 4185	Idler Pulley	13- 22
5887 4185	Idler Pulley	15- 15
5940 2641	Feed-in Solenoid Spring	17- 22
5940 2641	Feed-in Solenoid Spring	17- 27

Part No.	Description	Page and Index No.
0313 0050B	Philips Pan Head Screw - M3x5	7-107
0313 0050B	Philips Pan Head Screw - M3x5	11-103
0313 0080B	Philips Pan Head Screw - M3x8	13-108
0313 0080B	Philips Pan Head Screw - M3x8	15-103
0313 0100B	Philips Pan Head Screw - M3x10	9-103
0313 0140B	Philips Pan Head Screw - M3x14	17-104
0313 0140B	Philips Pan Head Screw - M3x14	21-106
0314 0040B	Philips Pan Head Screw - M4x4	9-109
0314 0060B	Philips Pan Head Screw - M4x6	5-102
0314 0060B	Philips Pan Head Screw - M4x6	7-105
0314 0060B	Philips Pan Head Screw - M4x6	9-102
0314 0060B	Philips Pan Head Screw - M4x6	11-101
0314 0060B	Philips Pan Head Screw - M4x6	13-105
0314 0060B	Philips Pan Head Screw - M4x6	15-101
0314 0060B	Philips Pan Head Screw - M4x6	17-101
0314 0060B	Philips Pan Head Screw - M4x6	19-102
0314 0060B	Philips Pan Head Screw - M4x6	21-102
0314 0080B	Philips Pan Head Screw - M4x8	15-114
0314 0100B	Philips Pan Head Screw - M4x10	7-109
0314 0100B	Philips Pan Head Screw - M4x10	15-111
0314 0120B	Philips Pan Head Screw - M4x12	5-103
0315 0080B	Philips Pan Head Screw - M5x8	21-111
0344 0060F	Philips Truss Head Screw - M4x6	5-101
0344 0060F	Philips Truss Head Screw - M4x6	9-101
0344 0060F	Philips Truss Head Screw - M4x6	15-113
0344 0060F	Philips Truss Head Screw - M4x6	19-101
0344 0060F	Philips Truss Head Screw - M4x6	21-104
0344 0080F	Philips Truss Head Screw - M4x8	5-104
0353 0060W	Philips Pan Head Screw - M3x6	19-104
0573 0040E	Hexagon Headless Set Screw - M3x4	11-106
0574 0040E	Hexagon Headless Set Screw - M4x4	7-108
0574 0040E	Hexagon Headless Set Screw - M4x4	11-102
0574 0040E	Hexagon Headless Set Screw - M4x4	13-101
0574 0040E	Hexagon Headless Set Screw - M4x4	15-108
0632 0100G	Pin - 2x10mm	11-108

Part No.	Description	Page and Index No
0720 0030E	Retaining Ring - M3	7-102
0720 0030E	Retaining Ring - M3	17-107
0720 0040E	Retaining Ring - M4	7-101
0720 0040E	Retaining Ring - M4	9-107
0720 0040E	Retaining Ring - M4	11-105
0720 0040E	Retaining Ring - M4	13-104
0720 0040E	Retaining Ring - M4	15-102
0720 0040E	Retaining Ring - M4	17-102
0720 0040E	Retaining Ring - M4	21-103
0720 0060E	Retaining Ring - M6	13-109
0720 0060E	Retaining Ring - M6	15-107
0720 0060E	Retaining Ring - M6	17-110
0720 0060E	Retaining Ring - M6	21-107
0720 0080E	Retaining Ring - M8	7-104
0720 0080E	Retaining Ring - M8	13-107
0720 0080E	Retaining Ring - M8	15-104
0741 3006	Ball Bearing - 6x17x6mm	13-102
0741 3006	Ball Bearing - 6x17x6mm	15-110
0800 0072	Philips Pan Head Screw - M2.6x4	11-107
0802 5233	Tapping Screw - M3x10	17-103
0802 5240	Tapping Bind Screw - M4x12	17-109
0951 3005B	Philips Screw With Flat Washer M3x5	7-103
0951 3005B	Philips Screw With Flat Washer M3x5	9-106
0951 3005B	Philips Screw With Flat Washer M3x5	11-115
0951 3005B	Philips Screw With Flat Washer M3x5	15-105
0951 4006B	Philips Screw With Washer - M4x6	7-106
0951 4006B	Philips Screw With Washer - M4x6	9-110
0951 4006B	Philips Screw With Washer - M4x6	13-103
0951 4006B	Philips Screw With Washer - M4x6	15-109
0951 4006B	Philips Screw With Washer - M4x6	17-108
0951 4006B	Philips Screw With Washer - M4x6	19-105
0951 4006B	Philips Screw With Washer - M4x6	21-101
0951 4006B	Philips Screw With Washer - M4x6	21-108
0951 4008B	Philips Screw With Washer - M4x8	11-109
0965 3008B	Tapping Screw With Washer - M3x8	13-106

Part No.	Description	Page and Index No.
0965 3008B	Tapping Screw With Washer - M3x8	15-106
1005 0944	Stepping Motor Cushion	11-104
1005 0946	Stepping Motor Cushion	15-112
1102 4473	CT - Connector - 2P	11-116
1105 0034	Nylon Clamp - 7N	11-110
1105 0134	Locking Support	11-112
1105 0196	Harness Clamp	17-106
1105 0196	Harness Clamp	21-109
1105 0234	Clamp	7-111
1105 0267	Wire Clamp	9-111
1105 0291	Wire Saddle	7-110
1105 0291	Wire Saddle	11-113
1105 0291	Wire Saddle	17-111
1105 0310	Wire Clamp	9-108
1105 0310	Wire Clamp	11-111
1105 0310	Wire Clamp	21-105
1105 0328	Harness Clamp - ES-0505	9-112
1106 0193	Bushing - 7.9mm	9-105
1106 0193	Bushing - 7.9mm	17-105
1106 0241	Bushing - 6.7mm	9-104
1106 0430	Bushing - 13mm	19-103
1106 0459	Bushing - 20.2mm	21-110
1107 0752	Fuse - 5A-250V	11-114
1204 2384	Interlock Switch	17- 7

Part No.	Description	Page and Index No

Part No.	Description	Page and Index No.

Part No.	Description	Page and Index No