

Software Update LE250E / DV250E

Please copy below files to USB memory (root)

- MB90_en.bin
- usb_auto_update_A1.txt
- mboot.bin (not always)

Procedure of Software Update

1. Turn the TV power off by mechanical switch (rocker switch)
2. Connect the USB memory to the TV.
3. Press „OK“ button from Remote control and turn the TV on (by mechanical switch)
→ When the Stand-by LED starts to blink rapidly, you can release the „OK“ button.
The screen keeps dark all the time.
4. After approximately 1-2 minutes the LED stops to flash and TV starts with new first Installation Menu (AIS)