

Software Update LE350/351/352

Please copy below files to USB memory (root)

- MB90_en.bin
- usb_auto_update_A1.txt
- mboot.bin (not always)

Procedure of Software Update

1. Turn the TV power off by mechanical switch (rocker switch)
2. Connect the USB memory to the TV.
3. Press „OK“ button from Remote control and turn the TV on (by mechanical switch)
→ You can release the „OK“ button after app. 6-8 seconds.
Please pay attention to the fact that sometimes the LED starts to flash 15-20 seconds later !! Please do not switch off the TV!!
The screen keeps dark all the time.
4. After approximately 1-2 minutes the LED stops to flash and TV starts with new first Installation Menu (AIS)

IMPORTANT INFO → Different Model derivate are available. Please check Model Name on the Label of the rear Cabinet before you start with the Software Update!

LE35xE



LE35xEB („B“ is written in a Square)

