



- ④ Display mode button (DISPLAY MODE)
- ⑤ Display
- ⑥ Super sound EQ button (SUPER SOUND EQ)
- ⑤ AI EQ button (AI EQ)
- ⑥ Manual EQ button (M1, M2, M3)
- ⑦ Flat button (FLAT)
- ⑧ Multi control buttons
(◀, ▶, ▲, ▼, MULTI CONTROL)
- ⑨ EQ button (EQ)