

922

■ Cabinet Parts Location

Ref. No.	Part No.	Values & Remarks
C807	ECBT1H102KB5	50V 1000P
C808, 809	ECBT1E103ZF	25V 0.01U
C810	ECEA1CKA100B	16V 10U
C811	ECBT1E103ZF	25V 0.01U
C813, 814	ECEA1HKA010B	50V 1U
C815	ECBT1E103ZF	25V 0.01U
C851	ECEA1HKAR33B	50V 0.33U
C852	ECQV1H104JM3	50V 0.1U
C861	ECBT1H220JC5	50V 22P
C862	ECBT1H270JU5	50V 27P
C871	ECEA0JKA101B	6.3V 100U
C872	ECBT1E103ZF	25V 0.01U
C901, 902	ECKT1H223ZF	50V 0.022U
C903, 904	ECA1EM471B	25V 470U Δ
C905-907	ECBT1E103ZF	25V 0.01U
C908	ECEA1CKA100B	16V 10U
C909	ECBT1H104ZF5	50V 0.1U
C910	ECEA1CKA100B	16V 10U
C911	ECA1HM221B	50V 220U Δ
C912	ECEA1HKA100B	50V 10U
C913	ECBT1E103ZF	25V 0.01U
C914	ECEA1AKA101B	10V 100U
C915	ECBT1E103ZF	25V 0.01U
C916	ECBT1H102KB5	50V 1000P
C921	ECBT1E103ZF	25V 0.01U
C951	ECA1EM471B	25V 470U Δ
C952	ECBT1H104ZF5	50V 0.1U
C991, 992	ECEA1AKA470B	10V 47U (E) (EG)
C993	ECEA1CKA100B	16V 10U

Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET PARTS	
1	RHD30007	SCREW	
2	RKM0203A-1K	CABINET	
3	XTB3+8JFZ	SCREW	
4	RGR0176A-A1	REAR PANEL	(E)
4	RGR0176A-G	REAR PANEL	(EG)
4	RGR0176A-D1	REAR PANEL	(GN)
5	RFKJSCH404EK	BOTTOM BOARD ASS'Y	
5-1	RKA0011A-2	FOOT	
6	RMN0231	HOLDER	
7	RMN0195-3	FL SPACER	
8	RMN0230	FL HOLDER	
9	RFKGTCH505EK	FRONT PANEL ASS'Y	
9-1	RKW0297-V	FL PANEL	
10	RGL0218-Q	PANEL LIGHT	
11	RGU0959-K	BUTTON, MULTI CONTROL etc.	
12	RGU0960-K	BUTTON, EQ SPACE etc.	
13	XTBS26+8J	SCREW	
14	SHE185-2	P. C. B. SPACER	
15	SNE2123	GND SCREW	(E) (EG)
16	XTBS3+8JFZ1	SCREW	
17	XTB3+16JFZ	SCREW	
18	RMC0229	SHIELD PLATE	(EG)

