



**UHER**

**Service**






**UHER**



**22 Hi-Fi Special**  
**24 Hi-Fi Special**




Wiedergabekopf  
Playback Head  
BV 7-33 \*  
BV 7-37 \* \*

| R                    | 1                                    | 2                      | 3 | 5.6 | 13.17 | 21.22 | 28.30 | 41                            | 45                         | 47 | 49 | 53                        | 55 | 59                   | 61 | 63 | 65 | 67 | 69 | 71                                        |
|----------------------|--------------------------------------|------------------------|---|-----|-------|-------|-------|-------------------------------|----------------------------|----|----|---------------------------|----|----------------------|----|----|----|----|----|-------------------------------------------|
| C                    | 1                                    | 2                      | 3 | 5   | 6     | 7     | 10    | 11                            | 12                         | 13 | 14 | 15                        | 16 | 17                   | 18 | 19 | 20 | 21 | 22 | 23                                        |
| Kontakte<br>Contacts | 1a-5, C7C12<br>19-m, C8C11<br>C9,C10 | B8<br>B9<br>B11<br>B10 |   |     |       |       |       | B6,B7<br>B13,B12<br>C6<br>C13 | D10<br>D14<br>D19-m 1001/2 |    |    | D8,C12<br>D9,D11<br>A' 8' |    | D2,D12,1<br>D5,4,5,6 |    |    |    |    |    | D1,11a-f, B4<br>D3,11g-m, B15<br>D6<br>D1 |






Betriebsartenschalter  
function selector





Gezeichnete Stellung: Mono 1  
Shown in 'Mono 1' position




a-b/g-h = Mono 1  
 a-c/g-i = Mono 2  
 a-d/g-k = Stereo  
 a-e/g-l = Multiplay 1  
 a-f/g-m = Multiplay 2

----- Gültig bis Gerät Nr.: 256000  
----- Valid up to ser. no.: 256000  
..... Gültig ab Gerät Nr.: 256001  
..... Valid from ser. no.: 256001



UHER 22 SPECIAL \*  
UHER 24 SPECIAL \*\*



|          |     |     |     |     |    |          |     |          |               |     |     |          |        |
|----------|-----|-----|-----|-----|----|----------|-----|----------|---------------|-----|-----|----------|--------|
| 142, 107 | 108 | 110 | 111 | 112 | 75 | 117, 119 | 122 | 126      | 125, 132, 134 | 135 | 137 | 143, 135 | 144    |
|          | 109 |     |     | 113 |    | 118, 120 | 123 | 127      | 130           | 136 | 138 | 140      |        |
|          |     |     |     | 114 |    |          | 124 | 128      | 131           |     |     | 141      |        |
|          |     |     |     | 115 |    |          | 125 | 131, 132 | 132           |     |     | 142      |        |
| 57       |     |     |     |     |    |          | 58  | 61       | 62            | 63  | 67  | 69, 71   | 72, 74 |
|          |     |     |     |     |    |          | 59  | 62       | 64            | 66  | 70  | 73       | 75     |
|          |     |     |     |     |    |          | 60  | 65       | 68            |     |     |          | 76     |
|          |     |     |     |     |    |          |     |          |               |     |     |          | 77     |
|          |     |     |     |     |    |          |     |          |               |     |     |          | 78     |
|          |     |     |     |     |    |          |     |          |               |     |     |          | 79     |
|          |     |     |     |     |    |          |     |          |               |     |     |          | 80     |

a-b/g-h = Mono 1  
a-c/g-i = Mono 2  
a-d/g-k = Stereo  
a-e/g-l = Multiplay I  
a-f/g-m = Multiplay II

Gültig bis Gerät Nr. 256000  
Valid up to ser. no. 256000  
Gültig ab Gerät Nr. 256001  
Valid from ser. no. 256001

255 816

**UHER 22 SPECIAL**

**UHER 24 SPECIAL**

*Stromlaufplan Circuit Diagram*

Gültig ab Gerät Nr. 254001 Valid from ser. no. 254001  
Änderungen vorbehalten! Alterations reserved!