

The following items are additions to your DL1720/DL1740 Communication Interface User's Manual (IM 701710-17E).

#### Chapter 3, "USB Interface" and Chapter 4, "Network Interface"

- **The following items must be installed on the PC to access the communications functions using the USB interface.**
  1. A dedicated library for the USB interface.
  2. A USB device driver for the PC-to-DL1720/DL1740 connection.
- **The following item must be installed on the PC to access the communications functions using the network interface.**
  1. A dedicated library for the network interface.

For information on obtaining the library or the driver, please contact your sales representative.

#### Section 3.2, "USB Interface Functions and Specifications"

Please add the underlined part.

##### USB Interface Specifications

Electrical and Mechanical Specifications	: Conforms to USB Rev.1.0
Connector	: Type B connector (receptacle)
Number of Ports	: 1
Power Supply	: Self-powered
<u>Supported Systems</u>	: <u>PC system supported. Models with a standard USB port that operates on Windows 98 SE, Windows Me, or Windows 2000 (a separate device driver is required for connection to the PC).</u>