




- A - RG
B - AKU +12 V
D - RG / AKU -







Sl. 30 – Šema primopredajnika PD-8




4200 T ARP POJAČAVAČ



1. Minus - mikrofon, taster, sl.
2. Taster
3. Mikrofon
4. Mikrofon
5. Slušalica
6. Slušalica
7. Slušalica

Medusobno
spojeno
1, 2, 4, 6



VRSTA RADA
I. POD. A1, A3J, A3H

PREDAJA UPRAV.
GOVOROM

VF POJAČANJE