



C O N T E N T S

MSC/PATRAN Installation & Operations Guide

1

Introduction & Overview

- Introduction, 2
 - Who Should Read This Guide, 2
- Overview of the MSC/PATRAN System, 3
 - The MSC/PATRAN PDB Database, 3
 - Modules and Translators, 3
 - FLEXlm, 3
 - Frameviewer On-Line Help System, 3
 - Year 2000 Compliance, 4
- Documentation Conventions, 5
 - Directory Path Convention, 6

2

Required Hardware & Software Configurations

- The mscinfo Utility, 8
- Memory and Performance, 9
 - RAM verses Swap, 9
 - Memory and Disk Space Requirements, 9
- Digital UNIX Requirements, 11
- Hewlett-Packard HP-UX Requirements, 12
- IBM AIX Requirements, 15
- Silicon Graphics IRIX Requirements, 18
- Sun Solaris Requirements, 21
- Microsoft Windows NT Requirements, 22
- MSC/PATRAN 3D Graphics Drivers, 24

3

Installing MSC/PATRAN on UNIX

- Overview, 28
- Installing MSC/PATRAN with mscsetup, 29
 - Mount CD-ROM, 30
 - Starting the mscsetup Installation Utility, 31
 - Selecting an Installation Device, 32
 - Inputting the Installation Directory, 33
 - Selecting Products to Install, 34



C O N T E N T S

MSC/PATRAN Installation & Operations Guide

- Selecting a Product Installation Type, 35
- Setting Application Prerequisites, 36
- Product Customization, 36
- License File Setup and Starting a FLEXlm server, 37
- Contract Amendment Form, 38
- Installation Review, 39
- Installation Messages, 40
- Upgrading an Existing Installation, 42
- Optional Steps, 44
 - Executable Path or Script for Parallel Installations, 44
 - Installing PCL Utilities and MSC Institute Files on UNIX, 45
 - Installing Spacetec Spaceball for Use with MSC/PATRAN, 46
- Module Setup and Installation, 47
 - MSC/PATRAN ANALYSIS MANAGER Setup, 47
 - MSC/PATRAN Direct CATIA Access Setup, 48
 - MSC/PATRAN CATIA Access Setup, 49
 - MSC/PATRAN Pro/ENGINEER Access Setup, 49
- Configuring Clients, 51
 - The mscsetup Utility Client Option, 51

4

Installing on Microsoft Windows NT

- Overview, 54
- TCP/IP Setup, 55
- Hummingbird Exceed Setup, 55
- Installing MSC/PATRAN with the Setup Wizard, 56
 - Selecting Components, 57
 - FrameViewer Installation (Optional), 58
 - MSC/PATRAN Core Product Installation, 59
 - FLEXlm Installation (Optional), 59
 - InterBase Installation (Optional), 60
- Upgrading an Existing Installation, 61
- Optional Steps, 62
 - Customizing Analysis Preferences in p3trans.ini, 62
 - Printing on Windows NT, 62
 - Displaying FrameViewer, 64
 - Installing PCL Utilities on Windows NT, 64
 - MSC/PATRAN Pro/ENGINEER Access Setup, 65



C O N T E N T S

MSC/PATRAN Installation & Operations Guide

- Adobe Type Manager Setup, 65
- MSC/PATRAN on Windows NT Startup Directory, 66
- Application Resources, 66
- MSC/PATRAN Pro/ENGINEER Access Setup, 67

■ Uninstalling, 68

■ Environment Variables, 70

■ Application Resources, 74

■ The *.pcl and *.def Setup Files, 76

- settings.pcl, 76
- p3epilog.pcl, 77
- Definition Files, 77

■ Command Line Arguments, 79

■ UNIX Shell Resource Limits, 80

■ The PDB Database System, 81

- Upgrading Databases, 81
- Creating Custom Template Databases, 82
- Moving Databases Between Platforms, 83
- MSC/PATRAN Database Caching and Swapping, 84

■ Startup Failures and Fatal Errors, 86

■ Errors in Functions and Opening Databases, 90

■ Import/Export, Analysis Submit and On-line Help, 95

■ Cosmetic Problems and Frequent Questions, 99

■ FLEXlm and Licensing Problems, 102

- General FLEXlm Troubleshooting, 102
- FLEXlm Common Problems and Resolutions, 103

5

User Environment

6

Problems & Resolutions



C O N T E N T S

MSC/PATRAN Installation & Operations Guide

A

Installing FLEXlm

- Overview, 116
- Installing FLEXlm Using a New Server, 117
- Replacing Codes on an Existing Server, 121
- Installing Using a Nodelock File, 123
- MSC_LICENSE_FILE versus LM_LICENSE_FILE, 124
- Additional Documentation, 125

B

InterBase in Version 8 or later

- Overview, 128
- Installing InterBase on UNIX, 129
 - Installing InterBase with mscsetup, 129
 - Installing on a UNIX Client without a Local InterBase, 132
 - NFS Access (UNIX Only), 134
 - InterBase and Semaphores on UNIX, 135
- Installing InterBase on Windows NT, 137
- Upgrading Databases, 138
- InterBase Problems and Resolutions, 139

C

Testing the Installation

- Test MSC/PATRAN, 146
- Test Application Preferences, 148
- Test Analysis Modules, 151
 - Test MSC/PATRAN ADVANCED FEA, 151
 - Test MSC/PATRAN ANALYSIS MANAGER, 153
 - Test MSC/PATRAN FEA, 154
 - Test MSC/PATRAN LAMINATE MODELER, 156
 - Test MSC/PATRAN MATERIALS, 156
 - Test MSC/PATRAN THERMAL, 157
- Test MSC/PATRAN CAD Access, 159
 - Test MSC/PATRAN ACIS Access, 159
 - Test MSC/PATRAN CATIA Access, 160



C O N T E N T S

D

Software
Deinstallation
Form

INDEX

MSC/PATRAN
Sales and Support

MSC/PATRAN Installation & Operations Guide

- Test the CADD5 5 Access Product, 161
- Test the EUCLID 3 Access Product, 162
- Test the MSC/PATRAN ProENGINEER Access, 163
- Test MSC/PATRAN Unigraphics Access, 164

■ Contract Amendment Form, 166

■ MSC/PATRAN Installation & Operations Guide

■ Where to Get Help, S-2

■ Technical Support Centers, S-5

■ MSC Offices, S-7

■ MSC Corporate Profile, S-8

■ Permission to Copy and Distribute MSC Documentation, S-16



C O N T E N T S

MSC/PATRAN Installation & Operations Guide