

CHAPTER

55

Stabilizers

CHAPTER 55
Stabilizers

Subject/Page	Date	COC	Subject/Page	Date	COC
EFFECTIVE PAGES					
1	Jun 15/2009				
2	BLANK				
55-CONTENTS					
O 1	Jun 15/2009				
2	BLANK				
55-00-00					
1	Oct 10/2002				
2	Oct 10/2002				
3	Feb 10/2003				
4	Oct 10/2002				
5	Oct 15/2008				
6	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

55-EFFECTIVE PAGES

D633A101-HAP

Page 1
Jun 15/2009



737-600/700/800/900 AIRCRAFT MAINTENANCE MANUAL

CHAPTER 55 Stabilizers

<u>CH-SC-SU</u>	<u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
55-00-00	STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION	2	HAP ALL
55-00-00	STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION	4	HAP ALL

55-CONTENTS

D633A101-HAP

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 1
Jun 15/2009

THIS PAGE IS INTENTIONALLY LEFT BLANK

55-00-00

D633A101-HAP

Page 1
Oct 10/2002

STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION**General**

Most of material in the horizontal stabilizer is aluminum. The elevator is graphite composite.

Horizontal Stabilizer Reference Dimensions


The horizontal stabilizer has three reference dimensions. These reference dimensions give horizontal stabilizer locations in inches. Measure each location from buttock line 0. These are the horizontal stabilizer reference dimensions:

- Stabilizer station
- Stabilizer leading edge station
- Elevator station.

Measure stabilizer stations perpendicular to the horizontal stabilizer rear spar.

Measure stabilizer leading edge stations perpendicular to the horizontal stabilizer leading edge.

Measure elevator stations perpendicular to the elevator hinge centerline.



STABILIZERS - HORIZONTAL STABILIZER - GENERAL DESCRIPTION

EFFECTIVITY
HAP ALL

55-00-00

D633A101-HAP

Page 3
Feb 10/2003

STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION**General**

Most of material in the vertical stabilizer is aluminum. The rudder is graphite composite.

Vertical Stabilizer Reference Dimensions

The vertical stabilizer has four reference dimensions. These reference dimensions give vertical stabilizer locations in inches. These are the vertical stabilizer reference dimensions:

- Vertical stabilizer station
- Vertical stabilizer leading edge station
- Rudder station
- Vertical stabilizer waterline.

Measure the vertical stabilizer station perpendicular to the vertical stabilizer rear spar. Vertical stabilizer station 0 starts at the body crown line.

Measure the vertical stabilizer leading edge station perpendicular to the vertical stabilizer leading edge. Vertical stabilizer leading edge station 0 starts at the body crown line.

Measure the rudder station perpendicular to the rudder hinge centerline. Rudder station 0 starts at the body crown line.


Measure the vertical stabilizer waterline parallel to the body waterline.

EFFECTIVITY
HAP ALL

55-00-00

D633A101-HAP

Page 4
Oct 10/2002



STABILIZERS - VERTICAL STABILIZER - GENERAL DESCRIPTION

EFFECTIVITY
HAP ALL

55-00-00

D633A101-HAP

Page 5
Oct 15/2008