

GAME CONTROLLER

MANUAL

COPYING THIS MANUAL

This document contains legally protected information. All rights reserved. Copying in mechanical, electronic or any other form without the written approval of the manufacturer is prohibited.

!!! Important Safety Notice !!!

Some medical studies have suggested that a long period of repetitive motion, coupled with an improper computing environment may be linked to certain types of physical discomfort or injuries. These include Carpal Tunnel Syndrome (CTS), Tendonitis, and Tendosynovitis. Take frequent breaks during the use of your game controller. If your arms, wrists, or hands feel aching, numbing, or tingling, please consult a qualified health care professional.

Put the game on pause for a while. Research suggests extended periods of exposure to vibrating equipment, coupled with an uncomfortable environment or other individual factors, may be linked to Hand-arm Vibration Syndrome (HAVS), also called Vibration Induced White Finger (VWF) or Raynaud's Syndrome. To help avoid this, take regular breaks for at least 10 minutes per hour of use, keep your hands and body warm, avoid gripping your controller too tightly, and maintain natural positioning of wrists, elbows, and shoulders. If your arms, wrists or hands are aching, numb or tingling, please consult a qualified health care professional.

Content:

SAFETY AND SERVICE 1

Cleaning.....	3
System requirements.....	4

OVERVIEW 5

SET UP 6

Connecting your game controller to a PC.....	6
--	---

FUNCTIONS..... 6

Auto-Fire.....	7
----------------	---

CUSTOMER CARE 8

Troubleshooting	8
Contacting customer care.....	9
Limited Warranty	10

SAFETY AND SERVICE

Please read this chapter carefully and follow all of the instructions. This will prolong the life of your game controller. Keep these instructions close to your game controller where they are readily available. Give this manual to the new owner if you sell or give away your game controller.



- **Never open the housing** of the game controller! This could lead to an electrical short-circuit or even a fire resulting in damage to your game controller.
- **Never allow children to play with electrical appliances without supervision.**
- The game controller is designed for household use only.

Set-up location

- Keep your game controller and all connected equipment away from moisture, dust and heat in order to avoid malfunctions.
- Do not expose the unit to direct sunlight for long periods of time; this will cause the plastic to fade and become brittle.



After transporting your game controller wait until it has assumed the ambient temperature before putting it into operation. In the event of major variations in the temperature, condensation can form on the inside of the game controller which can cause an electrical short-circuit.

Electro-magnetic compatibility

- When connecting the game controller observe the guidelines for electro-magnetic compatibility (EMC).
- Maintain a distance of at least one meter from sources of high frequency and magnetic interference (television sets, loudspeakers, mobile telephones, etc.), in order to avoid malfunctions and data loss.

Connecting the game controller

Observe the following instructions to connect your game controller properly:

- Route the cable so that no one can step on it or stumble over it.
- Do not place any objects on the cable, it could be damaged.

Repair

Please contact customer care if...

- Liquid has gotten into the inside of the game controller
- The game controller does not operate properly
- The game controller housing is damaged.

CLEANING

- Clean the game controller with a moist cloth.
- Do not use any type of solvents, caustic or gaseous cleaning agents.

SYSTEM REQUIREMENTS

Computer	PC/AT compatible computer
Processor	Pentium 166 or higher
Operating system	Windows®98SE/ME/2000/XP
RAM	16 MB or more
Hard disk drive	15 MB of free space
Installation device	CD-ROM drive (4x or higher)
Connection	USB port
Other Hardware	VGA colour monitor
Other Software	DirectX 8.0a or above


OVERVIEW



SET UP

CONNECTING YOUR GAME CONTROLLER TO A PC

1. Switch on your computer and wait until Windows has finished loading.
2. Insert the driver CD-ROM into your CD-ROM drive. The installation menu appears automatically and the program will install the Game controller driver.
3. Switch on the computer and all the peripherals connected (monitor, printer, external modem, etc.) and wait until the operating system has fully started.
4. Locate a free USB port on your computer.
5. Connect the end of the USB cable (❶) with the free USB socket on your computer (❷).



AUTO-FIRE

SETTING AUTO-FIRE

1. Press and hold the AUTO button.
2. Press the fire button to set auto-fire.
3. Release the AUTO button.
4. Press and hold the fire button to auto-fire.

CLEARING AUTO-FIRE

1. Press and hold the AUTO button.
2. Press the fire button to clear auto-fire.
3. Finally, release the AUTO button.

CUSTOMER CARE

TROUBLESHOOTING

CHECK CONNECTIONS AND CABLES

Start with a careful visual check of all cable links.

- Switch off the computer and check all cable connections. Do not arbitrarily swap the cables between various units, even if they appear to be precisely the same. Once you have ascertained that the power supply is not at fault and all connections are intact, switch on the computer again.

FAULTS AND POSSIBLE CAUSES

The game controller is not recognized or receives no response.

- Have you connected the cable according to the installation instructions? Check all cable connections.
- Did you connect the Game controller before installing the **software**? Remove the USB plug from the port and only connect it to the unit **after** installation.

CONTACTING CUSTOMER CARE

For fast answers to common questions, visit us online at:

<http://www.medionusa.com/disney>

To contact Customer Care by telephone, call (800) 822-3541 between the hours of 7 AM and 10 PM CST, Monday through Friday. On Saturday or Sunday, call between 8 AM and 7 PM CST.

LIMITED WARRANTY

MEDION warrants to our customers that this product is free from defects in materials and workmanship as follows: for a period of one (1) year from the date of original purchase, defective parts or a defective product returned to a MEDION repair facility or a MEDION Authorized Service Facility ("ASF") for such product, as applicable, and proven to be defective upon inspection, will be exchanged for new or comparable rebuilt parts, or a refurbished product, as determined by the MEDION repair facility or the ASF.

Limited warranty repair or replacement shall not extend the original limited warranty period of the defective product. This limited warranty does not cover any supplies or accessories, including but not limited to: software, blank media, user-installed drives, etc.

EXCLUSIONS: this limited warranty does not apply, and you will have no remedy hereunder with respect to (a) products that have been modified, opened, repaired or otherwise altered, except by MEDION or an ASF, (b) products that have been damaged or destroyed after delivery to the customer, (c) any third party software, interfaces, parts, supplies, peripherals or other products or any defects resulting from use of the product in connection with such third party products, (d) defects resulting from improper or inadequate maintenance, calibration or site preparation, (e) defects resulting from any misuse, abuse, accident, neglect, negligence or any use other than in accordance with the handling or operating instructions provided by MEDION, (f) defects resulting from exposure to unusual physical or electrical stress or from any operation other than in accordance with the published environmental specifications for the product.

TO THE EXTENT ALLOWED UNDER APPLICABLE LAW, THE ABOVE WARRANTIES ARE EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND MEDION SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND NO IMPLIED WARRANTY APPLIES TO THE PRODUCT AFTER THE APPLICABLE PERIOD OF THE EXPRESS LIMITED WARRANTY STATED ABOVE. Some countries, states or provinces do not allow exclusions or limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This limited warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.

MEDION's limited warranty is valid in any country or locality where MEDION has a support presence for this product and where MEDION has marketed this product. The level of warranty service you receive may vary according to local standards. MEDION will not alter form, fit or function of the product to make it operate in a country for which it was never intended to function.

TO THE EXTENT ALLOWED UNDER APPLICABLE LAW, THE REMEDIES IN THIS LIMITED WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO

EVENT WILL MEDION OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. IN NO EVENT SHALL RECOVERY OF ANY KIND AGAINST MEDION BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY MEDION WHICH CAUSED THE ALLEGED DAMAGE. WITHOUT LIMITING THE FOREGOING, YOU ASSUME ALL RISK AND LIABILITY FOR LOSS, DAMAGE OR INJURY TO YOU AND YOUR PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING OUT OF USE OR MISUSE OF, OR INABILITY TO USE THE PRODUCT NOT CAUSED DIRECTLY BY THE NEGLIGENCE OF MEDION. Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT AS LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Please note the following:

Be sure to keep your purchase receipt in a safe place. MEDION, at its option, may require a copy of the receipt to validate the warranty period effective date (i.e. date of purchase). Warranty liability only applies to material or factory faults. It does not apply to damage due to breakage, for example, a crack in the housing. Our service includes unit exchange or send-in repair:

Unit Exchange

In locations where Unit Exchange is available, MEDION will send you a replacement unit. You must return the defective unit to MEDION (using the shipping carton that the new one came in.)

Send-In Repairs

In locations where Send-In Repair Service is available, repair service can be obtained by shipping your unit to the MEDION Repair Center. The unit will be repaired and returned to you.

For either Unit Exchange or Send-In Repairs, you must have an authorized RMA number from Medion support before shipping your defective product.

Replacement products may be either new or equivalent in performance to new. MEDION replacement or repaired products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.

Out-of-Warranty Support

In addition to providing free technical support during the warranty period, MEDION is also available to support your product after the warranty period has ended. This out-of-warranty support will be provided on a fee basis.