









Appendix A:Troubleshooting

The following pages describe possible problems you may encounter while using Nikon View 5. If the problem persists, contact your retailer or a Nikon service representative.

Problem	Possible Cause	
Nikon View 5 does not start automatically when a camera or card reader is connected.	<ul style="list-style-type: none">• A memory card is not inserted in the camera or card reader.• The images on the memory card were taken with a make of camera not supported under Nikon View 5.• The camera is not properly installed (Windows only)• Disable Auto Launch is selected in the Auto launch tab of the Preferences dialog.• Your computer is running Nikon Capture 2 or Nikon Capture 3 camera control with your camera connected to the computer.	    —
The thumbnail list is not displayed.	<ul style="list-style-type: none">• The selected folder contains no images.• A folder containing images taken with a Nikon digital camera has not been selected.	 —
Movies cannot be played back	<ul style="list-style-type: none">• A movie player program is not installed.	
Can not find image files which have been transferred to the computer.	<ul style="list-style-type: none">• The destination folder specified in the File Destination and Naming dialog box has been changed.	

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually-updated information is available on-line at the following web-sites:

- For users in the United States of America:

<http://www.nikonusa.com/>

- For users in Europe:

<http://www.nikon-euro.com/>

- For users in Asia, Oceania, the Middle East, and Africa:

<http://www.nikon-asia.com/>

Visit these sites to keep up-to-date with the latest product information and general advice on digital imaging and photography.

For more information, please contact your nearest Nikon representative.

<http://www.nikon-image.com/eng/>

ArcSoft® Customer Service

U.S.A

Phone: 510-440-9901 (Monday-Friday 8:30am-5:30pm PST)

Fax: 510-440-1270

Web: <http://www.arcsoft.com/>

E-Mail: support@arcsoft.com

Mail: ArcSoft, Inc.

46601 Fremont Blvd.

Fremont, CA 94538

U.S.A.

N. America

46601 Fremont Blvd

Fremont, CA 94538

Tel: 1-510-440-9901

Fax: 1-510-440-1270

Web: <http://www.arcsoft.com>

E-Mail: support@arcsoft.com

Latin America

Tel (Brazil): 00817-200-0709

Tel (Chile): 800-202-797

E-Mail: latinsupport@arcsoft.com

Europe

Unit 14, Shannon Industrial
Estate

Shannon, Co. Clare, Ireland

Tel: +353 (0) 61-702087

Fax: +353 (0) 61-702001

E-Mail: eurosupport@arcsoft.com

China

ArcSoft Beijing Co., Ltd.

No.6 South Capital Gym Road

Beijing New Century Hotel

Office Building, #1060

Beijing 100044, China

Tel: 8610-6849-1368

Fax: 8610-6849-1367

E-Mail: tech@arcsoft.com.cn

Japan

Japan Support Center

M.D.S., Inc.

JTT Building 3F

3-3-4 Ueno, Taito-ku

Tokyo 110-0005, Japan

Tel: +81-3-3834-5256

Fax: +81-3-5816-4730

Web: <http://www.arcsoft.jp>

E-Mail: support@arcsoft.jp

Taiwan

ArcSoft Inc. Taiwan Branch

Tel: +886 (0) 2-2718-1869

Fax: +886 (0) 2-2719-0256

Web: <http://www.arcsoft.com.tw>

E-Mail: support@arcsoft.com.tw

