



Quick Setup Guide

1



Plug mouse USB connector into front panel USB port.

2



Plug keyboard USB connector into front panel USB port.






4

Plug power cord into back panel and into 120VAC source.




3

Connect one end of coax cable to IN 1 and the other end to Calibration OUT.



5

Press power button to turn instrument on.







WAVECREST CORPORATION
A TECHNOLOGIES COMPANY

IN 1
DC to 3 GHz

IN 2
DC to 3 GHz

IN 3
DC to 3 GHz

IN 4
DC to 3 GHz

IN 5
DC to 3 GHz

IN 6
DC to 3 GHz



OUT
Calibration

OUT

Making a Measurement with VISI™ Software



6

Select the Histogram Tool using the Clock button on the Main Dialog Bar




7

Turn on the 10MHz square wave.



8

Take a measurement by clicking on the button or the button.



9

Please refer to the SIA-3000 User's Guide for the complete setup and description of all tools and features of the WAVECREST SIA-3000.



WAVECREST CORPORATION
A TECHNOLOGIES COMPANY