

# Field Feature Bill of Material (FFBM)

#### PN 09G2967

# **INSTALLATION** of the Expansion Enclosure (FC 5015)

#### in IBM 3746 Model 900

Written by: JP. Aubin
Checked by: M. Dallier
Approved by: F. Charron
Reviewed by: B. Kelly

3746 PN 09G2967 FFBM 1 of 30 EC D55653 29OCT93

© Copyright IBM Corp. 1993

3746 FFBM

PN 09G2967 2 of 30

EC D55653 29OCT93



# **Before Installation (Steps 1-8)**

#### 1.0 Machines Affected

3746 Model 900.

### 2.0 Related BMs and ECs

## 2.1 Prerequisites

(Must be installed prior to this installation)

- · EC microcode D22482.
- EC documentation C38776.
   Checkpoint: EC level on PRD sheet (vol 1).

#### 2.2 Concurrent

(Must be installed together) None.

## 2.3 Companion

(Must be installed separately) None.

### 3.0 BMs to be Installed

- FFBM 09G2967 Installation instructions
- FFBM 09G2967 Expansion Enclosure installation

## 4.0 Preparation

- 1. Familiarize yourself with the purpose and details of these installation instructions before negotiating machine time with the customer.
- 2. Check all the items and count the parts listed on the BM(s) to be installed to verify whether all parts were received.

# 5.0 Programming

None.

# 6.0 Purpose and Description

Install an expansion enclosure and associated cabling in a 3746 Model 900.

## 7.0 Installation Time

FFBM	Machine	System
Installed	Hours	Hours
09G2967	1.0	0.0

# 8.0 Tools/Materials Required

ESD kit (PN 6428316).

PN 09G2967 3 of 30	EC D55653 29OCT93		


# **Installation (Steps 9-11)**

# 9.0 Safety

- This installation must be performed 3746-900 power off.
- Review the Safety Inspection Procedures and the Safety Notices located at the beginning of the 3745 Maintenance Information Procedure (MIP) manual, SY33-2054.

### 10.0 Details of Installation

- \_\_ 1. Ask the customer to deactivate all the lines connected to the 3746-900.
- 2. From the control panel of the 3746-900, set the **Power Control** indicator to **3**, and press the **Validate** key.
- \_\_ 3. Press the **Standby** key and wait for Standby indicator to remain on.
- \_\_\_ 4. Open the front and rear system covers.
- \_\_ 5. Switch OFF the CB1(s).



EC D55653 29OCT93		
----------------------	--	--




#### 10.1 Hardware Installation


#### 10.1.1 Covers Removal

From the rear of the 3746-900:

- 1. Unfasten the 4 screws of cover 5. Remove the cover and save for reinstallation.
- 2. Unfasten the 4 screws of cover 3. Remove the cover and save for reinstallation.
- \_\_\_ 3. Unfasten the 3 screws of the left cover. Remove the cover and save for reinstallation.
- 4. Unfasten the 2 screws of cover 4. Remove the cover and save for reinstallation.
- \_\_\_ 5. If present, remove cable(s) from clamp(s) on the cover 1.
- 6. Unfasten the 2 screws of cover 1. Remove the cover and save for reinstallation.
- \_\_\_\_ 7. Unfasten the 5 screws of cover 2. Remove the cover and save for reinstallation.




3746 PN 09G2967 EC D55653 29OCT93



#### From the front of the 3746-900:

- \_\_\_ 8. Remove the cover 9 (2 screws). Save parts for reinstallation.
- 9. Remove the cover 10 (2 screws). Save parts for reinstallation.



3746	PN 09G296
FBM	6 of 30

EC D55653		
29OCT93		




#### 10.1.2 Enclosure Installation

From the rear of the 3746-900:

- \_\_ 1. Remove the dummy enclosure 1 (four screws 2).
- \_\_ 2. Slide the enclosure 3 (PN 03F7365) into the frame.
- \_\_ 3. Secure with eight screws 4 (PN 1621210).

From the front of the 3746-900:

\_\_\_ 4. Install the two ground jumpers 5 (PN 72F1250) with 4 screws (PN 1621191) and 1 lockwhasher (PN 1785853).



3746	PN 09G2967
FFBM	7 of 30


EC D55653		
29OCT93		



#### 10.1.3 SPD2 Cassette and Cables Installation

From the rear of the 3746-900:


- \_\_ 1. Plug the SPD2 cassette 1 in position A.
- 2. Plug and route the cable 2 (PN 72F1193) from SPD2-J1 to SPD1-J2.
- \_\_\_ 3. Move the plug, on cable 3 (PN 03F7578) from the dummy connector to SPD2-J2 4.
- 4. Install the dummy coupler **5** (PN 03F7522) in position Q.




Rear View

EC D55653 29OCT93				
----------------------	--	--	--	--

- \_\_ 5. Plug and route the cable 2 (PN 03F7643) from SPD2-J5 3 to DCDP-J3 4.
- \_\_\_ 6. Verify that CP4 and CP5 are set ON.
- \_\_\_ 7. Reinstall cover 1 and its cables in clamps (if previously removed).





Front View

3746 FFBM

ΡN	09G2967	7
9 o	30	


EC D55653		
29OCT93		



### 10.1.4 CSCE Cassette and Cable Installation

From the front of the 3746-900:

- 1. Plug the CSCE cassette 1 in position A.
- 2. Plug the CSCE cable 2 to CS connectors D through P (grey area).
- 3. Install the blanking plate 3 (PN 03F7448) with 2 screws 3 (PN 1621210).
- 4. Reinstall all covers previously removed in step 10.1.1, "Covers Removal" on page 5.



#### 10.2 Power ON

\_\_\_ 1. Switch ON the CB1(s) and close the system covers.

Wait until the Standby LED comes ON.

2. Press the **Start** key.

Wait for SRC 00-00-0000 displayed on the control panel.

3. Set the **Power Control Mode** indicator to its initial value.

Press the Validate key.

#### - Important Note -

From this point, the traffic can be restarted and feature cassettes can be installed in concurrent maintenance via other MES.

Then, install the dummy processor (PN 03F7521) and coupler (PN 03F7522) cassettes received with this FFBM (an enclosure must be fully populated).

#### 11.0 Test Procedures

None.

# After Installation (steps 12-15)

# 12.0 Field Updating

None.

## 13.0 Publications Update

None.

## 14.0 Parts Disposition

#### 14.1 Purchased Machines

Refer to the parts ownership matrix to determine the correct owner of removed/unused parts.

- For EMEA/APG/AG Areas, refer to Hardware and General Service Code Description.
- For Domestic Areas, return parts to the customer.

## 15.0 Machine Records

- · Install the new MACHINE HISTORY supplied.
- Report installation and quality to existing procedures.

End of instructions.

3746	PN 09G2967	EC D55653		
FFBM	11 of 30	29OCT93		

3746 PN 09G2967 FFBM 12 of 30 EC D55653 29OCT93