


# 取扱説明書 ブラケット **KRB3-PLZ-50F**

Part No. Z1-901-220, IA003223


Feb. 2008

次の手順で機器にブラケットを取付け、ラックに組み込みます。


1. 底部のゴム足、側面のゴム足およびハンドルを取り外します。



2. ②のねじを使用して①のブラケットを図のように取り付けます。  
②のねじは、付属のねじ (M4 x 8皿ねじ) 以外は使用しないでください。




3. ③のねじと④のワッシャを使用してラックに取り付けます。



注意

機器が落下する恐れがあります。  
使用するラックに適合したサポートアングルを取り付けて、本体を支持してください。



No.	コード	説 明	数量
1	B9-000-025	BRKT KRB3-TOS L/R	2
2	M2-101-015	FLH SCREW S-NI M4X0.7X8	4
3	M2-102-002	MARU-SARA SCREW M5X0.8X14	4
4	M5-003-031	CUP WASHER 5 CW	4



菊水電子工業株式会社


本社・技術センター 〒224-0023 横浜市中区東山田 1-1-3 TEL: 045-593-0200 (代)

# INSTRUCTION MANUAL


## Bracket KRB3-PLZ-50F

Install the brackets to the instrument in the next procedure and build in it to the rack.


1. Remove the rubber feet on the bottom panel, the rubber feet on the side panel and handle.




2. As shown in figure, using ② screws, install ① brackets.  
For ② screws, do not use except the accompanying screws (M4 x 8 flat head screws).



3. Using ③ screws and ④ washers, mount the instrument in the rack.



**CAUTION** The instrument may fall.  
Install the suitable support angles  
applying to the used rack system to  
support the instrument.



No.	CODE	DESCRIPTION	QTY
1	B9-000-025	BRKT KRB3-TOS L/R	2
2	M2-101-015	FLH SCREW S-NI M4X0.7X8	4
3	M2-102-002	OVH SCREW S-NI M5X0.8X14	4
4	M5-003-031	CUP WASHER 5 CW	4



KIKUSUI ELECTRONICS CORP.

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, 244-0023, Japan