
Contents

About This Document.....	1
1 Safety Precautions.....	1-1
1.1 General Instructions.....	1-2
1.2 Symbols.....	1-2
1.3 Toxic Articles.....	1-3
1.4 Electric Safety.....	1-4
1.5 ESD Protection.....	1-6
1.6 Microwaves and Magnetic Fields.....	1-8
1.7 Laser.....	1-8
1.8 High Temperature.....	1-8
1.9 Aloft Work.....	1-8
1.10 Others.....	1-11
2 Typical RET Antenna System.....	2-1
2.1 Cabinet + BT + RET Antennas + RCU + SBT.....	2-2
2.2 Cabinet + BT + Cascaded RET Antennas + RCU + SBT.....	2-3
3 Typical Antenna System Shared Between 2G and 3G Base Stations.....	3-1
3.1 Shared RET Antenna; Independent Feeders.....	3-2
3.2 Independent RET Antennas; Shared Feeders.....	3-3
3.3 Shared Cascaded RET Antennas; Independent Feeders.....	3-5
3.4 Shared Cascaded RET Antennas; Shared Feeders.....	3-7
4 Introduction to RET Antenna Line Devices.....	4-1
4.1 RET Antennas.....	4-2
4.2 Feeders and Jumpers.....	4-3
4.3 RCUs.....	4-4
4.4 SBTs.....	4-5
4.5 AISG Control Cable.....	4-6
4.6 BTs.....	4-8
4.7 Splitters.....	4-9
5 Control of RET Antennas.....	5-1
5.1 Control of Macro Base Station RET Antennas.....	5-2
6 Antenna System Installation Preparations.....	6-1

6.1 Spacing Requirements for GSM Antenna Installation.....	6-4
7 Procedure for Installing the GSM RET Antenna System.....	7-1
8 Installing the Grounding Bar.....	8-1
9 Installing Antenna Supports.....	9-1
9.1 Installing the Antenna Support on the Tower.....	9-2
9.2 Installing the Antenna Support on the Rooftop.....	9-5
10 Assembling Antennas.....	10-1
10.1 Assembling Omnidirectional Antennas.....	10-2
10.2 Assembling Directional Antennas.....	10-2
11 Hoisting Antennas.....	11-1
12 Installing Antennas.....	12-1
12.1 Installing an Omnidirectional Antenna on the Tower Platform.....	12-2
12.2 Installing a Directional Antenna on the Tower Platform.....	12-4
12.3 Installing an Omnidirectional Antenna on the Rooftop.....	12-9
12.4 Installing a Directional Antenna on the Rooftop.....	12-11
13 Installing the Splitters.....	13-1
13.1 Installing the Splitters on the Antenna Side.....	13-2
13.2 Installing the Splitters on the Base Station Side.....	13-3
14 Installing RET Antenna Line Devices.....	14-1
14.1 Installing the RCU.....	14-2
14.2 Installing the AISG Extension Cable of the RRU3801C.....	14-4
14.3 Installing the SBT.....	14-5
15 Installing Feeders.....	15-1
15.1 Routing Feeders.....	15-2
15.2 Installing Feeder Grounding Kits.....	15-8
15.2.1 Grounding Locations of the Feeder Grounding Kits of the Mini Base Station.....	15-10
15.2.2 Grounding Locations of the Feeder Grounding Kits of the Macro Base Station.....	15-14
15.3 Leading Feeders into the Equipment Room.....	15-16
16 Installing the Jumpers Between the Feeders and the Cabinet.....	16-1
17 Testing the Antenna System.....	17-1
18 Labeling the Antenna System.....	18-1
19 Waterproofing the Feeder Window.....	19-1
20 Checking the Installation of the RET Antenna System.....	20-1
20.1 Checklist for Antenna Installation.....	20-2
20.2 Checklist for Feeder Installation.....	20-2
20.3 Checklist for Jumper Installation.....	20-3
20.4 Checklist for Grounding Bar Installation.....	20-4

20.5 Checklist for Feeder Window Installation.....20-4

20.6 Checklist for RET ALD Installation.....20-4

20.7 Checklist for Field Cleanliness of the Antenna System.....20-4

Figures

Figure 1-1 Putting on an ESD wrist strap.....	1-7
Figure 1-2 Fully unfolded A-shaped ladder.....	1-9
Figure 1-3 Ladder slant.....	1-10
Figure 1-4 Using the long ladder in a safe way.....	1-10
Figure 1-5 Ladder with its top end one meter above the eave.....	1-11
Figure 1-6 Hoisting a heavy object.....	1-12
Figure 1-7 Laying down and placing upright the cabinet.....	1-12
Figure 2-1 Cabinet + BT + RET Antennas + RCU + SBT.....	2-3
Figure 2-2 Cabinet + BT + cascaded RET Antennas + RCU + SBT.....	2-4
Figure 3-1 Shared RET antenna and RCU between the DBS3800 and the 2G base station (independent feeders)	3-2
Figure 3-2 Shared RET antenna and RCU between the BTS3812E and the 2G base station (independent feeders)	3-3
Figure 3-3 Feeders shared between the 20 W RRU3801C and the 2G base station (independent RET antennas)	3-4
Figure 3-4 Feeders shared between the BTS3812E and the 2G base station (independent RET antennas).....	3-5
Figure 3-5 Cascaded RET antenna shared between the DBS3800 and the 2G base station (independent feeders)	3-6
Figure 3-6 Cascaded RET antenna shared between the BTS3812E and the 2G base station (independent feeders)	3-7
Figure 3-7 Cascaded RET antenna and feeders shared between the 20 W RRU3801C and the 2G base station	3-8
Figure 3-8 Cascaded RET antenna and feeders shared between the BTS3812E and the 2G base station.....	3-9
Figure 4-1 Working principles of RET antennas.....	4-2
Figure 4-2 Connections of the feeder and jumpers in the antenna system.....	4-3
Figure 4-3 Kathrein RCU and Powerwave RCU.....	4-5
Figure 4-4 Kathrein SBT and Powerwave SBT.....	4-6
Figure 4-5 0.5-m-long AISG control cable.....	4-7
Figure 4-6 2-m-long AISG control cable.....	4-8
Figure 4-7 15-m-long AISG control cable.....	4-8
Figure 4-8 BT.....	4-9
Figure 4-9 1-for-3 Kathrein splitter.....	4-10
Figure 5-1 SBT + RCU.....	5-2
Figure 6-1 Dimensions of the 12-hole feeder window.....	6-2
Figure 6-2 Structure of the 12-hole feeder window.....	6-2

Figure 8-1 Indoor grounding bar.....	8-1
Figure 8-2 Installing a grounding bar on the wall.....	8-2
Figure 9-1 Structure of the antenna support on the tower platform.....	9-2
Figure 9-2 Protection coverage of the lightning arrester.....	9-3
Figure 9-3 Hoisting the antenna support or the antenna.....	9-4
Figure 9-4 Installing the antenna support on the tower platform.....	9-5
Figure 9-5 Structure of the antenna support on the rooftop.....	9-6
Figure 9-6 Protection coverage of the lightning arrester.....	9-7
Figure 10-1 Assembling fixing clips for the omnidirectional antenna.....	10-2
Figure 11-1 Hoisting the antenna support or the antenna.....	11-2
Figure 12-1 Installing the omnidirectional antenna.....	12-3
Figure 12-2 Omnidirectional antenna installed on the tower platform.....	12-4
Figure 12-3 Relation between the azimuth of directional antenna and the sector.....	12-6
Figure 12-4 Directional antenna with the pitch angle corresponding to the installation hole.....	12-7
Figure 12-5 Angle display before the adjustment of the pitch angle.....	12-7
Figure 12-6 Angle display after the adjustment of the pitch angle.....	12-8
Figure 12-7 Adjusting the pitch angle.....	12-8
Figure 12-8 Directional antenna installed on the tower platform.....	12-9
Figure 12-9 Omnidirectional antenna installed on the rooftop.....	12-11
Figure 12-10 Relation between the azimuth of directional antenna and the sector.....	12-12
Figure 12-11 Directional antenna with the pitch angle corresponding to the installation hole.....	12-13
Figure 12-12 Angle display before the adjustment of the pitch angle.....	12-14
Figure 12-13 Angle display after the adjustment of the pitch angle.....	12-14
Figure 12-14 Adjusting the pitch angle.....	12-15
Figure 12-15 Directional antenna installed on the rooftop (without parapet, with TMA).....	12-16
Figure 12-16 Directional antenna installed on the rooftop (with TMA and wall higher than 1,200 mm).....	12-17
Figure 13-1 1-for-3 splitter installed on the antenna side.....	13-3
Figure 13-2 1-for-3 splitter installed on the base station side.....	13-4
Figure 14-1 Removing the protective cap.....	14-2
Figure 14-2 Adjusting gear and spindle.....	14-3
Figure 14-3 Adjusting spindle.....	14-3
Figure 14-4 Removing the black adjusting gear.....	14-4
Figure 14-5 Installing the RCU.....	14-4
Figure 14-6 Installing the SBT.....	14-5
Figure 14-7 Installing the SBT jumper.....	14-6
Figure 15-1 1-for-1 feeder clip.....	15-2
Figure 15-2 1-for-3 feeder clip.....	15-2
Figure 15-3 Protection treatment for the feeder connector (unit: mm).....	15-4
Figure 15-4 Laying the feeders from the tower top to the feeder window.....	15-6
Figure 15-5 Laying the feeders from the rooftop to the feeder window.....	15-7
Figure 15-6 Installing the feeder grounding kits (a).....	15-8
Figure 15-7 Installing the feeder grounding kits (b).....	15-8

Figure 15-8 Grounding before leading the feeder into the equipment room (with outdoor grounding bar).....	15-9
Figure 15-9 Grounding before leading the feeder into the equipment room (without outdoor grounding bar)	15-10
Figure 15-10 Grounding locations of feeders between the base station and antennas mounted on a pole.....	15-11
Figure 15-11 Grounding locations of feeders between the base station and antennas not mounted on a pole	15-12
Figure 15-12 Feeder grounding for the base station mounted on a tower.....	15-13
Figure 15-13 Feeder grounding for the base station mounted indoors.....	15-14
Figure 15-14 Grounding for the RF antenna mounted on the tower platform.....	15-15
Figure 15-15 Grounding for the RF antenna mounted on the rooftop.....	15-16
Figure 15-16 Routing the feeders through the feeder window.....	15-17
Figure 18-1 Feeder labels (unit: mm).....	18-2
Figure 18-2 Binding a label.....	18-3
Figure 18-3 Fastening the label.....	18-3
Figure 19-1 Waterproofed feeder window.....	19-1

Tables

Table 4-1 Choosing proper feeders..... 4-4

Table 4-2 Relation between the BT quantity and the antenna system components..... 4-9

Table 6-1 Tools and instruments for the antenna system installation..... 6-1

Table 6-2 Spacing requirements for omnidirectional antenna installation.....6-4

Table 6-3 Spacing requirements for directional antenna installation.....6-5

Table 18-1 Contents of a feeder label.....18-1