

Instruction manual

Output Cable TL21-PFX

The TL21-PFX is a dedicated output cable for use in connecting a Kikusui PFX2421 Capacitor Tester to a DUT (capacitor). The cables that are necessary for making this connection are already assembled.

Before you use the TL21-PFX thoroughly read the warnings and precautions that are written in the PFX2400 series Capacitor Tester operation manual.

How to Use

Be sure to bind the current cables and the shielded cable with the attached cable tie.

Using the cable when its extra length is wound or twisted may cause problems such as abnormal oscillation or overshoot. To avoid these problems, make the cable as short as possible.

It is recommended to install fuses between the PFX2421 and the DUT (capacitor) to prevent short-circuiting of the current wire or the shielded wire and to secure the connection. Install the fuse or switch as close to the DUT (capacitor) terminal as possible.




To avoid short-circuiting, observe the following precautions.


- **First connect the cable to the PFX2421, and then connect the cable to the DUT (capacitor).**
- **Do not step on or place heavy objects on the cable, especially the shielded wire.**



If you are using the cable in a high-temperature environment such as in a temperature chamber, make sure that the operating temperature does not exceed 105 °C.



Specifications



Maximum operating voltage		10 Vdc
Maximum operating current		80 A
Maximum operating temperature		105 °C
Cable termination	DUT (capacitor) side	Current wire: No stripping Voltage sensing wire: Strip-off (approx. 6 mm)
	PFX2421 capacitor tester side	Current wire: R22-8 crimp terminal Voltage sensing wire: 1.25-3 crimp terminal
Size		Current wire: AWG4 (nominal cross section: 22 mm ²) Shielded wire (core wire) : AWG24
Length		Approx. 5m

KIKUSUI ELECTRONICS CORP.

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, 224-0023, Japan
TEL : +81-45-593-7570 Fax : +81-45-593-7571

<http://www.kikusui.co.jp/en>