

TECHNICAL MANUAL

TRP 8250 D SERIES

**** NOTE. The technical manual for the TRP 8400 series is based on the TRP 8250 D series manual, with all deviations described in the rear AMENDMENTS .***

All information contained in the manual including all drawings, specifications, data or other material, is the property of SKANDINAVISK TELEINDUSTRI SKANTI A/S, is disclosed in confidence for use only in operating and maintaining the equipment described herein, is subject to change without notice, is not to be copied and is not to be used or disclosed for any other purpose, without the written consent of SKANDINAVISK TELEINDUSTRI SKANTI A/S.

CONTENTS

INTRODUCTION

1.1 Distress operation on 2182 kHz	1-1
2. Introduction	2-1
2.1 Basic versions	2-3
3. Technical data	3-1
3.1 General	3-1
3.2 Receiver characteristics	3-1
3.3 Transmitter characteristics	3-4
3.4 Antenna Tuning Unit	3-5
3.5 Power requirements	3-5
3.6 Dimensions and weights	3-5

OPERATION

4. Operation	4-1
4.1 Operating instructions	4-1
4.2 Description of operating controls	4-21

INSTALLATION

5. Installation	5-1
5.1 Mounting the Control Unit	5-1
5.2 Mounting the Transceiver Unit	5-1
5.3 Mounting the Antenna Tuning Unit	5-1
5.4 Power Supply	5-2
5.5 Earth Connections	5-2
5.6 Antennas	5-3
5.7 Interconnection of Units	5-3
5.8 Connection of External Equipment	5-4
5.9 Final Installation Check	5-5
5.10 Remote frequency Control	5-6
5.11 Configuration Prom Programming	5-7

TECHNICAL DESCRIPTION

6. Technical Description	6-1
6.1 Control Unit	6-1
6.2 Transceiver Unit	6-1
6.3 Antenna Tuning Unit	6-1
6.4 AC Power Supply Unit	6-2
6.5 ALC and Protection system	6-2

SERVICE

7. Preventive Maintenance	7-1
7.1 Realignment of Master Oscillator 612 613 614	7-1
7.2 Realignment of Master Oscillator 615 616	7-2
7.3 Replacement of Backup Battery	7-3
8. Trouble Shooting and Service	8-1
8.1 Malfunction	8-1
8.2 Replacement of FUSES	8-1
8.3 Manual tuning to 2182 kHz in case of failure in the ATU	8-2
8.4 Description of Self Test functions	8-3
8.5 Spare Parts list, TRP 8250 D Series	8-31

DIAGRAMS

9. Circuit Description and Diagrams	9-1
9.1 Symbol Explanation	9-1
9.2 Abbreviations	9-2

AMENDMENTS

10. SKANTII Service Agents	10-1
----------------------------------	------