



Digital Oscilloscopes DL9000 Series



● Fast acquisition rate

- Up to 25,000 frames/sec/channel in continuous mode (when the Accumulate function is used)
- Up to 2.5 million frames/sec/channel in N Single mode

● History Memory function

- With a partitioned large-capacity memory, the DL9000 can automatically accumulate and display up to 2,000 waveform frames.

● Bandwidth and Sampling Rate

	DL9040/DL9040L	DL9140 / DL9140L	DL9240 / DL9240L
Analog frequency bandwidth	500 MHz	1.0 GHz	1.5 GHz
Maximum sampling rate	5 GS/s	5 GS/s	10 GS/s




Compact digital oscilloscopes with up to 1.5 GHz bandwidth and a 10 GS/s sampling rate.
History Memory function dramatically increases the performance of the large-capacity memory.
The enhanced performance and functionality make the DL9000 series the perfect signal measurement solution.

History Memory


Capture only the desired data for long periods of time.
 Make full use of the large-capacity memory to increase development efficiency without acquiring useless data.

Efficient Waveform Measurement


Collective measurement with large-capacity memory



Waveform comparison using memory partitioned into up to 2,000 areas




Isolate Abnormal Waveforms



History Replay Function

You can go back to previously-captured waveforms in History Memory and view them one by one, just like browsing address book entries. Furthermore, you can use the new History Replay function to continuously play back, stop, fast-forward, and rewind captured waveforms like a video recording.

Replay!



High Speed Response

Fast display updates, even when processing mega-words of data

Yokogawa's proprietary signal-processing IC (Advanced Data Stream Engine [ADSE]) has made the History Memory function and display functions far more advanced than those of conventional scopes. High-speed data processing is achieved using this hardware-based computation.


Maximum update rate in math mode:

60 frames/sec (1 MW, when adding channels)
 12 frames/sec (5 MW, when adding channels)

Maximum update rate in parameter measurement mode:

60 frames/sec (1 MW, when measuring a channel's maximum value)
 16 frames/sec (5 MW, when measuring a channel's maximum value)

Note: The above rates can vary depending on the oscilloscope settings.





Advanced Data Stream Engine (ADSE)

Enjoy the combination of dramatically enhanced performance and functionality!


Dot Density Display

Displays waveforms like an analog oscilloscope


The dot density display function varies the brightness of each display pixel, depending on how often waveforms pass through it. The DL9000 can rapidly capture waveforms at an acquisition rate of up to 25,000 waveforms/sec. Thus the oscilloscope can show eye patterns and perform real-time display processing even when capturing repetitive signals. ADSE-driven high-speed signal processing enables the digital oscilloscope to provide analog oscilloscope-like waveform displays.



Single waveform




You can freely change from overlaid waveforms to any single waveform and vice versa as the DL9000 retains up to 2,000 frames of waveform data.



Single waveform (full-wave comparison)

Overlaid waveforms using dot density display



Overlaid waveforms in colors

Enhanced functions for all signal handling tasks — capture, display, search and analysis



Waveform Capture — Filter functions —

To be able to observe signals after filtering out unnecessary components is extremely useful during circuit design. The DL9000 series is equipped with two types of filters, the input stage filters and filters based on high-speed computation. You can filter out unnecessary signal components during signal capture or apply high-speed filtering afterwards.

Filters in the input stage

- Analog filters: 200 MHz/20 MHz
- Real-time digital filters: 8 MHz/4 MHz/2 MHz/1 MHz/500 kHz/200 kHz/125 kHz/62.5 kHz/32 kHz/16 kHz/8 kHz


Filters based on computation

Select low pass or high pass filters with variable cutoff frequencies

Display filtered waveforms in real time at up to 60 frames/sec.

Simultaneously display both pre-filtered and post-filtered waveforms.

Desired filter setting: The lowpass/highpass filter frequencies and cutoff frequency can be set to values from 0.01 Hz to 1.0 GHz.



Example of input stage filtering



Example of computation filtering: PWM waveform analysis
 Yellow: PWM waveform
 Red: Filtering-based trend display of pulse widths

Waveform Capture — Advanced trigger functions —

The DL9000 series can be triggered using two or more channels in addition to an edge trigger or TV trigger. You can capture only the desired signals by combining various trigger types and thereby predetermining trigger conditions. Effective filtering helps to shorten the time needed to evaluate and troubleshoot a design.

DL9000 Series' Trigger Functions

Edge/state triggers

- Edge
- Edge (Qualified: conditional)
- Edge OR
- State

Pulse width triggers

- Pulse width
- Pulse width (Qualified)
- Pulse state

(Triggered using the length of period during which the conditions are true)

Enhanced triggers


- TV (NTSC/PAL (SECAM)/HDTV)
- I²C
- SPI
- CAN
- Serial pattern (define patterns up to 128 bits long)

Event interval triggers

- Event cycle
- Event delay
- Event sequence


Examples of Trigger Application

Trigger-based gating — Edge (Qualified): conditional trigger —
 The valid/invalid state of an edge trigger or pulse width trigger can be controlled according to the conditions of any other channel's state (high/low).




Setup and hold time triggers

To derive setup time/hold time conditions, event delay/event sequence triggers are set as shown in the following figure.




Slew rate trigger — Window comparator and pulse state —

The time taken to pass through the voltage level range specified for the window comparator is used to detect the pulse rise/fall time. With pulse state triggers, it is possible to derive trigger conditions, such as "More Than," "Less Than" and "Between," by specifying the ranges of rise time/fall time.



Runt pulse trigger

Runt pulses (pulses with levels lower than those of normal pulses) can also be captured in the same way as explained above. A runt pulse stays too long within the range set by the window comparator, as shown in the following figure. It is therefore possible to capture the runt pulse by setting the trigger conditions to a rise time longer than those of normal pulses.




Waveform Search and Display — Searching for and displaying selected waveforms from the large-capacity memory —

Dual-window Zoom function simultaneously zooms in on two areas

The DL9000 series allows the zooming magnification and position to be set separately for two different areas of a waveform. Thus you can change the timebase scale and view the two windows simultaneously.

The waveform on the right shows a measurement example of the time taken from the point of power-on to the point of gate array oscillation. The DL9000 measures the time length from the rising edge occurring immediately after power-on (cursor 1 of Zoom 1), to the start of oscillation (cursor 2 of Zoom 2).



Auto Scroll function for observing the entire waveform

Use the auto scroll function to automatically move the zoom windows through a long acquisition. Selecting the area to be zoomed-in on can be done easily by scrolling forward, backward, fast forwarding or pausing.

A variety of search functions

The DL9000 series has a variety of waveform search functions, enabling you to detect abnormal signals or find specific serial or parallel data patterns.

Data search types include:

- State search (based on high/low states of one or more channels)
- Serial pattern search (I²C/SPI/CAN/general-purpose pattern)
- Zone search
- Waveform window search
- Waveform parameter search (measured parameters, FFT, etc.)

Waveform Analysis — Serial bus analysis I²C/SPI/CAN —

The DL9000 can perform I²C, SPI and CAN bus analysis with the different available options (/F5, /F7 and /F8). Triggers for these bus types are standard features. These functions make it easy to discriminate between partial software failures and physical-layer waveform problems when troubleshooting systems by observing the physical-layer characteristics of signals.

Real-time bus analysis-up to 15 updates/sec


The DL9000 displays protocol analysis results while concurrently capturing bus signals.

Simultaneous analysis of different buses


With the Dual-window Zoom function, the DL9000 can simultaneously analyze and display the waveform of buses running at different speeds.

Serial data bus trigger functions

A variety of trigger conditions can be set, including triggers based on ID-Data combinations and combinations of a serial bus trigger and a regular edge trigger.



Example of High-speed/Low-speed CAN Bus Analysis Display
 CAN 500kbps
 CAN 125kbps

Example of I²C Bus Analysis Display

Advanced Analysis and Math Functions

Automatic Waveform Parameter Measurements


You can automatically measure waveform parameters, including max., min., peak-peak, pulse width, period, frequency, rise time, fall time, and duty ratio. You can also calculate the statistics of waveform parameters, such as the average, max., min., and standard deviation, over multiple cycles within an acquisition or over multiple acquisitions.



Trend Displays



The DL9000 graphs the long-term trends of data items obtained by automatic waveform parameter measurements. With the Trend display, you can observe short-term cyclic waveform fluctuations within a single frame, or medium to long-term waveform fluctuations by plotting frame-by-frame periods.

Pulse Width Trends of a switching power supply.




Histogram Displays

Histograms show waveform behavior, over an extended period time, relative to time (jitter) and voltage (noise). According to an on-screen histogram, you can analyze statistics, including max., min., average, and standard deviation. You can also display waveform parameter histograms, such as voltage P-P, frequency etc., to see how parameters vary over time.




Eye Pattern Analysis and Mask Testing

◆ Eye Pattern Analysis
This function automatically measures the waveform parameters of an eye pattern. Unlike the waveform parameter measurement of earlier DL series oscilloscopes, the DL9000 can calculate parameters based on the eye pattern formed by the crossings of two or more waveforms.



◆ Mask Testing
This function is used to evaluate the signal quality of high-speed data communication. Using Mask Editor software, a mask pattern is generated and loaded into the DL9000.
(The Mask Editor software can be downloaded from Yokogawa Electric's web page.)

① Mask pattern generation using the Mask Editor software
② After loading the mask pattern to the DL9000, you can perform error rate analysis or go/no-go judgment.




Math Functions (Addition, Subtraction, Integration, Edge Count, and Rotary Count)

You can calculate and display up to 8 math traces. The functions to choose from include: Filtering, +, -, x, Integration, Edge Count and Rotary Count. Since basic arithmetic operations are performed using hardware, the DL9000 can display results in real time.



The figure on the right shows the voltage and current waveforms of a switching power supply. The red math trace M1 has been calculated under the following conditions:

M1 = Ch. 1 (voltage) × Ch. 2 (current)
Ch. 1: Differential voltage probe (yellow)
Ch. 2: Current probe (green)



Example of a Switching Power Supply's Waveform Obtained by the Multiplication "Voltage × Current"

◆ Real-time Math Traces (Rotary Count)
This function counts and displays the number of edges between 2 input signals (Phases A and B). E.g., if Phase B leads (negative phase sequence), this function counts down. This function can be used to check the rotational angle of a motor.



USB Compliance Test Solution

Flexible System Configuration

A DL9240 or DL9240L together with the USB test fixture, test software and probes, allow you to test a USB device, host or hub for compliance to USB-IF specifications.

User-friendly Operability based on PC Software



The test software shows connection methods and test procedures in a wizard form for each test item. It shows connections, settings and operations necessary for carrying out each test enabling even first-time users to perform test easily.

Collaboration with Xviewer

You can output waveform data from a test result window to analyze failed signals using the Xviewer waveform analysis software.

Example of System Configuration


DL9240 or DL9240L digital oscilloscope (with Ethernet option)
• PBD2000 differential probe (one or two)
• PBA2000 active probe (two or three)
• 701933 current probe (one)
• Test bed PC (English Windows XP)
• 3 1/2-digit or greater DMM
• Pulse generator
• 701985 USB test fixture and software (one)



Detailed waveform analysis is possible with the Xviewer Waveform Analysis Software

For more information, see Bulletin 7019-85E, "USB 2.0-compliant Test Solutions."

Versatile Connectivity



GO/NO-GO I/O
Can be used to output the results of either GO/NO-GO tests or mask tests for communication purposes as a TTL level signal.

Probe power
(Factory-set option)




GPIB interface
A PC card slot is standard. A National Instruments' PCMCIA-GPIB card is required to be able to use the GPIB interface.


Trigger I/O
Separate ports available for external trigger input and output.

Trigger comparator OUT
Trigger types not supported by the DL9000 can be realized with external circuits that utilize the trigger comparator outputs of respective channels.

USB-PC connection port (Factory-set option)
Can be used to control the DL9000 externally or to upload data from the DL9000 to a PC.




Software Tools



Xviewer (optional software)

Xviewer runs on a PC and can be used to view waveforms captured with the DL9000 and to convert binary waveform data to ASCII data. Adding the Math option to Xviewer enables you to freely define computational expressions and to perform waveform math. This software supports FFT calculations with a maximum record length of 2 M words.



MATLAB Control Tool Kit (Optional software)

With the MATLAB tool kit, you can easily deal with waveform data captured using the DL series oscilloscope in a MATLAB environment. The software can be used to control the DL series' panel settings or to transfer data from the DL series to MATLAB.

DL Series Library (freeware)

This API lets you control the DL9000 series from an external program or to transfer the DL9000 series' data to the external program. The API is available as a DLL and can be accessed from your program.

Optional Accessories



PBA2500 2.5 GHz active probe



This active probe can be used in combination with the DL9000 series to measure signals with an analog bandwidth up to 1.5 GHz.

Bandwidth: DC to 2.5 GHz (-3 dB)
Attenuation and DC accuracy: 10:1 ($\pm 2\%$)
Input resistance: 100 k Ω ($\pm 2\%$)
Input capacitance: Approx. 0.9 pF (typ.)
Dynamic range: ± 7 V

PBD2000 2.0 GHz differential probe



This differential probe is suited for observation of fast differential signals, such as LVDS. Using this probe in combination with the DL9000 series, you can observe differential signals with an analog bandwidth up to 1.5 GHz.


Bandwidth: DC to 2.0 GHz (-3 dB)
Attenuation and DC accuracy: 10:1 (50 Ω)
Input capacitance: Approx. 1.1 pF (typ.)
Max. differential input voltage: ± 5 V

PB500 500 MHz passive probe




Input resistance: 10 M Ω $\pm 2\%$ (when used with the DL9000)
Input capacitance: Approx. 14 pF (typ.) (when used with the DL9000)
Attenuation: Fixed to 1/10
Bandwidth: DC to 500 MHz (within -3 dB)
Max. input voltage: ± 600 V DC + AC peak

PBL5000 5 GHz low capacitance probe



This wideband low capacitance probe can be used with the 50 ohm input setting.

Connector type: SMA
Input resistance: 450 Ω or 950 Ω
Input capacitance: Approx. 0.25 pF (typ. 450 Ω), 0.4 pF (typ. 950 Ω)
Attenuation: 10:1 or 20:1
Bandwidth: DC to 5 GHz (-3 dB)
Max. input voltage: 20 Vrms, 40 VACpeak

701920 ± 12 V/500 MHz differential probe

Bandwidth: DC to 500 MHz (within -3 dB)
Attenuation: 1/10 (fixed)
Input impedance (typ.): 100 k Ω /2.5 pF
Max. allowable differential voltage: ± 12 V (DC + ACpeak)
Max. common mode input voltage: ± 30 V (DC + ACpeak) (Output impedance: 50 Ω)

701975 50 ohm DC block



This DC block is used to remove bias voltage occurring when the PBL5000 probe is used.

Overall length: Approx. 25 mm
Connector type: SMA
Input impedance: 50 Ω
Frequency range: 20 MHz to 6 GHz
Max. input voltage: ± 10 V (DC + ACpeak)


701921 ± 700 V/100 MHz differential probe

Bandwidth: DC to 100 MHz (-3 dB)
Attenuation: 1/10 or 1/100 (selectable)
Max. allowable differential voltage: ± 700 V (DC + ACpeak)
Max. common mode input voltage: ± 700 V (DC + ACpeak) (common to both 1/10 and 1/100 attenuation ratios)

701932 DC to 100 MHz 30 Arms current probe



Bandwidth: DC to 100 MHz (-3 dB)
Max. continuous input range: 30 Arms
Amplitude accuracy: 0 to 30 Arms: $\pm 1\%$ of rdg ± 1 mV
Up to 500 Apeak: $\pm 2.0\%$ of rdg (DC, 45 to 66 Hz)
Weight: Approx. 240 g

701922 ± 20 V/200 MHz differential probe

Bandwidth: DC to 200 MHz (-3 dB)
Attenuation: 1/10 (fixed)
Max. allowable differential voltage: ± 20 V (DC + ACpeak)
Max. common mode input voltage: ± 60 V (DC + ACpeak)
Output impedance: 50 Ω

701931 DC to 20 MHz 500 Arms current probe



Bandwidth: DC to 2 MHz (-3 dB)
Max. continuous input range: 500 Arms
Amplitude accuracy: 0 to 500 Arms: $\pm 1\%$ of rdg ± 5 mV
Up to 700 Apeak: $\pm 2.0\%$ of rdg (DC, 45 to 66 Hz)
Weight: Approx. 520 g

Main Specifications

Models

Model name (No.)	Max. sampling rate	Freq. BW	Max. record length
DL9040 (701307)	5 GS/s	500 MHz	2.5 MW
DL9040L (701308)	5 GS/s	500 MHz	6.25 MW
DL9140 (701310)	5 GS/s	1 GHz	2.5 MW
DL9140L (701311)	5 GS/s	1 GHz	6.25 MW
DL9240 (701312)	10 GS/s	1.5 GHz	2.5 MW
DL9240L (701313)	10 GS/s	1.5 GHz	6.25 MW

Basic Specifications

Input channels:	4 (CH1 to CH4)
Input coupling:	AC, DC, GND, DC50Ω
Input impedance:	1 M Ω $\pm 1.0\%$ approx. 20 pF (when using PB500 probe, 10 M Ω $\pm 2.0\%$, approx. 14 pF) 50 Ω $\pm 1.5\%$
Voltage axis sensitivity:	For 1 M Ω input : 2 mV/div to 5 V/div (steps of 1-2-5) ranges For 50 Ω input : 2 mV/div to 500 mV/div (steps of 1-2-5) For 1 M Ω input : 150 Vrms CAT I For 50 Ω input : 5 Vrms or less and 10 Vpeak or less
Maximum input voltage:	For 1 M Ω input : 2 mV/div to 50 mV/div : ± 1 V 100 mV/div to 500 mV/div : ± 10 V 1 V/div to 5 V/div : ± 100 V

DC offset max. setting range: (When probe attenuation set to 1:1)	For 1 M Ω input : 2 mV/div to 50 mV/div : ± 1 V 100 mV/div to 500 mV/div : ± 10 V 1 V/div to 5 V/div : ± 100 V
For 50 Ω input	2 mV/div to 50 mV/div : ± 1 V 100 mV/div to 500 mV/div : ± 5 V

Vertical (voltage) axis sensitivity:	DC accuracy ¹ : For 1 M Ω input : $\pm 1.5\%$ of 8 div + offset voltage accuracy For 50 Ω input : $\pm 1.5\%$ of 8 div + offset voltage accuracy
Offset voltage axis accuracy ¹ :	2 mV/div to 50 mV/div : $\pm 1\%$ of setting + 0.2 mV 100 mV/div to 500 mV/div : $\pm 1\%$ of setting + 2 mV 1 V/div to 5 V/div : $\pm 1\%$ of setting + 20 mV

Voltage standing-wave ratio (VSWR): 1.5 or less within frequency bandwidth (typical value⁴)
Frequency characteristics^{1,2}: (Attenuation point of -3 dB when inputting a sinewave of amplitude ± 2 div or equivalent)

For 50 Ω input	DL9040/9040L DL9140/9140L DL9240/9240L
0.5 V/div to 10 mV/div:	DC to 500 MHz DC to 1 GHz DC to 1.5 GHz
5 mV/div:	DC to 400 MHz DC to 750 MHz DC to 1 GHz
2 mV/div:	DC to 400 MHz DC to 600 MHz DC to 750 MHz

For 1 M Ω input (from the probe tip when using the PB500 dedicated passive probe)	5 V/div to 10 mV/div: DC to 500 MHz DC to 500 MHz 5 mV/div to 2 mV/div: DC to 400 MHz DC to 400 MHz DC to 400 MHz
--	--

Residual noise level ³ :	0.4 mV rms or 0.05 div rms, whichever is larger (typical value ⁴)
-------------------------------------	---

A/D conversion resolution:	8-bit (25 LSB/div)
Bandwidth limit:	For each channel, select from FULL, 200 MHz, 20 MHz, 8 MHz, 4 MHz, 2 MHz, 1 MHz, 500 kHz, 250 kHz, 125 kHz, 62.5 kHz, 32 kHz, 16 kHz, and 8 kHz (separately configurable on each of the channels CH1 to CH4); Limit implemented with analog (200 MHz, 20 MHz) and digital filters (IIR+ FIR).
Max. sampling rate:	DL9040/9040L/9140/9140L DL9240/9240L
Real time sampling mode:	5 GS/s 10 GS/s

Interleave mode ON:	2.5 GS/s 5 GS/s
Interleave mode OFF:	2.5 TS/s 2.5 TS

Repetitive sampling mode:	2.5 TS/s 2.5 TS
Maximum record length	2.5 MW 6.25 MW

Time axis setting range:	500 ps/div to 50 s/div (steps of 1-2-5)
--------------------------	---

Time base accuracy¹: $\pm 0.001\%$

Time axis measurement accuracy¹: $\pm 0.01\% + 10$ ps + 1 sample interval

Max. acquisition rate⁵: When using 1.25 MW, 60 waveforms/sec/ch

When using 12.5 kW, 9000 waveforms/sec/ch

When using 2.5 kW, 25000 waveforms/sec/ch

400 ns or less (equivalent to 2.5 M waveforms/sec)

Trigger Section

Trigger modes: Auto, Auto Level, Normal, Single, and N Single

Trigger source: CH1 to CH4: LINE

EXT: Signals applied to measurement input terminals

Connected commercial power signal (only available with Edge trigger)

Signal input from EXT TRIG IN terminal

Trigger level range: ± 4 divisions from the screen center

CH1 to CH4: ± 2 V (1:1), ± 20 V (10:1 when used with a probe)

EXT: 0

Main Specifications



Functions

Waveform Acquisition/Display Functions:	
Acquisition modes:	Selectable from three acquisition modes – Normal, Average and Envelope
High resolution mode:	Vertical resolution is increased to max. 13 bits.
Repetitive sampling mode:	Allows switching between realtime and repetitive sampling in certain time axis settings.
Interpolate function:	Interpolates actual sampled data by up to 1000 times (or up to 2000 times in High-Res. mode) and increases the time resolution (up to 2.5 TS/s).
Roll mode:	Roll-mode display is enabled during the following time axis range when the trigger mode is Auto, Auto Level or Single: 100 ms/div to 50 s/div
Record length:	
DL9040L/9140L/9240L:	2.5 kW, 62.5 kW, 12.5 kW, 25 kW, 62.5 kW, 125 kW, 250 kW, 625 kW, 1.25 MW, 2.5 MW, 6.25 MW
DL9040/9140/9240:	2.5 kW, 62.5 kW, 12.5 kW, 25 kW, 62.5 kW, 125 kW, 250 kW, 625 kW, 1.25 MW, 2.5 MW
Accumulation:	Accumulates waveforms on the display. Choose Count/Time and Inten/Color.
Snapshot:	Retains the current displayed waveform on the screen.

Analysis Functions

Search and Zoom function:	Zooms the displayed waveform along the time (Horizontal Zoom) and voltage (Vertical Zoom) axes. Independent zooming factors can be applied to two zoom areas.
Voltage axis zoom factor:	1 to 10 times
Time axis zoom factor:	1 time to 1data/div
Auto scroll function:	Automatically scrolls the zoom window along the time axis
Search function:	Searches the currently displayed waveform for a specified portion occurring beyond a specified time, and displays the zoomed result on the screen.
Search types:	Edge, Edge Qualified, State, Pulse, Pulse Qualified, Pulse, State, Serial Pattern, I ^C (optional), SPI (optional)
History memory:	
Max data:	DL9040L/9140L/9240L: 2000 (2.5 kW), when using history 1600 (2.5 kW), when in N single mode
	DL9040/9140/9240: 1000 (2.5 kW), when using history 800 (2.5 kW), When in N single mode
History search:	Searches for and displays waveforms from the history memory that meet specified conditions.
Search types:	Rect, WAVE, Polygon, Parameter (Measure/FFT/XY)
Replay:	Automatically replays history waveforms.
Display:	Selected acquisition (#) or Average (Avg)
Cursor measurements:	The following five cursors can be selected: Vertical, Horizontal, VT, Marker, Serial
Automatic measurement of waveform parameters:	Performs automated measurement of the following waveform parameters.
Items unrelated to cycle which will be derived out of all data in the range.	MAX, MIN, HIGH, LOW, P-P, HIGH-LOW, +OVER, -OVER, RMS, MEAN, Sdev, IntegTY
Items related to cycle which will be derived out of all data in the range.	C.rms, C.mean, C.Sdev, C.IntegTY, (1/FREQ), FREQ, COUNT, BURST
Items which will be derived from the first encounter from the beginning of the specified range.	+WIDTH, -WIDTH, PERIOD, DUTY, RISE, FALL, DELAY
Telecom test:	Performs mask test and eye pattern measurement
Mask test items:	Wave Count, Wave Count%, Sample Point Count, Sample Point%
Eye pattern items:	Vtop, Vbase, stop, sbase, Tcrossing1, Tcrossing2, VCrossing, Crossing%, Eye Height, Eye Width, Q Factor, Jitter, Duty Cycle Distortion%, Ext Rate dB, Rise, Fall
Computation functions:	Computes up to eight traces (CH1-CH4/M1-M4) +, -, /, INTEG, COUNT (EDGE), COUNT (ROTARY), Through, Delay, Moving Avg, LowPass, High Pass, Stuff Bit (CAN option)
Reference functions:	Display and analysis (computation and cursors) of up to four traces (M1-M4) of the saved waveform data.
Action-on-trigger:	Waveforms including history can also be loaded for history searches or replay. Various parameters can be changed (however waveforms are not affected by T/Div changes).
Modes:	Automatically measured waveform parameters and waveform zones are determined, and the selected action is carried out each time conditions are met.
Actions:	OFF, All Condition, (GO/NOGO Zone/Param), GO/NOGO Telecom Test)
All conditions:	Buzzer, Print, Save, Mail
GO/NOGO zone:	After EXEC is pressed, the specified action is performed upon each acquisition
Zone types:	Determines whether or not the acquired waveform passes through the specified area
GO/NOGO parameter:	RECT, Polygon, WAVE
	Determines whether or not the specified parameter of the acquired waveform is within the specified range

Param: GO/NOGO telecom test:	Choose Measure, FFT, or XY
ANALYSIS:	Performs judgment using the conditions specified in the telecom test.
X-Y:	Selectable from XY, FFT, Wave Parameter, Accum Histogram and Serial Bus
FFT:	displays XY1, XY2 and T-Y simultaneously
Wave parameter:	supports up to 250 k points FFT
Accum histogram:	Single wave parameters can be viewed in one of the following formats. (Histogram, Trend and List)
Serial bus:	A histogram of the selected area can be displayed for a continuous signal.
	I ^C , SPI and CAN buses can be analyzed and the analysis results displayed (optional).

I^C Bus Analysis Functions (optional)

•Applicable bus:	I ^C bus: Bus speed : Max. 3.4 Mbit/s Address mode : 7 bit/10 bit
•Trigger function (standard):	SM bus: complies with System Management bus Source : SCL : CH1 to CH4 : SDA : CH1 to CH4
Type:	Selectable from the following five options:
- Address & data:	trigger on combination of assigned address & data pattern
- Non-Ack:	trigger on non acknowledge condition
- Every start:	trigger on start condition
- General call:	trigger on general call and the following byte
- Start byte / HS mode:	trigger on Start byte and HS mode
•Analysis function:	Signal input: CH1 to CH4, M1 to M4 can be configured Detailed data display mode: Time from the reference point, data (simultaneous binary and hex representations), presence/absence of ACK, R/W, address or data, start condition
Simple display mode:	Data (hex representation), R/W, start condition, presence/absence of ACK, address or data
Analyzable number of data items:	40,000 bytes max.
•Search function:	Pattern search: Searches data that agrees with the preset address pattern, data pattern and acknowledge bit condition.
•Analysis result save function:	Storage of analysis list data: The data can be saved to CSV-format files.

SPI Bus Analysis Functions (optional)

•Trigger function:	Mode: 3 wire/4 wire Bit order: MSB/LSB Source: Clock signal (SCK) CH1 to CH4
•Bit rate:	Data 1 (MOSI) CH1 to CH4 Data 2 (MISO) CH1 to CH4 CS signal (SS) CH1 to CH4
•Analysis function:	Analyzable number of data items: 40,000 bytes max.
Display of analysis results:	Analysis results can be displayed using the following 2 methods
- Simple analysis result list:	Data (hex representation), CS signal status
- Detailed analysis result display:	Detailed analysis result list, time from the reference point, data (select and show either Binary or Hex data), and CS signal status can be displayed.
•Search function:	Pattern search: Waveforms can be searched by specifying data pattern. When a waveform that agrees with the pattern is found, the zoom box moves to the position of that waveform to show the specified waveform.
•Analysis result save function:	Storage of analysis list data: The data can be saved to CSV-format files.

CAN Bus Analysis Functions (optional)

•Applicable bus:	CAN version 2.0 A/B High-speed CAN (ISO11898) Low-speed CAN (ISO11519-2)
•Bit rate:	1 Mbps, 500 kbps, 500 kbps, 250 kbps, 125 kbps, 83.3 kbps, user-defined
•Trigger function (standard):	Source: CH1 to CH4, Input through differential probe Type: SOF trigger Frame ID trigger Data field trigger: Selectable up to 8 bytes Remote Frame trigger Error Frame trigger Ack trigger

Frame ID, Data OR trigger, (Specify up to four ID, Data or ACK trigger conditions to set triggers on a logical OR condition.)	
Event Interval trigger	

•Analysis function:	Analyzable number of frames: 3,000 max. Analysis result display: Waveform and analysis list display Detailed analysis list display (Analysis display items: Frame type, time from trigger point, frame ID, DLC, Data, CRC, presence/absence of ACK)
•Analysis support functions:	Data search Field jump Stuff bit calculation
•Analysis result save function:	Storage of analysis list data: The data can be saved to CSV-format files.

Built-in Printer (B5 Option)

Printing method	Thermal line-dot
Paper width	112 mm
Effective print width	104 mm (832 dots)

Auxiliary I/O Section

Rear panel I/O signal:	Ext. trigger input, ext. trigger output, trigger comparator output, GO/NO-GO I/O, video output
Probe interface terminal (front panel)	No. of terminals: 4 Supported probes: PBA2500, PBD2000, PB500
Probe power terminal (/P2 option, rear panel):	No. of terminals: 2 Supported probes: FET probe (700939), current probes (701930, 701931, 701932, 701933), and differential probes (701920, 701921, 701922)

Storage

Internal storage media:	Capacity: 90 MB (Flash ROM) Usage: Saving and loading of waveforms and panel settings
-------------------------	--

Internal Hard Drive (C8 Option)

Capacity/file system:	40 GB FAT32
File name:	Supports long file names of up to 256 ASCII characters

USB Peripheral Connection Ports

Connector:	USB-type A connector × 2
Supported transmission standards:	LS (Low Speed) mode (1.5 Mbps), FS (Full Speed) mode (12 Mbps)
Supported devices:	USB HID Class Ver.1.1-compliant mouse/109 keyboard USB Printer Class Ver.1.0-compliant printers EPSON: Ink Jet Printers HP: PCL Ink Jet Printers USB Mass Storage Class Ver.1.1-compliant mass storage device USB hub device (1 unit only)
	* Please contact your local Yokogawa sales office for model names of verified devices
Max. No. of devices:	4

PC Card Interfaces

Number of slots:	2 (front panel (1), rear panel (1))
Supported cards:	GPIO card (National Instruments NI PCMCIA-GPIB card), Flash ATA memory card (PC card TYPE II), CF card + adapter card, and various hard disk type PC cards
	* Please contact your local Yokogawa sales office for model names of verified devices

USB-PC Connection Ports

Connector:	USB-type B connector × 1
Supported transmission standards:	HS (High Speed) mode, FS (Full Speed) mode
Supported class:	Operates as a multifunction

Model and Suffix Codes of DL9040/9140/9240

Model	Suffix Code	Description
701307		DL9040 digital oscilloscope 500 MHz max. 5 GS/s (2.5 GS/s/ch), 2.5 Mword/ch
701308		DL9040L digital oscilloscope 500 MHz max. 5 GS/s (2.5 GS/s/ch), 6.25 Mword/ch
701310		DL9140 digital oscilloscope 1 GHz max. 5 GS/s (2.5 GS/s/ch), 2.5 Mword/ch
701311		DL9140L digital oscilloscope 1 GHz max. 5 GS/s (2.5 GS/s/ch), 6.25 Mword/ch
701312		DL9240 digital oscilloscope 1.5 GHz max. 10 GS/s (5 GS/s/ch), 2.5 Mword/ch
701313		DL9240L digital oscilloscope 1.5 GHz max. 10 GS/s (5 GS/s/ch), 6.25 Mword/ch
Power cable	-D	UL/CSA standard
	-F	VDE standard
	-Q	BS standard
	-R	AS standard
	-H	GB standard
Help menu language	-HE	English Help
	-HC	Chinese Help
	-HK	Korean Help
Options	/B5	Built-in printer
	/P2 ¹	Probe power connections on rear panel (2 outputs for 900 MHz FET probe and current probe)
	/C8 ²	Built-in hard disk + Ethernet interface
	/C10 ²	Ethernet interface
	/F5 ³	I ² C + SPI bus analyzer
	/F7 ³	CAN + SPI bus analyzer
	/F8 ³	I ² C + CAN + SPI bus analyzer

1: Please specify this /P2 option if you use either current probes or differential probes such as 701920 or 701922.

2: Choose either one.

3: Choose either one. I²C, CAN and SPI bus signal triggers are standard.

[*signalXplorer* is a registered trademark of Yokogawa Electric Corporation.]

Microsoft, MS, Windows, and Internet Explorer are registered trademarks or trademarks of Microsoft Corporation in the US and other countries.

This product's TCP/IP software and documentation on TCP/IP software were developed/manufactured by Yokogawa based on BSD Networking Software, Release1, under license from the University of California.

Other company names and product names appearing in this document are the registered trademarks or trademarks of their respective companies.

Standard Accessories

Name	Qty
Power cable	1
3 prong-to-2 prong adapter	1
PB500 passive probe	4
Printer roll paper (when option /B5 is specified)	3
User's manual (1 set)	1
Front panel cover	1
Rubber leg cap	6
Soft case	1

Accessories (Optional)

Name	Model	Specifications
PB500 (10:1 passive probe)	701943	10 MΩ (10:1), 500 MHz, 1.5 m (one per order)
Mini-clip converter	700971	For use with PB500
BNC adapter	700972	For use with PB500
Grounding lead	700973	For use with PB500
PBA2500 (2.5 GHz active probe)	701913	2.5 GHz BW
PBL5000 (5 GHz probe)	701974	5 GHz BW
DC block	701975	For 50 Ω input, SMA connector
FET probe*	700939	900 MHz BW
100:1 probe	700978	100 MHz BW
Differential probe	701921	DC to 100 MHz BW/±700 V Max.
Differential probe*	701922	DC to 200 MHz BW/±20 V Max.
PBD2000 (2 GHz differential probe)	701923	2 GHz BW
Differential probe	700924	DC to 100 MHz BW/±1400 V Max.
Differential probe*	701920	DC to 500 MHz BW/±30 V Max.
Current probe*	701933	DC to 50 MHz BW, 30 Arms
Current probe*	701932	DC to 100 MHz BW, 30 Arms
Printer roll paper	B9988AE	10 m roll, 10 rolls/order
Rack mount kit	701984-01	EIA standard-compliant
	701984-02	JIS standard-compliant

* requires /P2 option on the DL9000.

Related Products

DL74000 series digital oscilloscopes



DL1700E series digital oscilloscopes



Note



• Before operating the product, read the user's manual thoroughly for proper and safe operation.

Yokogawa's Approach to Preserving the Environment

- Yokogawa's electrical products are developed and produced in facilities that have received ISO14001 approval.
- In order to protect the global environment, Yokogawa's electrical products are designed in accordance with Yokogawa's Environmentally Friendly Product Design Guideline and Product Design Assessment Criteria.



YOKOGAWA ELECTRIC CORPORATION

Communication & Measurement Business Headquarters /Phone: (81)-422-52-6768, Fax: (81)-422-52-6624
E-mail: tm@cs.jp.yokogawa.com

YOKOGAWA CORPORATION OF AMERICA

Phone: (1)-770-253-7000, Fax: (1)-770-251-6427

YOKOGAWA EUROPE B.V.

Phone: (31)-33-4641858, Fax: (31)-33-4641859

YOKOGAWA ENGINEERING ASIA PTE. LTD.

Phone: (65)-62419933, Fax: (65)-62412606

Subject to change without notice.

[Ed : 03/b] Copyright ©2005
Printed in Japan, 608(KP)